Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

K&F CONCEPT S255A3+BH-36

K&F CONCEPT S255A3+BH-36 75-inch Camera Tripod Instruction Manual

Model: S255A3+BH-36

1. Product Overview

The K&F CONCEPT S255A3+BH-36 is a lightweight and portable camera tripod designed for various photography and videography needs. It features a unique pentagonal tube design for enhanced stability, an adjustable height up to 75 inches (190 cm), and a 360-degree ball head for precise camera positioning. This tripod is compatible with cameras, cell phones, projectors, webcams, and ring lights.

Package Contents:

- K&F Concept Camera Tripod (S255A3+BH-36) x1
- Quick Release Plate x3
- Cellphone & Tablet Clip x1
- Remote Control x1
- Instruction Manual x1
- Tripod Bag x1



Image: The K&F CONCEPT S255A3+BH-36 tripod shown with its included accessories, including quick release plates, phone/tablet clip, and remote control.

2. Safety Information

- Always ensure all locking mechanisms are securely tightened before mounting equipment or leaving the tripod unattended.
- Do not exceed the maximum load capacity of 8kg (17.6lbs) to prevent damage to the tripod or attached equipment.
- Avoid placing the tripod on unstable or slippery surfaces without proper precautions.
- Keep hands and fingers clear of moving parts when adjusting the tripod to prevent pinching.
- Do not expose the tripod to extreme temperatures or corrosive substances.

3. Setup

3.1 Unpacking

Carefully remove all components from the packaging. Verify that all items listed in the 'Package Contents' section are present.

3.2 Attaching the Ball Head

The BH-36 ball head comes pre-attached to the tripod. If removed for any reason, align the 3/8"-16 screw on the tripod's top plate with the corresponding thread on the ball head and rotate clockwise until secure. Ensure the quick release plate is properly seated and locked on the ball head.



Image: Detailed view of the BH-36 Ball Head, showing the 1/4" screw, quick release plate, bubble level, pan lock knob, and tripod head locking knob.

3.3 Extending the Legs

To extend the tripod legs, release the quick flip locks on each leg section. Extend the legs to the desired height and angle, then firmly close the flip locks to secure them. The pentagonal tube design ensures stability at various extensions.



Image: Visual representation of the tripod's adjustable height, ranging from a compact 19 inches (48 cm) to a maximum of 75 inches (190 cm).

3.4 Adjusting the Center Column

The center column can be extended for additional height. Loosen the center column locking knob, raise the column to the desired position, and then tighten the knob to secure it. For added stability, especially in windy conditions, a camera bag or other weight can be hung from the bottom hook of the center column.



Image: Close-up of tripod details, highlighting the center column locking knob, quick flip locks on the legs, and the weight hanging hook for stability.

3.5 Attaching Camera or Device

Attach your camera or device to one of the quick release plates. Slide the quick release plate into the ball head's receiver and secure it using the quick release plate switch. The tripod includes a cellphone and tablet clip for smartphone and tablet compatibility.




Image: The tripod shown in use with a smartphone, camera, iPad, telescope, projector, and ring light, illustrating its wide compatibility.

3.6 Using the Remote Control

The included Bluetooth remote control allows for wireless photo capture with compatible smartphones. Refer to the remote control's specific instructions for pairing with your device.

Your browser does not support the video tag.

Video: This video demonstrates the K&F CONCEPT S255A3+BH-36 Compact Tripod with Ball Head, showcasing its portability, adjustable height, 36mm ball head for precise control, and compatibility with various devices using 1/4" and 3/8" standard screws. It also highlights the included accessories and carrying bag.

4. Operating Instructions

4.1 Adjusting the Ball Head

The 36mm ball head provides smooth 360-degree panning and versatile angle adjustments. Loosen the tripod head locking knob to adjust the camera angle, then tighten it to secure. Use the pan lock knob for smooth horizontal rotation.

4.2 Enhancing Stability

For maximum stability, ensure the tripod legs are fully extended and spread. The non-slip rubber pads on the feet improve grip on various surfaces. In windy conditions or with heavier equipment, utilize the bottom hook on the center column to hang additional weight, such as a camera bag.

4.3 Folding for Storage

To fold the tripod, remove any attached devices and accessories. Retract the center column and collapse the legs by releasing the quick flip locks. Fold the legs upwards, aligning them with the center column for a compact storage size of approximately 19.7 inches (50 cm). Store the tripod in its carrying bag.



Image: The tripod shown in its folded, compact state, highlighting its small storage diameter for easy portability.

5. Maintenance

- Clean the tripod regularly with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- If used in dusty or sandy environments, carefully clean the leg locks and joints to prevent grit from affecting

operation.

- Store the tripod in its carrying bag in a dry, cool place away from direct sunlight and moisture.
- Periodically check all screws and locking mechanisms for tightness and adjust as needed.

6. Troubleshooting

6.1 Tripod Instability

- **Issue:** Tripod wobbles or feels unstable.
- **Solution:** Ensure all leg sections are fully extended and their quick flip locks are securely fastened. Verify the center column locking knob is tight. If using on uneven ground, adjust individual leg lengths to level the tripod. Consider hanging a weight from the center column hook for increased stability.

6.2 Ball Head Movement Issues

- **Issue:** Ball head does not move smoothly or does not lock securely.
- **Solution:** Check that the tripod head locking knob is sufficiently loosened for movement and fully tightened for locking. Ensure no debris is obstructing the ball mechanism.

6.3 Remote Control Not Connecting

- **Issue:** Bluetooth remote control fails to pair with a smartphone.
- **Solution:** Ensure the remote control has power (check battery). Activate Bluetooth on your smartphone and put the remote into pairing mode (refer to remote's specific instructions). Make sure no other devices are interfering with the Bluetooth connection.

7. Specifications

Feature	Specification
Model Name	S255A3
Item Model Number	S255A3+BH-36
Brand	K&F CONCEPT
Material	Aluminum
Color	Black
Maximum Height	190 Centimeters (75 inches)
Minimum Height	48 Centimeters (19 inches)
Folded Size	50 Centimeters (19.7 inches)
Item Weight	1.3 Kilograms (2.86 pounds)
Weight Limit	17 Pounds (8 kg)
Tripod Head Type	Ball Heads (BH-36)
Special Feature	Foldable
Compatible Devices	Camcorder, Camera, Smartphone, Tablet

Batteries	1 Lithium Metal battery required (included for remote)

8. Warranty and Support

K&F CONCEPT products are designed for quality and reliability. For warranty information, technical support, or service inquiries, please refer to the official K&F CONCEPT website or contact their customer service directly. Keep your purchase receipt for warranty claims.
For additional resources and product information, visit theK&F CONCEPT Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT73M2KT

More documents and user manuals: **https://manuals.plus/**