

[Manuals.plus](#) /

› [Sunbeam](#) /

› Sunbeam ReviveSystem 3-in-1 Steam, Iron & Fabric Shaver Instruction Manual (Model 32610087)

Sunbeam 32610087

Sunbeam ReviveSystem 3-in-1 Steam, Iron & Fabric Shaver (Model 32610087)

Your comprehensive guide to garment care with 1000W power, ceramic soleplate, and integrated lint removal.

1. INTRODUCTION

The Sunbeam ReviveSystem 3-in-1 device is designed to simplify your garment care routine. It combines the functions of a steam iron, a garment steamer, and a fabric shaver into one compact unit. With 1000W of power, a durable die-cast ceramic soleplate, and a unique 6-leaf blade for lint removal, this versatile tool ensures your clothes are wrinkle-free and look their best.

This manual provides detailed instructions for safe and effective operation, maintenance, and troubleshooting.

2. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the voltage on the rating label corresponds to your mains voltage.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children and pets.
- Do not leave the appliance unattended while it is switched on or connected to the mains supply.
- Always unplug the appliance from the mains supply before filling or emptying the water tank, cleaning, or when not in use.
- The soleplate and steam outlet can become extremely hot and may cause burns. Handle with care.
- Do not direct steam towards people, animals, or electrical appliances.
- Use only distilled or demineralized water in the water tank to prevent mineral buildup.
- Do not use the fabric shaver on delicate fabrics that may snag.
- Ensure the fabric shaver's protective mesh is securely in place before operation.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Sunbeam ReviveSystem 3-in-1 device:

- **Ceramic Soleplate:** For ironing and steaming.
- **Detachable Water Tank (90ml):** For easy filling and emptying.
- **Power Button:** To turn the device on/off.
- **Steam Trigger/Continuous Steam Button:** To activate steam.
- **Fabric Shaver Head:** Integrated lint remover with 6-leaf blade.
- **Lint Collection Compartment:** To collect removed lint.
- **Foldable Handle:** For compact storage.
- **10-Foot Power Cord:** For extended reach.



Figure 1: Sunbeam ReviveSystem 3-in-1 device with included accessories (water fill cup, storage bag, fabric brush, heat insulation cover).

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.

2. Fill Water Tank:

- Ensure the device is unplugged.
- Detach the 90ml water tank by pressing the release button.
- Use the provided water fill cup to fill the tank with distilled or demineralized water. Do not overfill.
- Reattach the water tank securely until it clicks into place.



Figure 2: Detaching and filling the water reservoir.

3. Attach Accessories (Optional):

- For steaming delicate fabrics or removing lint, attach the fabric brush or heat insulation cover as needed.



Figure 3: Attaching the brush head for steaming.

5. OPERATING INSTRUCTIONS

5.1 Power On and Heat-Up

1. Plug the 10-foot power cord into a suitable electrical outlet.
2. Press the power button located on the handle. The indicator light will illuminate.
3. Allow approximately 30 seconds for the device to heat up. The indicator light will change or stop flashing when ready.



Figure 4: Quick 30-second heat-up time.

5.2 Ironing Function (Horizontal Use)

For traditional ironing, use the ceramic soleplate on a flat, heat-resistant surface (e.g., ironing board).

1. Place the garment flat on your ironing surface.
2. Gently glide the ceramic soleplate over the fabric.
3. To release a burst of steam, press the steam trigger. For continuous steam, press the continuous steam button.
4. The durable die-cast ceramic soleplate ensures smooth, wrinkle-free results.

CERAMIC NONSTICK COATED SOLEPLATE

*GLIDES OVER
MATERIALS SMOOTHLY*



INSULATION COVER



Figure 5: Ceramic soleplate for smooth ironing.

5.3 Steaming Function (Vertical Use)

For vertical steaming, hang your garment on a hanger.

1. Hang the garment securely.
2. Hold the steamer upright, a few inches away from the fabric.
3. Press the steam trigger for bursts of steam or the continuous steam button for a steady flow.
4. Move the steamer slowly over the fabric, allowing the steam to relax wrinkles.
5. The device provides up to 7 minutes of continuous steam.

5.4 Fabric Shaver Function

The integrated electric shaver removes lint and pills from fabrics.

1. Ensure the device is clean and free of water before using the shaver function.
2. Lay the garment flat on a clean, firm surface.
3. Gently press the fabric shaver head against the fabric and move it in circular motions or short strokes.
4. The unique 6-leaf blade and honeycomb mesh protection ensure rapid and safe lint removal.



Figure 6: Using the integrated fabric shaver.

Your browser does not support the video tag.

Video 1: Official product demonstration of the 3-in-1 Iron, Steamer, Fabric Shaver functions.

6. MAINTENANCE

6.1 Cleaning the Water Tank

1. Ensure the device is unplugged and cooled down.
2. Detach the water tank and empty any remaining water.
3. Rinse the tank with clean water. Do not use harsh detergents.
4. Allow the tank to air dry before reattaching or storing.

6.2 Cleaning the Soleplate

1. Ensure the device is unplugged and completely cool.
2. Wipe the ceramic soleplate with a soft, damp cloth.
3. Do not use abrasive cleaners or scouring pads, as these can damage the nonstick coating.

6.3 Emptying the Lint Collection Compartment

1. Ensure the device is turned off and unplugged.
2. Carefully remove the lint collection compartment.
3. Empty the collected lint into a waste bin.
4. Clean any remaining lint from the compartment and surrounding area with the provided brush.
5. Reattach the compartment securely.

6.4 Replacing Fabric Shaver Blades

An extra 6-leaf blade is included for replacement when the original blade becomes dull.

1. Ensure the device is turned off and unplugged.
2. Carefully twist and remove the protective mesh cover of the fabric shaver.
3. Gently lift out the old blade assembly.
4. Insert the new blade assembly, ensuring it sits correctly.
5. Replace the protective mesh cover by twisting it back into place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam produced.	Water tank is empty or not properly seated. Device not heated up.	Fill water tank and ensure it's securely attached. Wait 30 seconds for heat-up.
Water dripping from soleplate.	Device not hot enough for steam. Overfilled water tank.	Allow device to fully heat up. Do not overfill water tank.
Fabric shaver not effective.	Lint compartment full. Blades are dull.	Empty lint compartment. Replace shaver blades.
Device not turning on.	Not plugged in. Power button not pressed.	Ensure power cord is securely plugged in. Press the power button firmly.

8. SPECIFICATIONS

- **Brand:** Sunbeam
- **Model Number:** 32610087
- **Power:** 1000 Watts
- **Voltage:** 120 Volts
- **Water Tank Capacity:** 90 ml (3 oz)
- **Heat-Up Time:** 30 Seconds
- **Continuous Steam Time:** Up to 7 minutes
- **Soleplate Material:** Durable Die-Cast Ceramic
- **Fabric Shaver Blade:** 6-Leaf
- **Power Cord Length:** 10 feet
- **Product Dimensions:** 6.06"L x 3.07"W x 8.66"H
- **Item Weight:** 1.87 Pounds

- **Color:** Pearl White

9. WARRANTY AND SUPPORT

The Sunbeam ReviveSystem 3-in-1 Steam, Iron & Fabric Shaver is backed by a **3-Year Limited Warranty**.

For warranty claims, technical support, or replacement parts, please contact Sunbeam Customer Service:

- **Website:** www.sunbeam.com
- **Phone:** Refer to your product registration card or visit the website for local contact numbers.

Please have your model number (32610087) and proof of purchase ready when contacting support.