Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ProCraft AD110-2X

ProCraft AD110-2X Female 1/8" to Male RCA Adapters Instruction Manual

Model: AD110-2X | Brand: ProCraft (by usbargainsound)

Introduction

Thank you for choosing the ProCraft AD110-2X Female 1/8" (3.5 Mono) to Male RCA Adapters. These adapters are designed to convert a 1/8" (3.5mm) mono audio signal from a female jack to a male RCA plug, allowing for versatile audio connections between various devices. This manual provides essential information for the safe and effective use of your adapters.

Safety Information

- Ensure all audio equipment is powered off before connecting or disconnecting adapters to prevent damage to devices or hearing.
- Do not expose adapters to extreme temperatures, moisture, or corrosive substances.
- Keep out of reach of children.
- Avoid excessive force when plugging or unplugging to prevent damage to the connectors.

Package Contents

- One (1) Pair of ProCraft Female 1/8" (3.5 Mono) to Male RCA Adapters (AD110-2X)



Image: A pair of ProCraft AD110-2X adapters. Each adapter features a female 1/8" (3.5mm) mono jack on one end and a male RCA plug on the other, designed for audio signal conversion.

Setup and Connection

1. **Identify Connectors:** Locate the 1/8" (3.5mm) mono female jack on the adapter and the male RCA plug.
2. **Connect Source:** Insert the 1/8" (3.5mm) mono male plug from your audio source (e.g., a mono microphone, instrument output) into the female 1/8" (3.5mm) jack of the ProCraft adapter.
3. **Connect Destination:** Insert the male RCA plug of the ProCraft adapter into the RCA input jack of your receiving audio device (e.g., amplifier, mixer, speaker).
4. **Secure Connection:** Ensure both connections are firm and fully seated to prevent signal loss or intermittent audio.

These adapters are typically used to connect devices with a 1/8" mono output to equipment that requires an RCA input. For stereo signals, two adapters would be required, one for the left channel and one for the right channel, if the 1/8" source is stereo and you are converting to dual RCA mono inputs.

Operating Instructions

Once properly connected, the ProCraft AD110-2X adapters function passively to convert the audio signal. No additional power or configuration is required. Simply ensure your audio source is playing and your receiving device is powered on and set to the correct input.

- Verify that the volume levels on both your source and destination devices are set appropriately before playing audio to avoid sudden loud sounds.
- These adapters are designed for mono signals. If connecting a stereo 1/8" source to a stereo RCA input, you will

need two adapters and a stereo 1/8" to dual mono 1/8" cable, or a dedicated stereo adapter.

Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to wipe the adapters. Do not use liquid cleaners or solvents.
- **Storage:** Store adapters in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Handling:** Always grasp the connector housing when plugging or unplugging, not the cable (if applicable) or the adapter body itself, to prevent strain on the connections.

Troubleshooting

Problem	Possible Cause	Solution
No audio output	Loose connection Incorrect input selected on receiving device Volume too low on source or destination Faulty cable or device	Ensure all connections are secure. Select the correct input on your amplifier/mixer. Increase volume on both devices. Test with different cables or devices to isolate the issue.
Poor audio quality (static, hum)	Loose connection Interference from other electronics Damaged adapter or cable	Check and secure all connections. Move adapters/cables away from power sources or other electronics. Inspect adapter for visible damage; replace if necessary.

Specifications

- **Model:** AD110-2X
- **Connector 1:** 1/8" (3.5mm) Mono Female
- **Connector 2:** RCA Male
- **Type:** Audio Adapter
- **Brand:** ProCraft (by usbargainsound)
- **ASIN:** B0DT7FYJMB
- **UPC:** 810145864685

Warranty and Support

For warranty information or technical support, please refer to the seller's return policy or contact usbargainsound directly through their official channels. Specific warranty terms may vary based on the point of purchase.
Seller: usbargainsound
Return Policy: 30 days (as per Amazon's buybox winner information)

© 2026 usbargainsound. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT7FYJMB

More documents and user manuals: **https://manuals.plus/**