

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bonacell](#) /

› [Bonacell Wireless Controller Instruction Manual for PS4/PS5/PC](#)

Bonacell B0DT8G5RST

Bonacell Wireless Controller Instruction Manual

Model: B0DT8G5RST

INTRODUCTION

Thank you for choosing the Bonacell Wireless Controller. This manual provides detailed instructions for setting up, operating, and maintaining your controller. Please read this manual carefully before use to ensure optimal performance and longevity of your device.



Image: The Bonacell Wireless Controller, black with blue illuminated buttons, shown alongside its white USB receiver adapter.

PRODUCT FEATURES

- **Wide Compatibility:** Supports PS4, PS5, PC (Windows), Android, and iOS devices.
- **Dual Motor Vibration:** Enhances gaming immersion with realistic haptic feedback.
- **6-Axis Gyroscope Sensor:** Provides precise motion control for supported games.
- **Turbo Function:** Enables continuous rapid input for specific buttons.
- **3.5mm Audio Jack:** Allows connection of headphones for in-game audio.
- **Touchpad:** Integrated touchpad for additional control options.
- **RGB Multi-color Buttons:** Customizable lighting effects for personalized aesthetics.
- **Long Battery Life:** Built-in 1000mAh battery provides extended usage.



Image: Close-up views highlighting the controller's 360-degree joysticks, 3.5mm headphone jack, and 6-axis gyroscope sensor.

SETUP AND CONNECTION

1. Charging the Controller

The controller is equipped with a 1000mAh battery. Before first use, or when the battery is low, charge the controller using the provided Type-C cable or a compatible charging base.

- **Charging Time:** Approximately 2.5 hours.
- **Usage Time:** Up to 16 hours on a full charge.



Image: Visual representation of the controller's battery specifications, including its 1000mAh capacity, working time, and charging duration.

2. Connecting to PS5 (Wireless Receiver)

To play PS5 games, the controller must be connected via the wireless receiver. Direct Type-C cable connection does not support PS5 games.

1. **Step 1:** Plug the wireless receiver adapter into a USB port on your PS5 console. Briefly press the pairing button on the adapter.
2. **Step 2:** On the Bonacell Wireless Controller, press and hold the **SHARE** button and then hold the **P** button simultaneously for 5 seconds to enter pairing mode.
3. **Step 3:** Once successfully paired, the lights on both the controller and the adapter will remain illuminated.

Note: For the first connection, it is recommended to activate the device with a USB cable before attempting wireless pairing.

Pairing Steps

Step 1

Plug the adapter into the PS5 console USB port and press the adapter pairing button.



Step 2

Press and hold the PS4 controller "SHARE" button + "PS" button for 5 seconds to enter pairing mode.



Step 3

The lights of both the controller and the adapter are always on, the connection is successful!



Image: A three-step visual guide demonstrating how to pair the controller with a PS5 console using the USB adapter.

3. Connecting to PC (Wired)

Connect the controller to your PC directly using the Type-C data cable.

4. Connecting to PC (Bluetooth)

1. **Step 1:** Ensure your PC's Bluetooth function is enabled.
2. **Step 2:** On the Bonacell Wireless Controller, press and hold the **SHARE** button and the **P** button simultaneously for 3 seconds to enter pairing mode.
3. **Step 3:** On your PC, search for and select the controller from the list of available Bluetooth devices to complete the pairing.

5. Connecting to Android and iOS (Bluetooth)

Supports iOS 13+ devices.

1. **Step 1:** Activate the Bluetooth function on your mobile phone or tablet.
2. **Step 2:** On the Bonacell Wireless Controller, press and hold the **SHARE** button and the **P** button simultaneously for 3

seconds to enter pairing mode.

3. **Step 3:** On your mobile device, search for and select the controller from the list of available Bluetooth devices to complete the pairing.



Image: An illustration showing the Bonacell Wireless Controller's compatibility with various platforms such as PS5, PS4, PC, Android, and iOS.

OPERATING INSTRUCTIONS

1. RGB Multi-color Button Customization

- To change the light color: Press and hold the **L3** button and the **R3** button simultaneously for 3 seconds. The controller will vibrate for 1 second, indicating that the light color can now be changed.
- To switch light effect modes: Press and hold the **SET** button and the **R3** button simultaneously. Cycle through modes: Colorful → Monochrome → Colorful Transformation → Monochrome Breathing.

2. Turbo Function

The Turbo function allows for continuous rapid input of a button press. This can be useful in games requiring fast, repeated actions.

Specific instructions for activating and deactivating the Turbo function are typically found in the game's control settings or may involve a combination of the Turbo button (if present) and another action button. Refer to the controller's quick start guide or product packaging for exact button combinations if not detailed here.



Image: An illustration highlighting the dual vibration motors and the Turbo function capability of the controller.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the controller. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the controller frequently. Charge it regularly, even if not in use for extended periods.

TROUBLESHOOTING

- **Controller not connecting:**
 - Ensure the controller is charged.
 - Verify the correct pairing procedure for your device (PS5, PC, Android/iOS).
 - For PS5, ensure you are using the wireless receiver.
 - For Bluetooth connections, ensure Bluetooth is enabled on your host device and the controller is in pairing mode.
 - Try restarting both the controller and the host device.
- **Buttons or joysticks not responding:**
 - Ensure the controller is properly connected.
 - Check for any physical obstructions or debris around the buttons/joysticks.
 - If connected via PC, ensure drivers are up to date.
- **Vibration not working:**
 - Ensure the game supports vibration feedback.
 - Check in-game settings to ensure vibration is enabled.


SPECIFICATIONS

Feature	Detail
Product Name	Wireless Controller
Model Number	B0DT8G5RST
Dimensions	165 x 105 x 45 mm
Weight	0.26 kg (Item Package Weight: 300 g)
Battery Capacity	1000mAh Lithium Ion
Usage Time	Up to 16 hours
Charging Time	Approximately 2.5 hours
Charging Method	Base or Type-C charging
Connectivity	2.4GHz USB Receiver, Bluetooth, USB-C (wired)
Compatibility	PS4, PS5, PC (Windows), Android (iOS 13+)
Key Features	Dual Shock Motor, Six-Axis Gyroscope, Touchpad, 3.5mm Audio Jack, Turbo Function, RGB Buttons
Material	ABS

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Bonacell customer service through the retailer's platform where the product was purchased.

Related Documents - B0DT8G5RST

<p>Wireless Controller Operation Manual</p>  <p><small>Please read the manual carefully. Misuse may result in injury, damage to the equipment, or loss of data. Please read the manual thoroughly before using the product.</small></p>	<p>Bonacell RH-088-F Wireless Controller Operation Manual</p> <p>User manual for the Bonacell RH-088-F Wireless Controller, detailing setup, features like RGB lighting and turbo function, and connectivity options for Android, iOS, Windows, macOS, PS4, and PS3.</p>
--	--