Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UML0 N3S

UML0 N3S Cordless Vacuum Cleaner Instruction Manual

Brand: UML0 | Model: N3S

1. Introduction

Thank you for choosing the UML0 N3S Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before first use and keep it for future reference.

2. Package Contents

Upon unpacking, please ensure all components listed below are present and in good condition:

- Main Motor Unit
- Adjustable Metal Tube
- Motorized Floor Brush with LED Lights
- 2-in-1 Brush (Crevice Tool & Dusting Brush)
- Long Crevice Tool
- Wall Mount Bracket with Screws
- Power Adapter
- Washable HEPA Filter (2 included, 1 pre-installed)
- 2-in-1 Cleaning Gadget (for brush roll and filter)
- User Manual



Image: All components of the UML0 N3S Cordless Vacuum Cleaner, including the main unit, extension tube, various attachments, and charging accessories.

Video: Unboxing and Quick Look-N3S Cordless Vacuum. This video demonstrates the contents of the package and initial assembly steps.

3. Setup and Assembly

Your UML0 N3S vacuum cleaner is designed for easy assembly and versatile use. Follow these steps to set up your device:

1. **Attach the Extension Tube:** Align the adjustable metal tube with the main motor unit and click it into place.

2. **Attach the Motorized Floor Brush:** Connect the motorized floor brush to the other end of the extension tube. Ensure it clicks securely.
3. **Install Battery:** The battery pack slides into the main motor unit until it clicks. The vacuum can be charged with the battery installed or removed.
4. **Wall Mount Installation (Optional):** Use the provided wall mount bracket and screws to install the charging dock in a convenient location near an electrical outlet. This allows for easy storage and charging.



Image: The UML0 N3S Cordless Vacuum Cleaner fully assembled with the extension tube and motorized floor brush, alongside its various cleaning attachments.

4. Operating Instructions

The UML0 N3S offers powerful suction and versatile cleaning modes for various surfaces.

Power On/Off and Speed Modes

- **Power On/Off:** Press the power button on the handle to turn the vacuum on or off.

- **Adjust Suction:** The vacuum features two suction modes: Standard and Max. Press the speed control button to switch between modes.

Cleaning Different Surfaces

- **Hard Floors & Low-Pile Carpets:** Use the motorized floor brush. Its V-shaped 2-in-1 brush roller is effective on both surfaces. LED headlights illuminate dark areas for thorough cleaning.
- **Versatile Cleaning:** The lightweight main motor (2.2 lbs) and multiple accessories allow for cleaning cars, beds, furniture, curtains, and sofas.
- **Maneuverability:** The flexible 180° swivel and 90° up and down movement of the brush head allow easy access to hard-to-reach areas under furniture and beds.

Self-Standing Feature

The vacuum is designed with a self-standing feature. When the main unit is upright, the brush head locks into position, preventing the vacuum from falling over, making storage convenient.



Image: The UML0 N3S Cordless Vacuum Cleaner demonstrating its self-standing feature, ideal for convenient storage.

Video: Powerful Suction Cordless Vacuum Cleaner. This video showcases the vacuum's suction capabilities on various debris.

Video: Cordless Vacuum Cleaners for Home, Hard Floor and Carpet-N3S. Demonstrates the vacuum's effectiveness on different floor types.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your UML0 N3S vacuum cleaner.

Emptying the Dust Cup

To empty the dust cup, simply press the release button on the side of the main unit. The bottom flap will open, allowing you to dump collected debris directly into a trash bin.

Cleaning the Filters

The 4-stage high-efficiency filtration system includes a washable HEPA filter. Regular cleaning and replacement of the filter are crucial for maintaining powerful suction and preventing secondary pollution. Two extra filters are included as backup.

- To access the filter, twist and remove the dust cup from the main unit.
- Remove the filter and tap it gently to dislodge loose dirt.
- Rinse the filter under running water until clean. Ensure it is completely dry before reinserting.

Cleaning the Motorized Brush Roll

The motorized brush roll is designed for easy removal and cleaning to prevent hair tangles and maintain efficiency.

- Locate the release latch on the side of the brush head and open it.
- Pull the brush roll out.
- Use the provided 2-in-1 cleaning gadget to cut and remove any tangled hair or fibers from the brush roll.
- Reinsert the clean brush roll and secure the latch.



Image: Detailed diagram of the 4-stage high-efficiency filtration system, highlighting the washable HEPA filter.

Video: How to clean the filters and the motorized brush. This video provides a step-by-step guide for maintaining the vacuum's filters and brush.

6. Troubleshooting

If you encounter any issues with your UML0 N3S Cordless Vacuum Cleaner, please refer to the following common solutions:

Problem	Possible Cause	Solution
No Power / Not Turning On	Battery is not charged or not properly installed.	Ensure the battery is fully charged and securely clicked into the main unit. Check power adapter connection.

Problem	Possible Cause	Solution
Loss of Suction	Dust cup is full, filter is clogged, or brush roll is tangled.	Empty the dust cup. Clean or replace the HEPA filter. Remove any tangled hair from the motorized brush roll.
Brush Roll Not Spinning	Hair or debris tangled in the brush roll.	Remove and clean the motorized brush roll as described in the Maintenance section.
Short Battery Runtime	Battery not fully charged or operating in Max mode.	Ensure battery is fully charged (approx. 4.5 hours). Runtime is shorter in Max mode (20 mins) compared to Standard mode (40 mins).

7. Specifications

Feature	Detail
Brand	UML0
Model Name	N3S (Cordless Vacuum Cleaner)
Special Feature	Low Noise, Lightweight, High-efficiency Filtration, Washable Filter, Pet Hair, Dog Hair, Bagless
Filter Type	HEPA Filter
Is Cordless?	Yes
Capacity	800 Milliliters
Charging Time	4.5 Hours
Max Runtime	40 Minutes (Standard Mode), 20 Minutes (Max Mode)
Recommended Uses	Carpet, Car, Hard Floor, Home, Household, Handheld, Stick, Upright
Form Factor	Stick
Item Weight	2.2 pounds (main motor)
Noise Level	65 Decibels
Battery Type	Lithium-Ion (12V, 2200 mAh)
Product Dimensions	17.1"L x 11.2"W x 7.1"H

8. Warranty and Support

For warranty information, technical support, or any questions regarding your UML0 N3S Cordless Vacuum Cleaner, please contact UML0 US directly through their official channels. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT8SV88X

More documents and user manuals: **https://manuals.plus/**