

[Manuals.plus](#) /

› [RALGEND](#) /

› RALGEND 8-Drawer Dresser (Model 4801DGWT) Instruction Manual

RALGEND 4801DGWT

RALGEND 8-Drawer Dresser (Model 4801DGWT) Instruction Manual

Brand: RALGEND | Model: 4801DGWT

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your RALGEND 8-Drawer Dresser, Model 4801DGWT. Please read this guide thoroughly before beginning assembly or use to ensure proper setup and safe operation. Keep this manual for future reference.




Image: The RALGEND 8-Drawer Dresser, Model 4801DGWT, in a white finish, positioned in a bedroom.

SAFETY INFORMATION


- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly.
- **Two-person assembly is recommended** for safety and ease.
- **Install the anti-tip device** as instructed to prevent accidental tipping, especially in households with children or pets.
- Do not exceed the weight limits for drawers or the top surface.
- Keep small parts away from children during assembly.

Anti-Tip Device

Offers extra stability, protecting children and pets.



✓ Ours



✗ Others



Image: A close-up diagram illustrating the installation of the anti-tip device, showing how it secures the dresser to the wall.

PACKAGE CONTENTS

Before starting assembly, verify that all components and hardware are included in your package. Refer to the included assembly manual for a complete list of parts. If any parts are missing or damaged, contact RALGEND customer support.

- Dresser panels (top, bottom, sides, back)
- Drawer panels (front, back, sides, bottom)
- Drawer slides (metal)
- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tip device kit
- Assembly tools (basic tools may be included, but an electric screwdriver is recommended for efficiency)

SETUP AND ASSEMBLY

Follow the step-by-step instructions provided in the separate assembly manual included with your product. The following general guidelines apply:

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the dresser components and your flooring.
2. **Identify Parts:** Lay out all parts and hardware, matching them against the parts list in your assembly manual. Each part is labeled.
3. **Assemble the Frame:** Begin by assembling the main frame of the dresser according to the manual's diagrams.
4. **Install Drawer Slides:** Attach the metal drawer slides to the dresser frame and drawer sides. Ensure they are aligned correctly for smooth operation.
5. **Assemble Drawers:** Construct each of the eight drawers. Pay close attention to the orientation of the drawer fronts, especially with the handleless design.
6. **Insert Drawers:** Carefully insert the assembled drawers into the dresser frame.
7. **Install Anti-Tip Device:** Securely attach the anti-tip device to the back of the dresser and to a wall stud. This is a critical safety step.



Image: Detail showing the thick desktop construction and the smooth metal slides for the drawers, indicating quality components.

OPERATING INSTRUCTIONS

Drawer Operation

The RALGEND 8-Drawer Dresser features a modern handleless design. To open a drawer, gently pull from the recessed groove located at the top edge of each drawer front. The smooth metal slides ensure easy opening and closing.



Image: A hand demonstrating how to open a drawer using the integrated recessed handle, highlighting the handleless design.

Storage Capacity

- **Drawers:** Each of the eight drawers provides ample space for categorized storage of clothing, accessories, or other items. Each drawer has a maximum weight capacity of approximately 22 lbs (10 kg).
- **Top Surface:** The spacious top surface is suitable for placing decorative items, books, or a television up to 55 inches. Ensure the weight of items placed on top does not exceed the dresser's stability limits.



Image: The dresser with several drawers partially open, showcasing the internal storage capacity for various items, and the spacious top surface with decorative elements.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your RALGEND dresser, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish. The dresser features an easy-to-clean finish.
- **Spills:** Promptly wipe up any spills to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Humidity:** Maintain a stable room temperature and humidity level to prevent warping or cracking of the wood materials.
- **Hardware:** Periodically check and tighten all assembly hardware to ensure stability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or loose hardware.	Check that drawer slides are installed correctly and all screws are tightened. Ensure no obstructions are in the slide path.
Drawers appear uneven.	Frame not level or drawer components not assembled squarely.	Verify the dresser is on a level surface. Recheck drawer assembly steps to ensure all panels are flush and square.
Dresser feels unstable.	Loose assembly hardware or anti-tip device not installed.	Tighten all screws and fasteners. Ensure the anti-tip device is securely anchored to the wall.
Missing parts or damaged components.	Shipping damage or packaging error.	Do not proceed with assembly. Contact RALGEND customer support immediately for replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	RALGEND
Model Number	4801DGWT
Color	White
Dimensions (D x W x H)	15.7" x 47.2" x 39.9"
Item Weight	111.3 Pounds (approx. 50.5 kg)
Number of Drawers	8
Material	Quality Particleboard and MDF
Drawer Weight Capacity	Approx. 22 lbs (10 kg) per drawer
Top Surface Capacity	Supports TVs up to 55 inches
Assembly Required	Yes

PRODUCT SIZE




Image: A detailed diagram illustrating the overall dimensions of the dresser (47.2" W x 15.7" D x 40" H) and the dimensions and weight capacity of a single drawer (22 lbs).

WARRANTY AND SUPPORT

For any questions, concerns, or to report missing/damaged parts, please contact RALGEND customer support. While specific warranty details are not provided in this manual, RALGEND is committed to customer satisfaction. Please refer to your purchase documentation or the RALGEND website for warranty information.

Contact Information: Please visit the official RALGEND store on Amazon for support and contact options: [RALGEND Amazon Store](#)