



[Manuals.plus](#) /

> [BODACIOUS](#) /

> BODACIOUS 3.5 Cubic Feet Chest Freezer Instruction Manual (Model BD-72Q-NEW)

## BODACIOUS BD-72Q-NEW

# BODACIOUS 3.5 Cubic Feet Chest Freezer Instruction Manual

Model: BD-72Q-NEW

## IMPORTANT SAFETY INFORMATION

---

Please read all instructions carefully before using your new freezer. Keep this manual for future reference.

- **Electrical Safety:** Ensure the freezer is connected to a grounded power outlet with the correct voltage (110 Volts). Do not use extension cords.
- **Placement:** Place the freezer on a firm, level surface. Allow adequate space around the unit for proper ventilation.
- **Flammable Materials:** Do not store explosive substances or flammable materials near the freezer.
- **Children:** Supervise children to ensure they do not play with the appliance. Old freezers should be disposed of safely to prevent child entrapment.
- **Cleaning and Maintenance:** Always unplug the freezer before cleaning or performing any maintenance.

## PRODUCT OVERVIEW

---

The BODACIOUS 3.5 Cubic Feet Chest Freezer (Model BD-72Q-NEW) is a compact, energy-efficient appliance designed for supplemental frozen storage in various settings such as apartments, RVs, homes, bars, dorms, and kitchens. It features a top-open door, adjustable temperature control, and quiet operation.

### Key Features

- **Compact and Portable Design:** Ideal for limited spaces.
- **Whisper-Quiet Operation:** Operates at approximately 38dB.
- **Energy Efficient:** Low daily energy consumption.
- **Frost Drainage Port:** Facilitates easy defrosting and cleaning.
- **Adjustable Temperature Control:** 6 settings for customized freezing.



*Image: The BODACIOUS 3.5 Cubic Feet Chest Freezer with its lid open, showing the interior storage space.*

## INSTALLATION AND SETUP

---

### Unpacking

1. Carefully remove all packaging materials, including any tape and protective film.
2. Inspect the freezer for any shipping damage. Report any damage to the retailer immediately.
3. Ensure all included components, such as the removable basket, are present.

### Placement

- Place the freezer on a strong, level floor that can support its weight when fully loaded.
- Allow at least 4 inches (10 cm) of space around the back and sides of the freezer for proper air circulation.
- Avoid placing the freezer in direct sunlight or near heat sources like stoves, radiators, or heaters, as this can affect cooling efficiency and increase energy consumption.
- The freezer is designed for indoor use.



*Image: The freezer positioned in a kitchen, illustrating its compact dimensions (21.06"W x 20.27"D x 24.4"H) and minimal space requirement.*

### Initial Power-On

1. After placing the freezer, wait at least 24 hours before plugging it in. This allows the refrigerant to settle.
2. Plug the freezer into a dedicated, grounded 110V electrical outlet.
3. The compressor will start, and the interior will begin to cool. Allow several hours for the freezer to reach its operating temperature before loading food.

## OPERATING INSTRUCTIONS

---

### Temperature Control

The freezer features a mechanical temperature control dial with 6 settings, ranging from 'Min' to 'Max'.

# 6 Temperature Controls for Colorful Taste

-0.4°F to 32°F for Flexible selection of freshness temperature for each ingredient



\*Quick freezing will lead to the freezer refrigeration to speed up, resulting in the freezer outside the temperature rises higher also compressor running noise, it is recommended that the use of 2-3H adjusted to 3-5 gear.

Image: Close-up of the temperature control dial with settings from 0 to Max, indicating different temperature ranges for various food types.

## Recommended Temperature Settings

Setting	Temperature Range	Recommended Use
0-1	-0.4°F to 32°F	Refrigeration (Fruits & Vegetables)
1-2		Refrigeration (Bulky Meat)
2-3		Frozen (Ice Cream)
3-5		Deep Freeze (Fish, Shrimp)

Setting	Temperature Range	Recommended Use
5-6 (Max)		Quick Freeze (Foods to be frozen)

Turn the dial to adjust the temperature. A higher number indicates a colder setting. For initial quick freezing, set to 'Max' and then adjust to a lower setting once items are frozen.

## Loading the Freezer

- Do not overload the freezer. Allow space for air circulation around items for efficient freezing.
- Use the removable basket for smaller, frequently accessed items to keep them organized.
- Ensure food is properly sealed to prevent freezer burn and maintain freshness.



*Image: An illustration showing the interior of the freezer with a removable basket for organizing small food items and a curved bottom design for increased storage capacity.*


## MAINTENANCE

---

### Defrosting

Defrost the freezer when the frost layer reaches approximately 0.2 inches (5 mm) thick. Excessive frost reduces efficiency.

1. Unplug the freezer from the power outlet.
2. Remove all food items and store them in another freezer or cooler.
3. Open the lid and place a towel or shallow pan under the frost drainage port located at the bottom of the freezer.
4. Remove the drain plug to allow water to escape.
5. Allow the frost to melt naturally. Do not use sharp objects or heating devices to speed up defrosting, as this can damage the freezer.
6. Once defrosted, clean the interior, dry thoroughly, replace the drain plug, and plug the freezer back in.



## Efficient Drainage Systems

Image: A close-up view of the efficient bottom drainage system, highlighting the frost drainage port for easy maintenance.

## Cleaning

- Clean the interior and exterior surfaces with a soft cloth and a mild detergent solution.
- Do not use abrasive cleaners, harsh chemicals, or scouring pads, as they can damage the finish.
- Wipe down the door gasket regularly to ensure a tight seal.

## TROUBLESHOOTING

Before contacting customer support, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Freezer does not operate	No power to the unit; Power cord unplugged; Circuit breaker tripped.	Check power outlet; Ensure cord is securely plugged in; Reset circuit breaker.
Freezer is not cold enough	Temperature control set too warm; Door not closed properly; Excessive frost buildup; Poor ventilation.	Adjust temperature to a colder setting; Ensure door is sealed; Defrost the freezer; Provide adequate space around the unit.
Excessive noise	Freezer is not level; Objects vibrating against the unit.	Adjust leveling feet; Ensure no objects are touching the freezer.
Water on floor	Drain plug is open or loose; Excessive humidity.	Ensure drain plug is securely closed; Reduce humidity in the room if possible.

## PRODUCT SPECIFICATIONS

Feature	Specification
Brand	BODACIOUS
Model Number	BD-72Q-NEW
Capacity	3.5 Cubic Feet
Product Dimensions (D x W x H)	20.27 x 21.06 x 24.4 inches
Item Weight	38.8 pounds

Feature	Specification
Installation Type	Freestanding, Countertop
Color	Black
Voltage	110 Volts
Wattage	58 watts
Door Hinges	Top
Door Material Type	Stainless Steel
Shelves	1 (removable basket)
Certification	ETL

## WARRANTY AND CUSTOMER SUPPORT

---

BODACIOUS products are manufactured with quality and reliability in mind. For specific warranty details, please refer to the warranty card included with your purchase or contact our customer support.

If you have any questions or require assistance with your BODACIOUS 3.5 Cubic Feet Chest Freezer, please do not hesitate to contact our professional support team. We are ready to answer your questions before or after your purchase.



*Image: An icon representing customer satisfaction, indicating BODACIOUS's commitment to service.*