Onerbl AC-DC Adapter for Polaroid Pogo CZA-05300B / DIXIETREE SJ-09030028

Onerbl AC-DC Adapter User Manual

For Polaroid Pogo Instant Digital Camera CZA-05300B and DIXIETREE SJ-09030028

Model: AC-DC Adapter for Polaroid Pogo CZA-05300B / DIXIETREE SJ-09030028

1. Introduction

Thank you for choosing the Onerbl AC-DC Adapter. This adapter is designed to provide reliable power for your compatible devices, specifically the Polaroid Pogo Instant Digital Camera CZA-05300B and DIXIETREE SJ-09030028 power supplies. It converts AC power from a wall outlet to the DC power required by your device, enabling operation or battery charging.

Please read this manual thoroughly before using the adapter to ensure safe and optimal performance. Keep this manual for future reference.

2. Safety Information

To prevent fire, electric shock, or injury, always follow these basic safety precautions:

- **Indoor Use Only:** This adapter is designed for indoor use. Do not expose it to rain, moisture, or extreme temperatures.
- **Avoid Water:** Do not use the adapter near water or in wet conditions. If it comes into contact with liquid, unplug it immediately.
- **Proper Voltage:** Ensure the wall outlet voltage matches the input voltage specified on the adapter (100-240V AC).
- **Correct Connection:** Only connect the adapter to devices for which it is specified. Using it with incompatible devices may cause damage.
- **Unplug When Not in Use:** Disconnect the adapter from the power outlet when not in use for extended periods or during electrical storms.
- **Handle with Care:** Do not drop, disassemble, or attempt to repair the adapter. Refer all servicing to qualified personnel.

- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it with cloths or other materials.

3. Product Overview

The Onerbl AC-DC Adapter is a reliable power solution featuring:

- **Compatibility:** Specifically designed for Polaroid Pogo Instant Digital Camera CZA-05300B and DIXIETREE SJ-09030028 9V3ACDM devices.
- **Safety Features:** Equipped with Over Voltage Protection, Over Heat Protection, and Short Circuit Protection to safeguard your devices.
- **Durable Design:** Manufactured with quality materials for long-lasting performance.

What's in the Box:

- 1 x Onerbl AC-DC Adapter



Figure 1: Front and side view of the Onerbl AC-DC Adapter. The adapter is black with a standard US two-prong plug on one side and a barrel connector cable extending from the other.

4. Setup Instructions

1. **Verify Compatibility:** Ensure your device is a Polaroid Pogo Instant Digital Camera CZA-05300B or

uses a DIXIETREE SJ-09030028 9V3ACDM power supply. Check your device's power input specifications.

2. **Connect to Device:** Carefully insert the barrel connector tip of the Onerbl AC-DC Adapter into the DC input port of your compatible device. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the adapter's two-prong plug into a standard 100-240V AC wall outlet.
4. Your device should now be receiving power or begin charging its battery.



Figure 2: The Onerbl AC-DC Adapter in use, plugged into a white power strip on a desk, demonstrating a typical setup.

5. Operating Instructions

Once connected, the Onerbl AC-DC Adapter will automatically supply power to your device or charge its battery. There are no additional controls on the adapter itself.

- **Powering On:** If your device has a power button, press it to turn on the device after connecting the adapter.
- **Charging:** If your device has a rechargeable battery, the adapter will initiate charging. Refer to your device's manual for charging indicators.
- **Disconnecting:** To disconnect, first unplug the adapter from the wall outlet, then gently remove the barrel connector from your device.

6. Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly winding the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cable for any signs of damage, such as frayed wires, cracks, or loose connections. If damage is found, discontinue use and replace the adapter.

7. Troubleshooting

If you encounter issues with your Onerbl AC-DC Adapter, refer to the following common solutions:

- **Device Not Powering On/Charging:**
  - Ensure the adapter is securely plugged into both the wall outlet and your device.
  - Test the wall outlet with another device to confirm it is functional.
  - Verify that the adapter is compatible with your specific device model (Polaroid Pogo CZA-05300B or DIXIETREE SJ-09030028).
  - Check the adapter's cable and connector for any visible damage.
- **Adapter Feels Hot:**
  - It is normal for adapters to feel warm during operation. However, if it becomes excessively hot to the touch, unplug it immediately.
  - Ensure there is adequate ventilation around the adapter and it is not covered.
  - Confirm the adapter is not overloaded by connecting it to an incompatible device.

If the issue persists after trying these steps, contact customer support.

8. Specifications




Figure 3: Dimensions of the Onerbl AC-DC Adapter, showing approximate measurements of 2.6 inches length, 1.6 inches width, and 1.2 inches depth for the main body, with a cable length of 76 inches.

Attribute	Detail
Brand	Onerbl
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Input Voltage	100-240 Volts (AC)
Output Voltage	9 Volts (DC)
Amperage	3 Amps
Wattage	27 Watts
Connector Type	Barrel Connector
Compatible Devices	Polaroid Pogo Instant Digital Camera CZA-05300B, DIXIETREE SJ-09030028 9V3ACDM
Special Feature	Short Circuit Protection, Over Voltage Protection, Over Heat Protection
Color	Black
Cable Length	Approximately 76 inches (193 cm)

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the Onerbl customer service department. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the manufacturer's website or contact your retailer.

© 2025 Onerbl. All rights reserved.