

[Manuals.plus](#) /

> [XINFUTE](#) /

> XINFUTE RC3602301/01BR Remote Control User Manual for Verizon Fios Cable TV Box IPSTB1200

XINFUTE RC3602301/01BR

XINFUTE RC3602301/01BR Remote Control User Manual

For Verizon Fios Cable TV Box IPSTB1200

1. INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your new XINFUTE RC3602301/01BR remote control. This remote is specifically designed to be compatible with the Verizon Fios Cable TV Box IPSTB1200, offering a direct replacement or secondary control option.

2. SETUP

2.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) and lift to remove it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2.1: Battery compartment with batteries installed.

2.2 Initial Use

This remote control operates using infrared (IR) technology. Once batteries are correctly installed, the remote is ready for use with your compatible Verizon Fios Cable TV Box IPSTB1200. No additional programming or pairing is typically required for standard IR functionality. Point the remote directly at the cable TV box for optimal performance.

3. OPERATING THE REMOTE CONTROL

The XINFUTE RC3602301/01BR remote control features a standard layout for easy navigation and control of your Verizon Fios Cable TV Box. Below is an overview of common button functions:



Figure 3.1: Front view of the remote control.

- **PWR (Power):** Turns the cable TV box on or off.
- **MENU:** Accesses the main menu of the cable TV box.
- **OK:** Confirms selections or opens information.
- **Navigation Arrows (Up, Down, Left, Right):** Navigates through menus and guides.
- **BACK:** Returns to the previous screen or menu.
- **EXIT:** Exits current menu or application.
- **INFO:** Displays program information.
- **Mute:** Mutes or unmutes the audio.
- **Play/Pause, Fast Forward, Rewind:** Controls media playback.
- **VOL +/-:** Adjusts the volume.
- **CH +/-:** Changes channels.
- **LAST:** Returns to the previously viewed channel.

For specific functions related to your Verizon Fios service, refer to your cable TV box's user guide.

4. MAINTENANCE

4.1 Cleaning

To clean your remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries, as this can lead to leakage or damage.

5. TROUBLESHOOTING

If you encounter issues with your remote control, try the following solutions:

- **Remote not responding:**
 - Ensure the remote is pointed directly at the Verizon Fios Cable TV Box.
 - Check if the batteries are installed correctly with the correct polarity.
 - Replace the batteries with fresh ones.
 - Ensure there are no obstructions between the remote and the cable TV box.
- **Limited range:**
 - The maximum effective range is approximately 5 meters (16 feet). Ensure you are within this range.
 - Replace batteries if they are low.
- **Specific buttons not working:**
 - Clean around the button to ensure no debris is preventing it from pressing correctly.
 - If only certain buttons fail, and others work, it might indicate a specific internal issue.

If problems persist after trying these steps, refer to the warranty information for support options.

6. SPECIFICATIONS

Brand	XINFUTE
Model Number	RC3602301/01BR
Compatible Model	IPSTB1200
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA batteries (not included)
Maximum Range	5 meters (approx. 16 feet)
Material	ABS Material
Item Weight	0.08 kg (approx. 2.8 oz)
Item Dimensions (L x W x H)	6"L x 3"W x 1"H (approx.)

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This product comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and

ensures the product functions as intended under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact the seller or manufacturer directly. All goods are inspected before shipment. If you are not satisfied with your purchase, you may contact us within 24 hours of receipt.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0DT98CDJC>

More documents and user manuals: <https://manuals.plus/>