Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC Power Cord B0DT99JDYM

Onerbl AC Power Cord Replacement for Rotai ETB001 Elliptical Machine

Model: AC Power Cord B0DT99JDYM | **Brand:** Onerbl

Introduction

This manual provides essential instructions for the safe and effective use of your Onerbl AC Power Cord Replacement. This power cord is designed to provide reliable power to compatible devices, specifically the Rotai ETB001 Under Desk Elliptical Machine. Please read this manual thoroughly before use and retain it for future reference.

Safety Information

- Ensure the power cord is compatible with your device's voltage and current requirements before connecting.
- Do not use the power cord if it is damaged, frayed, or has exposed wires.
- Keep the power cord away from water, excessive heat, and sharp objects.
- Do not attempt to modify or repair the power cord. Contact customer support if assistance is needed.
- Always unplug the power cord from the wall outlet before disconnecting it from the device.

Compatibility

This Onerbl AC Power Cord is specifically designed and tested for compatibility with the following devices:

- Rotai ETB001 Under Desk Elliptical Machine
- Ellipse for Seniors Leg Exerciser
- Fully Assembled Portable Electric Seated Pedal Exerciser

Using this power cord with incompatible devices may result in damage to the device or the power cord itself.

Setup and Installation

Follow these steps to properly connect your new AC power cord:

1. **Unpack the Power Cord:** Carefully remove the new Onerbl AC power cord from its packaging. Inspect it for any

visible damage.

2. **Disconnect Old Cord (if applicable):** If replacing an existing cord, ensure the elliptical machine is turned off and unplugged from the wall outlet. Gently disconnect the old power cord from both the elliptical machine and the wall outlet.
3. **Connect to Device:** Locate the power input port on your Rotai ETB001 Elliptical Machine. Insert the device-end connector of the new Onerbl power cord firmly into this port.
4. **Connect to Power Outlet:** Plug the wall-end connector of the power cord into a standard, grounded electrical wall outlet.
5. **Verify Connection:** Ensure both ends of the power cord are securely connected.



Image: The Onerbl AC Power Cord, showing both the device-end and wall-end connectors. This image illustrates the typical appearance of the power cord for connection.

Operation

Once the power cord is securely connected as described in the "Setup and Installation" section, your Rotai ETB001 Elliptical Machine is ready for use. Simply turn on your elliptical machine using its power switch. The power cord facilitates the electrical connection from the wall outlet to the device.

Maintenance

To ensure the longevity and safe operation of your Onerbl AC Power Cord, follow these maintenance guidelines:

- **Cleaning:** Wipe the cord with a dry, soft cloth. Do not use liquid cleaners or immerse the cord in water.
- **Storage:** When not in use, store the power cord in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cord sharply.
- **Inspection:** Periodically inspect the cord for any signs of wear, cuts, or damage. If damage is observed, discontinue use immediately and replace the cord.

Troubleshooting

If your device is not receiving power after connecting the Onerbl AC Power Cord, consider the following:

- **No Power:**
  - Ensure both ends of the power cord are fully and securely plugged into the device and the wall outlet.
  - Check if the wall outlet is functional by plugging in another known working appliance.
  - Verify that the elliptical machine's power switch is in the "ON" position.
  - Inspect the power cord for any visible damage. If damaged, replace it.
- **Intermittent Power:**
  - Ensure connections are tight and stable.
  - Avoid placing heavy objects on the cord or running it through high-traffic areas where it might be jostled.

If problems persist after following these steps, contact customer support.

Specifications

Product Name	Onerbl AC Power Cord Replacement
Model Number	B0DT99JDYM
Brand	Onerbl
Color	Black
Special Feature	Short Circuit Protection
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Compatibility	Rotai ETB001 Under Desk Elliptical Machine

Warranty and Support

Onerbl products are designed for reliability and performance. For information regarding warranty coverage, technical support, or replacement parts, please refer to the contact information provided with your purchase or visit the official Onerbl website. Please have your product model number (B0DT99JDYM) available when contacting support.
For further assistance, please contact your retailer or the manufacturer directly.

© 2024 Onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT99JDYM

More documents and user manuals: **https://manuals.plus/**