Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM FPSC3DRDS-NO

T4TREAM Fluted 3-Drawer Dresser (Model FPSC3DRDS-NO) Instruction Manual

Model: FPSC3DRDS-NO | Brand: T4TREAM

1. Introduction

This instruction manual provides comprehensive guidance for the assembly, operation, care, and maintenance of your T4TREAM Fluted 3-Drawer Dresser. Please read this manual thoroughly before beginning assembly or use to ensure proper installation and to maximize the lifespan of your furniture. Retain this manual for future reference.



Image 1: T4TREAM Fluted 3-Drawer Dresser, Natural Oak finish. This image displays the assembled dresser with its distinctive fluted panel design and faux marble top.

2. Safety Information

To prevent injury and damage to the product, adhere to the following safety guidelines:

- **Anti-Tip Kit:** Always install the included anti-tip kit to secure the dresser to a wall. This is crucial to prevent tipping, especially in households with children or pets.
- **Weight Distribution:** Distribute weight evenly across drawers and the top surface. Avoid placing excessively heavy items on the top or in a single drawer.
- **Drawer Use:** Open only one drawer at a time to maintain stability. Do not climb on or lean heavily on open drawers.
- **Assembly:** Assembly should ideally be performed by two adults to ensure safety and proper handling of components.
- **Placement:** Place the dresser on a level, stable surface. Uneven surfaces can compromise stability.



Image 2: Detail of the dresser's stable support legs and the reinforced base with steel support, indicating the attachment point for the anti-tip mechanism.

3. Package Contents

Before beginning assembly, verify that all components and hardware are present. Refer to the parts list provided in your packaging. If any items are missing or damaged, contact customer support immediately.

- Dresser panels (top, bottom, sides, back)
- Drawer components (fronts, sides, backs, bottoms)
- Hardware kit (screws, dowels, cam locks, drawer slides, handles)
- Anti-tip kit
- Assembly instructions manual
- Spare parts pack



Image 3: Various components of the dresser, including drawer parts and main panels, laid out before assembly.

4. Assembly Instructions

Assembly is designed to be straightforward. Each component is labeled with a serial number to assist in identification. A pack of spare parts is included in case of hardware loss. Two adults are recommended for assembly.

1. **Prepare Workspace:** Clear a spacious area and lay out all components on a soft, clean surface to prevent scratches.
2. **Assemble Frame:** Follow the numbered steps in the included assembly guide to construct the main dresser frame. Ensure all connections are secure but avoid overtightening screws.
3. **Install Drawer Slides:** Attach the drawer slides to the inner sides of the dresser frame and to the drawer boxes as indicated in the instructions. Ensure they are correctly oriented for smooth operation.
4. **Assemble Drawers:** Construct each drawer box, ensuring the left and right drawer sides are correctly positioned. Incorrect placement can prevent drawers from closing fully.

5. **Attach Handles:** Secure the metal handles to the front of each drawer.
6. **Insert Drawers:** Carefully slide the assembled drawers into the dresser frame. Test each drawer for smooth operation.
7. **Install Anti-Tip Kit:** Securely attach the anti-tip device to the back of the dresser and to a wall stud using the provided hardware. This step is essential for safety.



Image 4: Detailed view of the smooth-glide drawer slides, illustrating the mechanism for effortless drawer operation.

5. Operating Instructions

Your T4TREAM dresser is designed for efficient storage and display.

- **Drawer Functionality:** The three drawers feature smooth-glide mechanisms for easy opening and closing. Utilize them to store clothing, bedding, cosmetics, jewelry, or other personal items.
- **Top Surface:** The spacious faux marble top is suitable for displaying decorative items, framed photos, or a lamp. Avoid placing hot items directly on the surface without protection.

- **Organization:** To maintain neatness, consider using drawer organizers for smaller items.



Image 5: The dresser's faux marble top and an open drawer showcasing its storage capacity for various items.

6. Care and Maintenance

Proper care will preserve the appearance and functionality of your dresser.

- **Cleaning the Faux Marble Top:** The melamine veneer faux marble top is water-resistant and easy to clean. Wipe spills immediately with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Cleaning Wood Surfaces:** For the natural oak finish, dust regularly with a soft, dry cloth. For deeper cleaning, use a slightly damp cloth and dry immediately.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the wood finish.
- **Humidity Control:** Maintain a stable humidity level in the room to prevent wood from warping or cracking.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Tighten as necessary.

7. Troubleshooting

Refer to the following solutions for common issues:

- **Drawers do not close completely:**
  - Ensure the drawer slides are correctly installed and aligned on both the drawer box and the dresser frame.
  - Verify that the left and right drawer boxes are inserted into their corresponding sides.
  - Check for any obstructions within the drawer or on the slides.
- **Dresser feels unstable:**
  - Confirm the dresser is placed on a level surface. Adjust feet if necessary.
  - Ensure all assembly screws are tightened.
  - Verify the anti-tip kit is properly installed and secured to the wall.
- **Damaged or missing parts:**
  - Refer to the spare parts pack. If the required part is not available, contact T4TREAM customer support.

8. Specifications

Feature	Detail
Brand	T4TREAM
Model Name	FPSC3DRDS-NO
Product Dimensions (Overall)	16"D x 32"W x 32"H
Color	Natural Oak
Furniture Finish	Oak
Item Weight	80 Pounds
Room Type	Bedroom, Living Room, Hallway, Entryway, Home Office
Assembly Required	Yes
Material	FSC-Certified wood, MDF, P2 engineered wood, Melamine veneer (faux marble top)

Dimensions

- ☑ Overall: 32″ W × 16″ D × 32″ H
- ☑ Packaging Dimensions & Weight: 37″×20″×10″, 80 lbs




Image 6: Technical diagram illustrating the overall dimensions of the T4TREAM 3-Drawer Dresser.

9. Warranty and Customer Support

T4TREAM is committed to providing quality products. While specific warranty details are not included in this manual, please retain your proof of purchase. For any questions regarding warranty coverage, product issues, or assistance with assembly, please contact T4TREAM customer support.

Your package is designed with protective packaging to minimize transit damage. If you receive a damaged item or have any concerns, please reach out to us. We are available to assist you.

For further assistance, visit the official T4TREAM store on Amazon:T4TREAM Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT9BVCFX

More documents and user manuals: **https://manuals.plus/**