Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM FPSC7DRDS-DWT

T4TREAM Fluted 7-Drawer Dresser Instruction Manual

Model: FPSC7DRDS-DWT

1. Introduction

Thank you for choosing the T4TREAM Fluted 7-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The T4TREAM Fluted 7-Drawer Dresser in a bedroom setting.

2. Safety Information

WARNING: Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Always use tip-over restraint devices.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
- Place the heaviest items in the lowest drawers.
- This product is heavy. Assembly should be performed by two adults.

Ensure all parts are securely fastened before use. Do not stand on the dresser. Keep small parts and packaging materials away from children.

3. Parts List

Before beginning assembly, verify that all components and hardware are present. Each part is meticulously labeled with serial numbers for easy identification. A pack of spare parts is included in case of loss during assembly.

3.1. Main Panels

- Top Panel
- Side Panels (Left & Right)
- Bottom Panel
- Back Panel
- Drawer Fronts (7 units)
- Drawer Side Panels (14 units)
- Drawer Back Panels (7 units)
- Drawer Bottom Panels (7 units)
- Support Legs
- Central Support Beam

3.2. Hardware

- Screws, Dowels, Cam Locks, Cam Bolts
- Drawer Slides (14 pairs)
- Metal Handles (7 units)
- Anti-Tip Kit (Wall anchor, strap, screws)
- Allen Wrench (if required)

4. Setup and Assembly

Assembly is designed to be straightforward with clear, user-friendly instructions. Typically, two adults can easily put it together. We recommend using your own screwdriver with hex bits for efficiency, rather than just the provided Allen wrench.

4.1. Preparation

- Choose a clean, flat, and spacious area for assembly.
- Lay out all parts and hardware, matching them to the provided list.
- Required tools (not included): Phillips head screwdriver, hammer.

4.2. Assembly Steps (General Overview)

1. **Assemble the Main Frame:** Connect the side panels to the bottom and top panels using the designated hardware. Ensure all connections are secure.
2. **Install Support Legs:** Attach the support legs and the central support beam to the bottom of the dresser. The cabinet's stability is reinforced by the innovative inclusion of a steel support at the base.
3. **Install Drawer Slides:** Securely attach the drawer slides to the interior side panels of the dresser frame.
4. **Assemble Drawers:** For each of the 7 drawers, connect the side, back, and front panels. Insert the drawer bottom panel. Attach the remaining part of the drawer slides to the drawer sides.
5. **Attach Handles:** Secure the metal handles to the front of each drawer.
6. **Insert Drawers:** Carefully slide each assembled drawer into its corresponding slot in the dresser frame. Ensure they

slide smoothly.

7. **Install Anti-Tip Kit:** Attach the anti-tip device to the back of the dresser and secure it to a wall stud according to the instructions provided with the kit. This is crucial for safety.



Image 4.1: Detail of the stable support legs and steel-reinforced bottom for enhanced stability.

Your browser does not support the video tag.

Video 4.2: An overview of the T4TREAM Fluted 7-Drawer Dresser, showcasing its features and design.

5. Operating Instructions

The T4TREAM Fluted 7-Drawer Dresser is designed for efficient storage and ease of use.

5.1. Using the Drawers

- The dresser features 7 smooth-glide drawers for easy opening and closing.
- To open a drawer, gently pull the metal handle. To close, push the drawer firmly until it is flush with the dresser

frame.

- Avoid forcing drawers open or closed.
- Distribute weight evenly within the drawers. Place heavier items in lower drawers to maintain stability.



Image 5.1: The 7 spacious drawers offer efficient storage for various items.



Image 5.2: A drawer organized with cosmetics and small accessories.

6. Maintenance

Proper care will ensure the longevity and appearance of your T4TREAM dresser.

6.1. Cleaning

- The fluted panel and marble-look top are designed for water resistance and easy maintenance.
- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- Promptly clean up spills to prevent staining.

6.2. General Care

- Periodically check and tighten all hardware to ensure stability.
- Avoid exposing the dresser to direct sunlight or extreme temperature changes, which can cause warping or fading.
- Do not place hot items directly on the top surface without protection.



Image 6.1: The unique walnut veins top is wear-resistant and waterproof, making it easy to clean.

7. Troubleshooting

Here are solutions to common issues you might encounter:

Issue	Possible Cause	Solution
Drawers are stiff or sticking	New slides, uneven assembly, or minor alignment issues.	Regular use often improves smoothness. Ensure drawer slides are correctly installed and lubricated if necessary. Check that the drawer is inserted into the correct slot.
Drawer fronts do not align perfectly	Minor variations in assembly or manufacturing.	While often minor, re-check drawer assembly and ensure all screws are tightened evenly. Slight adjustments to drawer slides may help.

Issue	Possible Cause	Solution
Dresser feels unstable or wobbly	Loose hardware or improper installation of support legs/anti-tip kit.	Ensure all assembly hardware is fully tightened. Verify that the anti-tip kit is securely installed to a wall stud.

8. Specifications

Feature	Detail
Brand	T4TREAM
Model Name	FPSC7DRDS-DWT
Product Dimensions	16"D x 54"W x 32"H
Material	Engineered Wood
Finish Type	Stickers, Blister Molding and Melamine veneer
Number of Drawers	7
Color	Dark Walnut
Room Type	Bedroom, Living Room, Hallway, Entryway, Home Office
Assembly Required	Yes




Image 8.1: Detailed dimensions of the dresser.

9. Warranty and Support

T4TREAM is committed to providing quality products and customer satisfaction. We encourage you to buy with confidence.

If you have any questions, concerns, or require assistance with your T4TREAM Fluted 7-Drawer Dresser, please do not hesitate to reach out to our customer support team. We are here to assist you every step of the way.

For support, please visit the official T4TREAM store or contact customer service through your purchase platform.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT9C8WYB

More documents and user manuals: **https://manuals.plus/**