Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM FPSC8DRDS-NO

T4TREAM Fluted 8 Drawers Dresser Instruction Manual

Model: FPSC8DRDS-NO

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your T4TREAM Fluted 8 Drawers Dresser. Please read these instructions carefully before beginning assembly and retain this manual for future reference.



Image: The T4TREAM Fluted 8 Drawers Dresser in Natural Oak, featuring a faux marble top and gold handles, styled in a bedroom setting.

Product Specifications

Feature	Detail
Brand	T4TREAM
Model Name	FPSC8DRDS-NO
Product Dimensions	16"D x 54"W x 32"H
Color	Natural Oak
Furniture Finish	Oak
Room Type	Bedroom, Living Room, Hallway, Entryway, Home Office

Assembly Required	Yes
Material	Optimal MDF, P2 engineered wood, coated metal pull, melamine veneer (faux marble top)



Image: A diagram illustrating the overall dimensions of the dresser (54"W x 16"D x 32"H) and the internal dimensions of a single drawer (24"W x 12"D x 6"H).

Setup and Assembly

The T4TREAM Fluted 8 Drawers Dresser is designed for straightforward assembly. We recommend two adults for the assembly process to ensure stability and ease of handling.

Before You Begin:

- **Unpacking:** Carefully unpack all components and hardware. Verify that all parts are present by cross-referencing with the included parts list.
- **Inspect for Damage:** Although packaging is designed to protect the item, inspect all pieces for any damage. Contact customer support immediately if any parts are damaged or missing.
- **Tools:** Ensure you have the necessary tools for assembly (e.g., screwdriver).
- **Workspace:** Assemble the dresser on a clean, soft surface (like a carpet) to prevent scratches.

Assembly Steps:

1. Follow the detailed, user-friendly instructions provided in the separate assembly guide.
2. Each component is meticulously labeled with serial numbers to assist in identification.
3. A pack of spare hardware is included in case of loss during assembly.
4. Ensure all connections are secure before proceeding to the next step.
5. Install the anti-tipping hardware as directed to enhance stability and safety.



Image: A detailed view showing the construction elements of the dresser, including the gold-colored metal handles, the vertical fluted texture on the drawer fronts, and the sturdy, splayed wooden legs with a steel support bracket.

Operating Instructions

The T4TREAM Fluted 8 Drawers Dresser is designed for efficient and organized storage in various rooms.

Drawer Usage:

- The dresser features 8 smooth-glide drawers. To open, gently pull the metal handle. To close, push the drawer until it is fully seated.
- Utilize the spacious drawers to store clothing, bedding, cosmetics, jewelry, and other personal items.
- Avoid overloading drawers to ensure smooth operation and prevent damage to the drawer slides.

Top Surface Usage:

- The spacious faux marble tabletop can be used to display framed photos, decorative accents, lamps, or as a TV stand.
- Ensure items placed on the top surface do not exceed the dresser's weight capacity (refer to the full assembly guide for specific limits).



Image: An aerial view of the dresser with several drawers partially open, showcasing the depth and capacity for organizing items like folded clothes and accessories.

Maintenance

Proper care and maintenance will ensure the longevity and appearance of your T4TREAM dresser.

- **Cleaning the Faux Marble Top:** The melamine veneer faux marble top is water-resistant and easy to clean. Wipe spills immediately with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cleaning Wood Surfaces:** For the natural oak finish, use a soft, dry cloth for dusting. For deeper cleaning, a slightly damp cloth with mild soap can be used, followed by drying thoroughly.
- **Drawer Slides:** Periodically check drawer slides for smooth operation. If a drawer becomes stiff, a small amount of silicone lubricant can be applied to the slides.
- **Hardware:** Ensure all screws and fasteners remain tight. Periodically check and tighten as needed to maintain structural integrity.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.



Image: A detailed view of the faux marble top, emphasizing its texture and the ease of access to a drawer containing various personal care items.

Troubleshooting

This section addresses common issues you might encounter with your dresser.

- **Drawers are Stiff or Not Sliding Smoothly:**
  - Check if the drawer slides are properly aligned and free from obstructions.
  - Ensure the drawer is not overloaded.
  - Apply a small amount of silicone lubricant to the drawer slides if needed.
- **Drawers Do Not Align Evenly:**
  - Verify that all assembly screws are tightened appropriately. Uneven tightening can cause misalignment.
  - Re-check the assembly steps for the drawer runners and ensure they are installed correctly on both the drawer and the dresser frame.
- **Dresser Feels Unstable:**
  - Ensure the dresser is placed on a level surface.
  - Confirm that all structural fasteners are securely tightened.
  - Verify that the steel support at the base is correctly installed and providing adequate support.
  - Always use the provided anti-tipping hardware to secure the dresser to the wall.
- **Damaged or Missing Parts:**
  - If you received damaged parts or are missing components, please contact T4TREAM customer support for assistance.

Warranty and Support

T4TREAM is committed to providing quality products and customer satisfaction.

Customer Support:

If you have any questions, concerns, or require assistance with your T4TREAM Fluted 8 Drawers Dresser, please do not hesitate to reach out to our customer support team. We are here to assist you every step of the way.
Contact information can typically be found on the product packaging or the official T4TREAM website.

Protection Plans:

Extended protection plans may be available for your product. These plans offer additional coverage beyond the standard manufacturer's warranty. Please refer to your purchase documentation or the retailer's website for details on available protection plans.

- 2-Year Protection Plan: Available for purchase.
- 3-Year Protection Plan: Available for purchase.
- Complete Protect: Monthly plan covering eligible past and future purchases.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT9MHCQF

More documents and user manuals: **https://manuals.plus/**