

[Manuals.plus](#) /

> [Joydeco](#) /

> Joydeco Cordless Cellular Shades Instruction Manual (Model SC0030-WH-15-36)

## Joydeco SC0030-WH-15-36

# Joydeco Cordless Cellular Shades Instruction Manual

Model: SC0030-WH-15-36

## INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Joydeco Cordless Cellular Shades. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your product. Keep this manual for future reference.

## SAFETY INFORMATION


- This product features a cordless design for enhanced safety, making it suitable for homes with children and pets.
- Ensure the blinds are securely installed to prevent accidental detachment.
- Do not attempt to modify the product as this may compromise its safety and functionality.
- Keep packaging materials away from children to avoid choking hazards.

## PACKAGE CONTENTS

Verify that all components are present before beginning installation.

# HOW TO MEASURE?

For Inside Mount Only



Choose Width=Window Width (or Subtract 1/2" Max)

Choose Height  $\geq$  Inside Window Height

Window Depth  $\geq$  2.75"

## WHAT'S IN THE PACKAGE



Installation manual x1



cellular shades x1



Rubber pads x2 Rubber stopper x1  
Hex screwdriver x1 Handle x1

Figure 1: Package Contents and Measurement Guide


- Cellular Shades (1 unit)
- Installation Manual (1 unit)
- Rubber Pads (2 units)
- Rubber Stoppers (1 unit)
- Hex Screwdriver (1 unit)
- Handle (1 unit)

## MEASURING FOR INSTALLATION (INSIDE MOUNT ONLY)

Accurate measurements are crucial for proper fit and function. These blinds are designed for inside mount installations.

# HOW TO MEASURE?

For Inside Mount Only



Choose Width=Window Width (or Subtract 1/2" Max)

Choose Height  $\geq$  Inside Window Height

Window Depth  $\geq$  2.75"

## WHAT'S IN THE PACKAGE



Installation manual x1



cellular shades x1



Rubber pads x2 Rubber stopper x1  
Hex screwdriver x1 Handle x1

Figure 2: Detailed Measurement Instructions

1. **Window Width:** Measure the inside width of your window frame at three points (top, middle, bottom). Use the smallest measurement.
2. **Choose Blind Width:** The chosen cellular shade width should be less than or equal to your window's inside frame measurement, with a maximum reduction of 1/2 inch from the window size.
3. **Window Height:** Measure the inside height of your window frame.
4. **Choose Blind Height:** The chosen blind height should be greater than or equal to your window's inside height.
5. **Window Depth:** Ensure your window depth is at least 2.75 inches for proper installation.

## INSTALLATION (No Tools, No Drill)

Your Joydeco cellular shades are designed for easy, drill-free installation using a tension-mounted system.

# EASY INSTALLATION

ALL IT TAKES IS  
**3** STEPS AND  
**30** SECONDS



Attach rubber  
pads to both ends  
of the blinds

Press the tension  
mechanism and position  
the blinds in the frame

Tighten clockwise and  
cover with caps

*Figure 3: Easy 3-Step Installation Process*

1. **Attach Rubber Pads:** Attach the provided rubber pads to both ends of the blind's headrail. These pads help secure the blind within the window frame.
2. **Position and Engage Tension:** Press the tension mechanism on the headrail and carefully position the blinds inside your window frame. Ensure the blinds are level and centered.
3. **Tighten and Secure:** Using the hex screwdriver, tighten the tension mechanism by turning it clockwise until the blinds are firmly secured in place. Once tightened, cover the mechanism with the provided caps for a finished look.

For a visual guide on the tension mechanism, refer to the image below:



## EASY TO INSTALL WITHOUT DRILLING

- ✓ Spring device
- ✓ sturdy and durable
- ✓ express setup

## COMPLEX INSTALLATION AND DAMAGED WALLS

- ✗ Damage to walls
- ✗ Installation time
- ✗ Difficult to repair



Figure 4: Tension Mechanism Detail

## OPERATION

Your Joydeco cellular shades feature a cordless, top-down/bottom-up design for versatile light control and privacy.

# PROTECT PRIVACY




*Figure 5: Top-Down/Bottom-Up Operation Examples*

1. **Raising the Blinds (Bottom-Up):** Gently push the bottom rail upwards to raise the blinds. The cordless mechanism will hold the blinds at your desired height.
2. **Lowering the Blinds (Top-Down):** Gently pull the top rail downwards to lower the blinds from the top. This allows natural light to enter while maintaining privacy in the lower portion of the window.
3. **Adjusting Both Panels:** You can adjust both the top and bottom rails independently to achieve various light and privacy configurations, such as having the middle section of the window covered while the top and bottom are open.
4. **Using the Handle:** Attach the provided handle to the bottom rail for easier grip and adjustment, especially for taller windows.

## PRODUCT FEATURES

### Blackout and Thermal Insulation

# 100% BLACKOUT SHADES



*Figure 6: Blackout Capability*

These cellular shades are engineered to block approximately 99% of light, providing a true blackout effect. This feature is beneficial for bedrooms, nurseries, or any room where complete darkness is desired. The honeycomb cell structure, with built-in aluminum foil, also provides thermal insulation, helping to reduce heat transfer and improve energy efficiency.




Figure 7: Thermal and Acoustic Properties

### Noise Reduction

The unique honeycomb design of the cellular shades contributes to noise reduction, creating a quieter indoor environment by absorbing sound waves.

### Cordless Child Safety



## Cordless Child Safety

*Figure 8: Cordless Design for Child Safety*

The cordless operation eliminates dangling cords, enhancing safety for households with children and pets by removing potential strangulation hazards.

## Durable Construction



Figure 9: Construction Details

Constructed from premium polyester fabric and featuring aluminum top and bottom tracks, these shades are designed for durability and long-lasting performance.

## MAINTENANCE

Regular cleaning will help maintain the appearance and functionality of your cellular shades.

- **Dusting:** Use a feather duster, soft cloth, or vacuum cleaner with a brush attachment to gently remove dust from the shades.
- **Spot Cleaning:** For minor spots, use a damp cloth with mild soap and water. Blot the stained area gently; do not rub vigorously. Allow to air dry completely.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the fabric and color of the shades.

## TROUBLESHOOTING

| Problem                          | Possible Cause                                                   | Solution                                                                                                                                                                                                                                                                                                                      |
|----------------------------------|------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Blinds do not stay up or down.   | Tension mechanism needs adjustment.                              | Gently adjust the tension mechanism by pushing or pulling the rails until the desired resistance is achieved.                                                                                                                                                                                                                 |
| Blinds are not securely mounted. | Tension mechanism not tightened enough or incorrect measurement. | Ensure the tension mechanism is tightened clockwise using the hex screwdriver. Re-verify window measurements to ensure they fall within the recommended range for the blind size. If the window is too wide, the tension mount may not be sufficient, and alternative mounting (if available for your model) might be needed. |
| Blinds appear uneven.            | Improper initial positioning.                                    | Loosen the tension slightly, adjust the blinds to be level, and then re-tighten the tension mechanism.                                                                                                                                                                                                                        |

## SPECIFICATIONS

| Feature            | Detail                                                 |
|--------------------|--------------------------------------------------------|
| Brand              | Joydeco                                                |
| Model Number       | SC0030-WH-15-36                                        |
| Material           | Aluminum (Headrail), Polyester (Fabric)                |
| Color              | A - White                                              |
| Product Dimensions | 15"W x 36"H                                            |
| Opacity            | Blackout                                               |
| Operation Mode     | Manual, Cordless, Top-Down/Bottom-Up                   |
| Special Features   | Blackout, Cordless, Thermal Insulated, Noise Reduction |
| Item Weight        | 2.34 pounds                                            |

## WARRANTY AND SUPPORT

---

For warranty information or customer support, please refer to the contact details provided at the point of purchase or visit the official Joydeco website. Keep your purchase receipt as proof of purchase.