

LUXOAK CFT106

LUXOAK 97-inch Farmhouse TV Stand with 33-inch Electric Fireplace

Brand: LUXOAK | Model: CFT106

1. INTRODUCTION

Thank you for choosing the LUXOAK 97-inch Farmhouse TV Stand with Electric Fireplace. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before beginning assembly or use, and retain this manual for future reference.

2. SAFETY INFORMATION

Important Safety Guidelines:

- Ensure proper installation and use.
- Do not exceed the weight capacity of 300 lbs for the tabletop and 50 lbs for adjustable shelves.
- Use caution when adjusting flame and temperature settings on the electric fireplace.
- Follow all included instructions carefully to prevent injury or damage.
- The electric fireplace features overheat protection for safety.

3. PACKAGE CONTENTS

Your LUXOAK TV Stand and Electric Fireplace are shipped in two separate packages. Please ensure you have received both packages before beginning assembly, as they may arrive on different days.

3 Colors Available for Your Choice

TV Stand: 97"W x 14"D x 31.9"H

Fireplace: 33.3"W x 19"H

Color: White/Barnwood & Rustic Black & Light Grey

Assembly Required: YES

Weight Capacity: 300lbs

Material: Engineered Wood & Metal



This graphic explains the delivery process, showing that the product is shipped in two distinct packages. Customers should be aware that these packages might arrive on separate days.

Included Components:

- Electric Fireplace unit
- TV Stand components (engineered wood panels, glass doors)
- Hardware (screws, cam locks, dowels, etc.)
- Instruction manual

4. SETUP & ASSEMBLY

Assembly is required for both the TV cabinet and the electric fireplace. It is recommended that two adults participate in the assembly process to ensure stability and ease of handling. Please follow the detailed instructions and numbered parts provided in your package. Ensure you have adequate space for assembly.

33 inch Electric Fireplace



3D Log Embers



62°F-82°F



7 Flame Colors



Timer 30mins-6H



This diagram provides key measurements for the TV stand: 97 inches in width, 14 inches in depth, and 31.9 inches in height. It also indicates a maximum tabletop weight capacity of 300 pounds and 50 pounds for each adjustable shelf.

4.1 Tools Required

- Phillips head screwdriver
- Hammer (optional, for dowels)

4.2 Assembly Steps

1. Unpack all components and verify against the parts list.
2. Follow the step-by-step graphical instructions provided in the separate assembly manual.
3. Ensure all connections are secure before proceeding to the next step.
4. Install the electric fireplace unit into the designated central compartment.

5. OPERATING INSTRUCTIONS (ELECTRIC FIREPLACE)

The 33-inch electric fireplace provides warmth and ambiance. It can be controlled via the integrated control panel or

the included remote control.



This image details the electric fireplace's capabilities, including realistic 3D log embers, a temperature range of 62°F to 82°F, seven selectable flame colors, and a timer function from 30 minutes to 6 hours. A remote control is shown, indicating convenient operation.

5.1 Fireplace Features

- **3D Log Embers:** Realistic log-like design for visual appeal.
- **Temperature Settings:** Adjustable from 62°F to 82°F (17°C to 28°C).
- **Flame Colors:** Choose from 7 distinct flame colors.
- **Brightness Levels:** 5 adjustable brightness levels for the flames.
- **Timer Function:** Set the fireplace to operate for 30 minutes up to 6 hours.
- **Heating Area:** Capable of heating areas up to 400 sq. ft.
- **Overheat Protection:** Automatic shut-off feature for enhanced safety.

5.2 Controls

The fireplace can be operated using the control panel located on the unit or the provided remote control. Refer to the fireplace-specific manual for detailed button functions.

6. STORAGE AND DESIGN FEATURES

This TV stand is designed with ample storage and practical features to enhance your living space.



This image illustrates the storage options of the TV stand, featuring a central open cubby for media devices and two spacious side cabinets with glass doors. The cabinets contain adjustable shelves, demonstrating flexibility for organizing various items.

- **Large Tabletop:** Accommodates TVs up to 100 inches.
- **Open Cubby:** A central open compartment for media devices.
- **Glass-Door Cabinets:** Two large cabinets with glass doors on either side of the fireplace.
- **Adjustable Shelves:** Each cabinet includes two adjustable shelves, allowing customization of storage space to fit various items.
- **Magnetic Door Catches:** Ensures cabinet doors close securely and quietly.
- **Cable Management:** Integrated cutouts in the rear panel help organize and conceal cables for electronic devices.
- **Stable Base:** A robust 4-inch high base provides enhanced stability.



Magnetic Door Catch

Cable Management



Stable & Sturdy Base

This composite image highlights practical design elements: magnetic door catches ensure cabinet doors remain securely closed, a dedicated cutout in the rear panel facilitates organized cable management for electronic devices, and a robust 4-inch high base provides stability and support for the entire unit.

7. MAINTENANCE

To ensure the longevity and appearance of your TV stand and fireplace, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Fireplace Care:** Ensure the fireplace vents are clear of obstructions. Refer to the fireplace manual for specific cleaning instructions.
- **Inspections:** Periodically check all hardware connections to ensure they remain tight.

8. TROUBLESHOOTING

If you encounter any issues with your LUXOAK TV Stand or Electric Fireplace, consider the following general

troubleshooting steps:

- **Fireplace Not Turning On:** Check if the power cord is securely plugged into a working outlet. Ensure the main power switch on the fireplace unit is in the 'ON' position.
- **No Heat Output:** Verify that the temperature setting is above the current room temperature. Check if the heat function is enabled via the control panel or remote.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace sensor.
- **Loose Components:** If any part of the TV stand feels loose, re-tighten the corresponding hardware. Do not overtighten.
- **Missing Parts:** If you find any parts missing during assembly, contact customer support immediately.

9. SPECIFICATIONS

Feature	Detail
Brand	LUXOAK
Model Name	Framhouse Fireplace TV Stand
Model Number	CFT106
Color	Rustic Black
Product Dimensions (D x W x H)	14"D x 97"W x 31.9"H
Item Weight	160 Pounds
Weight Limit (Tabletop)	300 Pounds
Weight Limit (Adjustable Shelf)	50 Pounds
Material	Engineered Wood
Mounting Type	Floor Mount
Assembly Required	Yes
Fireplace Size	33 inches
Fireplace Temperature Range	62°F - 82°F
Fireplace Flame Colors	7
Fireplace Brightness Levels	5
Fireplace Timer	30 minutes - 6 hours

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact LUXOAK customer service. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DT9PZDH7>

More documents and user manuals: <https://manuals.plus/>