

PTHTECHUS LT49

PTHTECHUS Kids 4G Smart Watch LT49 Instruction Manual

Model: LT49

1. INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your PTHTECHUS Kids 4G Smart Watch, Model LT49. Please read this manual thoroughly before using the device and retain it for future reference. This smartwatch is designed for children aged 4-12 years old, offering communication, entertainment, and educational features.

Important Note: This Kids Smart Watch model LT49 does not require connection to a smartphone application. The GPS function and video call function are not available on this specific model.

2. PACKAGE CONTENTS

Upon opening your PTHTECHUS Kids 4G Smart Watch package, please verify that all the following items are included:

- PTHTECHUS Kids 4G Smart Watch (Model LT49)
- USB Charging Cable
- Instruction Manual
- 4G Smartwatch SIM Card (for initial activation)
- Additional Wristband (color may vary)
- Protective Sleeve (color may vary)
- Decorative Stickers

3. SETUP

3.1 Initial Charging

Before first use, fully charge the smartwatch. Connect the USB charging cable to the watch's charging port and plug the other end into a compatible USB power adapter (not included). The watch display will indicate charging status. A full charge typically takes 2-3 hours.

3.2 SIM Card Activation

The smartwatch includes a 4G SIM card for communication features. To activate the SIM card:

1. Insert the provided SIM card into a smartphone.
2. Visit the SpeedTalk Mobile website to activate the SIM card. Follow the on-screen instructions for activation.
3. Once activated, carefully insert the SIM card into the smartwatch's SIM card slot. Ensure the watch is powered off before inserting or removing the SIM card.

The included SIM card supports 30 minutes of calls and is valid for 7 days. Additional service plans may be required for continued use.



Figure 1: PTHTECHUS Kids 4G Smart Watch LT49. The watch features a vibrant display and a comfortable strap, shown alongside a SpeedTalk Mobile SIM card.

4. OPERATING THE SMART WATCH

4.1 Basic Navigation

The smartwatch features a 1.54-inch IPS HD touch screen. Swipe left or right to navigate through the different functions and tap to select an option. The side buttons are used for power on/off and the SOS function.



Figure 2: Key components of the smartwatch, including the HD camera, SIM card slot, and SOS button.

4.2 Two-Way Calling

With an activated 4G SIM card, the smartwatch supports two-way voice calls. You can make and receive calls directly on the watch. Ensure contact numbers are saved in the watch's phonebook.

Two-way calling



Figure 3: The two-way calling feature allows children to communicate with pre-approved contacts.

4.3 SOS Emergency Function

In an emergency, press and hold the SOS button for 3 seconds. The watch will automatically dial preset emergency phone numbers until one is answered. This feature is designed to provide quick contact with guardians.

4.4 Camera

The smartwatch includes a built-in camera. Navigate to the camera icon on the screen and tap to open. Tap again to take photos. Photos can be viewed in the gallery.



Figure 4: The watch features a camera for capturing moments and a music player for entertainment.

4.5 Music Player

The watch has a music player. Transfer MP3 audio files to the watch's internal storage via a computer. Navigate to the music player icon to select and play songs.

4.6 Learning Cards & Story Book

Engage with built-in learning cards to explore different animals, vegetables, and colors. The watch also includes 10 audio stories to aid in language development and listening skills.

Audio Books



Learning Cards




Figure 5: Educational features like audio books and interactive learning cards are included.

4.7 Puzzle Games

The smartwatch comes with 7 pre-installed puzzle games designed to develop independent thinking and logic skills. Navigate to the games section to choose and play.

4.8 Classroom Mode

Activate Classroom Mode to minimize distractions during school hours. In this mode, certain functions may be restricted, allowing children to focus on their studies without interruptions.

4.9 Habit Tracking

The watch includes features for habit tracking, helping children develop good routines and common sense life skills.

Habit Tracking



Figure 6: The habit tracking feature helps children establish and maintain daily routines.

4.10 Additional Tools

The smartwatch also includes practical tools such as an alarm clock, pedometer, and calculator.



Alarm Clock



Pedometer



Calculator




Figure 7: Useful tools like an alarm clock, pedometer, and calculator are integrated into the watch.

5. MAINTENANCE

5.1 Cleaning

Wipe the watch screen and strap with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the device.

5.2 Battery Care

To prolong battery life, avoid extreme temperatures and do not allow the battery to fully discharge frequently. Charge the watch regularly.

6. TROUBLESHOOTING

- **Watch not powering on:** Ensure the watch is fully charged. Press and hold the power button for several seconds.

- **SIM card not detected:** Ensure the SIM card is correctly inserted and has been activated with a service plan. Power cycle the watch after inserting the SIM.
- **Cannot make/receive calls:** Verify the SIM card is active and has sufficient credit/data. Check network signal strength. Ensure contact numbers are correctly saved in the watch's phonebook.
- **Screen unresponsive:** Try restarting the watch. If the issue persists, contact customer support.

7. SPECIFICATIONS

- **Model Number:** LT49
- **Brand:** PTHTECHUS
- **Display:** 1.54-inch IPS HD Touch Screen
- **Connectivity:** 4G Network (SIM card required)
- **Battery:** 700 mAh Nonstandard Battery (included)
- **Features:** Two-Way Calling, SOS, Camera, Music Player, Learning Cards, Puzzle Games, Classroom Mode, Habit Tracking, Alarm Clock, Pedometer, Calculator.
- **Note:** GPS and Video Call functions are not available on this model.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact PTHTECHUS customer service directly. Contact details can typically be found on the product packaging or the official PTHTECHUS website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question