

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Gabby's Dollhouse](#) /
- › [Gabby's Dollhouse: The Movie, Meow-Mazing Interactive Dollhouse, 7 Rooms, LCD Screen Eyes, Figures, Sound FX, Kids Toys for Girls & Boys Ages 3 and Up](#)

## Gabby's Dollhouse 6074577

# Gabby's Dollhouse: The Movie, Meow-Mazing Interactive Dollhouse Instruction Manual

Brand: Gabby's Dollhouse | Model: 6074577

## PRODUCT OVERVIEW

The Gabby's Meow-mazing Interactive Dollhouse brings the magic of Gabby's Dollhouse: The Movie to life. This interactive playset stands over 2 feet tall and offers full 360-degree play across 7 themed rooms and various play areas. It features animated LCD eyes that display digital expressions and includes over 60 interactive animations. Users can experience 6 play modes, including two interactive games (Cat of the Day & Find-it), along with music from the movie, sound effects, and animations activated by nose-pushes, Paw Bump Magic buttons, and elevator rides. Use the Cat-a-vator to travel between floors and the party room, then send dollhouse deliveries down the slide and unbox surprise dollhouse accessories. With Meow Tech, playtime gets more amazing by pairing with the Interactive Pandy Paws and Gabby's Interactive Ears (each sold separately) for enhanced play.



Image: The Gabby's Dollhouse Meow-Mazing Interactive Dollhouse in its packaging, showing the main dollhouse unit.

## WHAT'S INCLUDED

- 1 Dollhouse playset
- 1 Gabby figure
- 7 Furniture pieces
- 3 Accessories
- 2 Dollhouse Delivery boxes

## SETUP GUIDE

### 1. Battery Installation

The dollhouse requires 3 AA batteries for its interactive features. Locate the battery compartment, typically on the back or base of the dollhouse. Use a Phillips head screwdriver to open the compartment, insert the batteries according to the polarity indicators (+/-), and securely close the compartment.

## 2. Initial Assembly

Carefully remove all components from the packaging. The dollhouse may come partially folded or require minor assembly of external parts like the slide or specific room sections. Refer to the visual guides on the packaging or included quick-start sheet for specific assembly instructions. Ensure all pieces click securely into place.



Image: The dollhouse fully assembled and open, highlighting its 30-inch height.

## 3. Accessory Placement

Place the included Gabby figure, furniture pieces, and accessories within the dollhouse's 7 themed rooms as desired. The dollhouse is designed for 360-degree play, allowing access from multiple angles.

## FEATURES & OPERATION

### Interactive LCD Eyes & Sound FX

The dollhouse features animated LCD eyes that display various digital expressions. These, along with over 60 interactive


animations, music from the movie, and sound effects, are activated through different play actions. Pressing the dollhouse's nose or activating Paw Bump Magic buttons will trigger these interactive elements.



Image: A close-up of the dollhouse's cat-shaped head, showing the digital eye animations and indicating over 60 sounds.

### Play Modes & Games

Explore 6 distinct play modes, including two interactive games: "Cat of the Day" and "Find-it." These modes are designed to enhance imaginative play and engagement. Specific actions within the dollhouse will activate these modes.



## 6 PLAY MODES & 2 INTERACTIVE GAMES

Image: The dollhouse's cat head displaying various digital eye animations, illustrating the 6 play modes and 2 interactive games.

### Cat-a-vator & Paw Bump Magic

Utilize the working Cat-a-vator to transport figures between the different floors of the dollhouse. The "Paw Bump Magic" buttons, located strategically, trigger animations, lights, and sounds, adding to the interactive experience.



## ACTIVATE ANIMATIONS, LIGHTS & SOUNDS

Image: Demonstrates the "Paw Bump Magic" feature and the Cat-a-vator moving a figure between floors.

### Dollhouse Deliveries & Themed Rooms

Send dollhouse deliveries down the spiral slide, just like Gabby does in the show, and unbox surprise dollhouse accessories. The dollhouse features 7 distinct themed rooms, each designed for unique play scenarios.



## EXPLORE 7 THEMED ROOMS

Image: An interior view of the dollhouse, showcasing the various themed rooms and play areas.

### **Meow Tech Connectivity**

The dollhouse incorporates "Meow Tech" technology, allowing it to interact with other Gabby's Dollhouse products, such as the Interactive Pandy Paws and Gabby's Interactive Ears (each sold separately). This feature enables linked interactive play between multiple compatible toys.



\*EACH SOLD SEPARATELY

# CREATE MEOWGICAL MOVIE ADVENTURES

Image: A visual representation of the "Meow Tech" feature, showing how the dollhouse can connect with other interactive Gabby's Dollhouse toys.

## MAINTENANCE

### Cleaning

To clean the dollhouse, wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the plastic or electronic components. Ensure the dollhouse is completely dry before storing or resuming play.

### Battery Care

Always use fresh batteries of the specified type (3 AA). Do not mix old and new batteries, or different types of batteries. Remove batteries if the dollhouse will not be used for an extended period to prevent leakage and damage. Dispose of used batteries responsibly according to local regulations.

## TROUBLESHOOTING

---

### No Power or Intermittent Functionality

- Check that the batteries are inserted correctly with the correct polarity.
- Replace old batteries with new ones.
- Ensure the power switch (if present) is in the "ON" position.

### Interactive Features Not Responding

- Verify that the dollhouse has fresh batteries.
- Ensure that the activation points (e.g., nose, Paw Bump Magic buttons) are pressed firmly and correctly.
- If using Meow Tech, ensure compatible products are within range and properly activated.

### Parts Not Moving Smoothly (e.g., Cat-a-vator, Slide)

- Check for any obstructions or debris in the moving parts.
- Ensure the dollhouse is placed on a flat, stable surface.

## SPECIFICATIONS

---

Feature	Detail
Product Dimensions	5.19 x 26 x 17 inches
Item Weight	12 ounces
ASIN	B0DTBSDK7M
Item Model Number	6074577
Manufacturer Recommended Age	3 years and up
Batteries Required	3 AA batteries
Release Date	July 15, 2025
Manufacturer	Spin Master

## WARRANTY AND SUPPORT

---

This product is covered by the Spin Master Care Commitment. For detailed information regarding warranty terms, conditions, and customer support, please refer to the official Spin Master website or contact their customer service directly. Contact information can typically be found on the product packaging or the manufacturer's official website.

