

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Jocoevol](#) /

› [Jocoevol 55-inch Large Sideboard Buffet Storage Cabinet Instruction Manual](#)

### Jocoevol sidboard0509

# Jocoevol 55-inch Large Sideboard Buffet Storage Cabinet Instruction Manual

Model: sidboard0509

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Jocoevol 55-inch Large Sideboard Buffet Storage Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

## SAFETY INFORMATION

- Always follow the assembly instructions carefully to avoid injury.
- Do not overload the cabinet. The maximum weight capacity is 96 pounds (43.5 kg).
- Ensure all fasteners are securely tightened before use. Periodically check and retighten as necessary.
- Place the cabinet on a level surface to prevent tipping.
- Keep small parts and packaging materials away from children during assembly.

## SETUP AND ASSEMBLY

The Jocoevol Sideboard Buffet Storage Cabinet is designed for straightforward assembly. All necessary parts are numbered, and pre-drilled holes are provided for accurate installation. Clear installation instructions are included in the package.

### Required Tools (Not Included):

- Phillips head screwdriver
- Hammer (for dowels, if applicable)

### Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all numbered parts and hardware are present according to the included parts list.
2. **Identify Parts:** Match each component with its corresponding number in the instruction manual.

3. **Assemble Frame:** Follow the step-by-step diagrams in the provided manual to connect the main frame components using the designated screws and dowels. Ensure all connections are snug but do not overtighten until the entire frame is assembled.
4. **Install Back Panel:** Secure the back panel to the assembled frame using the small nails or screws provided.
5. **Attach Doors:** Mount the cabinet doors using the hinges. Adjust hinges as needed to ensure doors close properly and are aligned.
6. **Install Handles:** Attach the handles to the cabinet doors.
7. **Place Adjustable Shelves:** Insert the shelf pins into the desired height positions within the cabinet compartments. Place the adjustable shelves onto the pins.
8. **Final Check:** Once assembly is complete, gently move the cabinet to its desired location. Ensure it is stable and level.



*Image: Fully assembled Jocoevol Sideboard Cabinet.*

## Heavy-Duty Structure


Long-Lasting Strength  
and Stability

## Unique Modern Style

Features a Sleek  
Linear Design

## Durable Material

Water-Resistant &  
Scratch-Proof



*Image: Detail of cabinet construction and material features.*

## OPERATING INSTRUCTIONS

### Adjustable Shelves:

The cabinet features adjustable shelves to accommodate items of various heights. To adjust a shelf:

1. Empty the shelf of all contents.
2. Carefully lift the shelf and remove the four shelf pins from their current holes.
3. Reinsert the shelf pins into the desired set of holes at the new height. Ensure all four pins are at the same level.
4. Place the shelf back onto the pins, ensuring it is stable before placing items on it.

## 2-Tier Adjustable Shelf



*Image: Adjustable shelf mechanism.*

### **Storage Capacity:**

Utilize the spacious interior for storing crockery, cutlery, dishes, pots, utensils, or other household items. Distribute weight evenly across shelves and within the cabinet to maintain stability.

# Ample Storage Space



*Image: Interior view demonstrating ample storage and dimensions.*

## MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as needed to maintain structural integrity.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.
- **Heat and Moisture:** Keep the cabinet away from direct heat sources and excessive moisture to prevent warping or damage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Uneven floor; loose fasteners.	Ensure the cabinet is on a level surface. Check and tighten all assembly screws.
Doors do not align or close properly.	Hinges are not adjusted correctly; cabinet not level.	Adjust the door hinges according to the assembly manual. Ensure the cabinet is level.
Missing or damaged parts upon arrival.	Shipping damage; packaging error.	Contact Jocoevol customer support immediately with details of the missing or damaged parts. Refer to the "Support" section for contact information.
Adjustable shelf does not sit level.	Shelf pins are not inserted into corresponding holes.	Ensure all four shelf pins are inserted into holes at the same height level.

## SPECIFICATIONS

---

**Brand:** Jocoevol

**Model Name:** sidboard0509

**Product Dimensions:** 55"W x 15.7"D x 32.2"H (139.7 cm W x 39.88 cm D x 81.79 cm H)

**Color:** Green

**Material:** Engineered Wood

**Item Weight:** 96 Pounds (43.5 kg)

**Number of Shelves:** 2 (adjustable)

**Special Features:** Adjustable Shelf, Anti-Tipping, Heavy Duty

**Mounting Type:** Floor Mount

**Assembly Required:** Yes

**Recommended Uses:** Crockery, Cutlery, Dish, Pots, Utensils, General Storage

## SUPPORT

---

For any questions regarding assembly, missing parts, or product concerns, please contact Jocoevol customer support. We are committed to providing quality service and will respond within 24 hours.

Please refer to your purchase documentation or the Jocoevol brand store for specific contact methods (e.g., email address, phone number).

**Online Resources:** [Visit the Jocoevol Store on Amazon](#)