

[Manuals.plus](#) /

› [Keeppley](#) /

› Keeppley K20239 Moon Kitty Bonsai Building Blocks Instruction Manual

Keeppley K20239

Keeppley K20239 Moon Kitty Bonsai Building Blocks Instruction Manual

Model: K20239

PRODUCT OVERVIEW

The Keeppley K20239 Moon Kitty Bonsai Building Blocks set allows for the construction of a decorative bonsai-style model featuring a Moon Kitty character. This set is part of a popular building block series and includes succulent-themed elements. The patterns on the blocks are silk-screened, ensuring durability and preventing corners from lifting or discoloration over time.

This set contains between 100-200 pieces and typically takes approximately 30 minutes to assemble.

SAFETY INFORMATION

Warning: Not suitable for toddlers. This product contains small parts which may pose a choking hazard.

Always supervise children during assembly and play. Keep packaging materials away from children to prevent suffocation risks.

PARTS LIST

This building block set includes all necessary pieces for assembly, totaling between 100-200 individual blocks. An instruction manual is also included in the box.



Image Description: A fully assembled Keeppley K20239 Moon Kitty Bonsai Building Blocks set. The model features a white and pink Moon Kitty character standing on a white circular base with green leaf-like pieces. Behind the character, there's a pink and yellow bonsai-style structure resembling a plant with multiple layers of petals or leaves. A pink heart-shaped fan is attached to a stick on the right side of the structure. The base has pink accents and small pink feet. The overall color scheme is pastel pink, yellow, white, and green.

SETUP AND ASSEMBLY

1. **Unpack Components:** Carefully open the packaging and remove all building blocks and the instruction manual.
2. **Organize Pieces:** For easier assembly, sort the blocks by color or shape as indicated in the included manual.
3. **Follow Instructions:** Refer to the step-by-step visual instructions provided in the physical instruction manual. Each

step will guide you through connecting the blocks to form the Moon Kitty bonsai model.

- 4. **Estimated Assembly Time:** The assembly process typically takes approximately 30 minutes to complete.
- 5. **Secure Connections:** Ensure all blocks are firmly pressed together to create a stable and durable model.

If you encounter any difficulties, double-check the previous steps in the manual.

OPERATING (DISPLAY AND INTERACTION)

Once assembled, the Keeppley K20239 Moon Kitty Bonsai Building Blocks set is designed for display. It can be placed on a shelf, desk, or any flat surface as a decorative item.

- **Display:** Position the model in a visible location to enjoy its aesthetic appeal.
- **Interaction:** While primarily a display model, individual components are securely connected. Avoid excessive force or dropping the model to prevent disassembly.

MAINTENANCE

To keep your Moon Kitty Bonsai Building Blocks set in optimal condition, follow these simple maintenance guidelines:

- **Cleaning:** Dust the model regularly with a soft, dry cloth or a soft brush. For more stubborn dirt, a slightly damp cloth can be used, but ensure no water enters crevices.
- **Storage:** If disassembling for storage, keep all pieces in a sealed container to prevent loss and protect them from dust and damage.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause colors to fade over time.
- **Chemicals:** Do not use harsh chemicals or abrasive cleaners, as these can damage the plastic and silk-screened patterns.

TROUBLESHOOTING

Here are some common issues and solutions you might encounter during or after assembly:

- **Missing Pieces:**
Carefully check all packaging materials and the assembly area. If a piece is genuinely missing, contact Keeppley customer support with details of the missing part (refer to the part numbers in the included manual).
- **Difficulty Connecting Blocks:**
Ensure the blocks are correctly oriented according to the instructions. Apply firm, even pressure. If a block seems too tight, try wiggling it gently into place. Do not force blocks, as this can cause damage.
- **Model Instability:**
Review the assembly steps to ensure all connections are secure and no steps were missed. Loose connections can lead to an unstable model. Re-press any loose blocks.

SPECIFICATIONS

Brand	Keeppley
Model Number	K20239
Product Dimensions	6 x 6 x 2 inches

Number of Pieces	100-200
Manufacturer Recommended Age	6 years and up
ASIN	B0DTGRF5VY

WARRANTY AND SUPPORT

For information regarding product warranty, missing parts, or further assistance, please refer to the contact information provided in the original product packaging or visit the official Keeppley website.
Please retain your proof of purchase for any warranty claims.

© 2023 Keeppley. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question