

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MAHANCRIS](#) /

› [MAHANCRIS 68.5" Floating TV Stand with Power Outlet \(Model TVBK103E01\) - Instruction Manual](#)

MAHANCRIS TVBK103E01

MAHANCRIS 68.5" Floating TV Stand with Power Outlet

Model: TVBK103E01

INTRODUCTION

Thank you for choosing the MAHANCRIS Floating TV Stand. This wall-mounted entertainment center is designed to optimize your living space while providing functional storage and integrated power solutions. This manual provides essential information for safe assembly, operation, and maintenance of your new TV stand.



Image: The MAHANCRIS Floating TV Stand, Model TVBK103E01, installed beneath a wall-mounted television in a modern living room setting. The stand provides organized storage for media devices and decorative items.

SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Avoid placing overweight items on the product for extended periods.
- Children are prohibited from climbing on the product.
- Ensure the wall-mounting brackets are securely fastened to a suitable wall structure (e.g., wood studs, concrete) capable of supporting the stand's weight and any items placed on it.
- Do not overload the power outlets. Ensure total wattage of connected devices does not exceed the stand's specified limits.
- Keep all electrical connections dry and away from liquids.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Floating TV Stand Components (Engineered Wood Panels, Metal Frames)
- Integrated Power Outlet Unit (2 AC outlets, 2 USB ports, 4.9-foot power cord)
- Wall-Mounting Brackets (2 sets)
- Expansion Screws (6 pieces)
- Cable Management Grommet
- Assembly Hardware (screws, dowels, etc.)
- Assembly Tools (e.g., Allen wrench)
- Instruction Manual


SETUP AND INSTALLATION

The MAHANCRIS Floating TV Stand is designed for straightforward assembly. Follow the detailed instructions provided in the separate assembly guide included with your product. Ensure you have the necessary tools and assistance for safe installation.

1. **Unpack and Identify Parts:** Carefully unpack all components and compare them against the parts list in the assembly guide. Ensure all parts are present and undamaged.
2. **Assemble the Stand:** Follow the step-by-step instructions in the assembly guide to construct the main body of the TV stand. All parts are clearly labeled, and holes are precision-drilled for ease of assembly.
3. **Choose Mounting Location:** Select a suitable wall location. The stand must be mounted to a sturdy wall structure, such as wood studs or concrete, to ensure stability and safety. Use a stud finder to locate studs if mounting to drywall.
4. **Mark Drilling Points:** Use a level and the provided template (if applicable) to accurately mark the drilling points for the wall-mounting brackets.
5. **Install Wall Brackets:** Drill pilot holes and securely attach the two sets of wall-mounting brackets to the wall using the provided expansion screws. Ensure they are level and firmly anchored.
6. **Mount the TV Stand:** Carefully lift the assembled TV stand and align it with the installed wall brackets. Secure the stand to the brackets according to the assembly guide.
7. **Connect Power:** Plug the integrated power cord into a wall outlet.

User-Friendly Installation

With grommet holes and a level for accurate placement, it is easy to install this TV stand.



Organized Cables



Grommet Holes

Image: An exploded view diagram illustrating the assembly process of the floating TV stand, showing how the engineered wood panels and metal frames connect, and how the unit attaches to the wall.

Your browser does not support the video tag.

Video: An official MAHANCRIS video demonstrating the features and installation process of the Floating TV Stand with Charging Station. This video provides a visual guide to assembly and highlights key functionalities.

OPERATING INSTRUCTIONS

Your floating TV stand is designed for convenient use and organization of your media devices.

- Power Outlets:** The integrated power strip features two AC outlets (120V/12A) and two USB ports (5V/2A). Use these to power your TV, game consoles, DVD players, and charge mobile devices.
- Cable Management:** Utilize the plastic grommet on the top surface to neatly route cables from your TV and other devices, keeping them organized and out of sight.
- Storage:** The open shelves provide ample space for routers, set-top boxes, soundbars, remote controls, and

decorative items.



Image: A detailed view of the built-in power outlet on the TV stand, showing two standard AC outlets and two USB charging ports, ready for connecting electronic devices.

Organized Cables

Streamline your cables, no more tangled messes.



Image: A close-up of the circular cable management grommet on the TV stand's surface, designed to help organize and conceal power and data cables for a tidy appearance.

MAINTENANCE

To ensure the longevity and appearance of your MAHANCRIS Floating TV Stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Dusting:** Regularly dust the stand to prevent buildup.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Weight Distribution:** Distribute weight evenly across the shelves to prevent stress on any single point.

TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Stand feels unstable after mounting:**

- Ensure all wall-mounting brackets are securely fastened to wall studs or appropriate anchors.
- Verify that all assembly screws within the stand itself are tightened.
- Confirm the wall material is suitable for supporting the weight.

- **Power outlets are not working:**

- Check if the main power cord is securely plugged into a functional wall outlet.
- Ensure the total power draw of connected devices does not exceed the specified limits (120V/12A for AC, 5V/2A for USB).
- Test the wall outlet with another device to confirm it is supplying power.

- **Missing or damaged parts during assembly:**

- Review the package contents list carefully.
- Contact MAHANCRIS customer support for assistance with replacement parts.

SPECIFICATIONS

Model Number	TVBK103E01
Product Dimensions	68.5" L x 11.0" W x 8.9" H (174cm L x 28cm W x 22.6cm H)
Material	Engineered Wood, Metal
Item Weight	20.7 pounds
Weight Capacity	Up to 150 lb
Power Outlets	2 AC Outlets (120V/12A)
USB Ports	2 USB Ports (5V/2A)
Power Cord Length	4.9 feet
Color	Black



Image: A technical diagram illustrating the key dimensions (length, width, height) of the 68.5-inch floating TV stand and its maximum weight capacity of 150 lbs.

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact MAHANCRIS customer service. Refer to the contact information provided with your purchase or visit the official MAHANCRIS store online.

MAHANCRIS Official Store: [Visit Store](#)