

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Yaheetech](#) /

› [Yaheetech Heavy Duty Pop Up Canopy Tent, 10x20 Commercial Instant Shelter Tent for Wedding, Parties, Adjustable Outdoor Canopy with Wheeled Carry Bag, 6 Sandbags & 10 Stakes, Navy Blue Instruction Manual](#)

Yaheetech B0DTH8G4F3

Yaheetech Heavy Duty Pop Up Canopy Tent Instruction Manual

Model: B0DTH8G4F3

PRODUCT OVERVIEW

The Yaheetech Heavy Duty Pop Up Canopy Tent is designed for versatile outdoor use, providing reliable shelter and shade for various events. Its robust construction ensures durability, while its user-friendly design allows for quick and easy setup and transport. This 10x20 ft canopy is suitable for commercial events, parties, family gatherings, and more.



Image: The Yaheetech 10x20 Pop Up Canopy Tent, showcasing its full structure and navy blue color.

- **Weather-resistant Materials:** Crafted from durable polyester fabric with a water-resistant PU coating and UPF 50+ UV protective coating, supported by a sturdy steel frame.
- **Three Adjustable Heights:** Easily adjust the height to 10.3', 10.6', or 10.9' with simple button presses.
- **Reinforced Fabric & Frame:** Double-layered fabric at corners and ends for extra durability. Hammered paint-finished frame offers water and scratch resistance.
- **Designed for Commercial Use:** Provides 200 sq. ft. of shade, accommodating fifteen to twenty people, with a banner section for display.
- **Hassle-free Moving & Storing:** Folds into a compact roller bag (15.7" L × 10.2" W × 62" H) for easy transportation.

SETUP INSTRUCTIONS

Setting up your Yaheetech Pop Up Canopy Tent is a straightforward process. While it can be managed by one person, two people are recommended for optimal ease and speed.

1. **Unpack the Frame:** Remove the folded frame from the wheeled carry bag. Place the frame in the desired setup location.




Image: Close-up of the wheeled carry bag, highlighting its rubber handle, double zippers, and heavy-duty wheels for easy transport.

- 2. Partially Extend the Frame:** Gently pull the frame outwards from opposite corners until it is partially extended. Do not fully extend the legs yet.
- 3. Attach the Canopy Top:** Drape the canopy fabric over the partially extended frame. Ensure the corners of the canopy align with the frame's corners. Secure the canopy to the frame using the attached straps or Velcro fasteners.



Image: A visual guide showing the three quick and easy installation steps: unfolding the steel frame, fixing the canopy with straps, and adjusting the height.

- 4. Fully Extend the Frame:** From the center of the frame, push upwards until the frame locks into place. This will fully open the canopy.
- 5. Adjust Leg Height:** Press the buttons on each leg to extend them to your desired height (10.3', 10.6', or 10.9'). Ensure all legs are locked at the same height for stability.



WATERPROOF



VENTILATIVE



EASY TO
SET UP



UPF 50+

Image: Detailed dimensions of the 10x20 ft canopy tent when set up at various heights, and its compact folded size for storage.

6. **Secure the Canopy:** Use the provided stakes and guy lines to anchor the canopy to the ground. Fill the included sandbags with sand or other heavy material and attach them to the legs for additional stability, especially in windy conditions.



Image: A visual packing list showing the steel frame, wheeled carry bag, stakes, guy lines, and six sandbags included with the canopy tent.

OPERATING INSTRUCTIONS

The Yaheetech Pop Up Canopy Tent is designed for ease of use and adaptability to various outdoor scenarios.

Adjusting Height

To adjust the height of the canopy, simply press the push-button on each leg and slide the leg to the desired height setting. Ensure all four legs are adjusted to the same height for stability and proper canopy tension.

Utilizing Sidewalls (Optional)

The canopy comes with four detachable sidewalls. Three of these feature windows to allow light in, and one is a front panel with double-sided zippers for easy access. Attach the sidewalls using the Velcro fasteners along the top and sides of the frame. This allows you to customize the level of privacy and protection from elements.





Image: Examples of the canopy tent's versatility, showing its use in commercial situations, for backyard barbecues, and at parties or weddings.

Weather Considerations

The canopy features a UPF 50+ UV protective coating for sun protection and a water-resistant PU coating. However, it is important to note that while water-resistant, the tent may not be fully waterproof in heavy rain. Always secure the tent with guy lines, ground anchors, and sandbags when using in windy conditions. Disassemble and store the canopy during strong winds, heavy rain, or snow to prevent damage.



BLOCK 99% UV



WATERPROOF

It is not recommended to use it in
strong wind and heavy rain

Image: Visual representation of the canopy's ability to block 99% of UV rays and its water-resistant properties. Note: Not recommended for strong wind and heavy rain.

MAINTENANCE

- **Cleaning:** Clean the canopy fabric with mild soap and water. Do not use harsh detergents or abrasive cleaners. Allow the fabric to air dry completely before folding and storing to prevent mildew.
- **Frame Care:** Inspect the steel frame regularly for any signs of rust or damage. Clean any dirt or debris from the frame. The hammered paint finish provides good resistance to water and scratches.
- **Storage:** Always store the canopy in its wheeled carry bag in a dry, cool place away from direct sunlight when not in use. Ensure all components are clean and dry before storage.
- **Strap Tension:** Periodically check and tighten the straps on the canopy top to prevent water accumulation, especially after rain.

TROUBLESHOOTING

- **Difficulty Extending/Retracting Frame:** Ensure all locking mechanisms are disengaged before attempting to extend or retract the frame. Apply gentle, even pressure. If the frame is stiff, check for any obstructions or debris in the joints.

- Canopy Not Taut:** Verify that the frame is fully extended and locked. Ensure all leg heights are set equally. Adjust the canopy straps to pull the fabric taut.
- Water Accumulation on Top:** This can occur if the canopy is not sufficiently taut or if the straps are loose. Tighten the straps and ensure the frame is fully extended. In heavy rain, it is advisable to lower the canopy or tilt one side to allow water to run off.
- Instability in Wind:** Always use all provided stakes, guy lines, and sandbags. Ensure sandbags are filled with sufficient weight. For strong winds, it is recommended to take down the canopy.

SPECIFICATIONS

Feature	Detail
Brand	Yaheetech
Model	B0DTH8G4F3
Material	500D Oxford Cloth, PU Coating, Steel
Color	Navy Blue
Item Weight	89.84 Pounds
Ultraviolet Light Protection	UPF 50+
Frame Material	Alloy Steel
Water Resistance Level	Water Resistant
Product Dimensions (L x W x H)	226.77 x 114.57 x 131.5 inches
Assembly Required	Yes

WARRANTY AND SUPPORT

This product comes with a 30-day easy return policy. For any issues or inquiries, please contact Yaheetech customer support. Please note that replacement parts may not be available separately.

- Returns:** 30-day easy returns.
- Customer Support:** Refer to your purchase documentation or the Yaheetech official website for contact information.