

[manuals.plus](#) /

› [FUNYET](#) /

› [FUNYET FUNPAD 10-inch Android Tablet User Manual](#)

FUNYET FUNPAD

FUNYET FUNPAD 10-inch Android Tablet User Manual

Model: FUNPAD

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your FUNYET FUNPAD 10-inch Android Tablet. Please read it thoroughly before using the device and retain it for future reference.



Image: Front and back view of the FUNYET FUNPAD 10-inch Android Tablet, showcasing its sleek design and camera module.

2. WHAT'S IN THE Box

Upon unboxing your FUNYET FUNPAD, you should find the following items:

- FUNYET FUNPAD 10-inch Android Tablet
- Power Adapter
- USB Type-C Charging Cable
- Quick Start Guide



Image: The FUNYET FUNPAD tablet alongside its included power adapter and USB Type-C charging cable.

3. PRODUCT OVERVIEW

3.1 Physical Features

The FUNYET FUNPAD features a slim metal frame and a matte finish back, providing a comfortable grip. It is designed to be lightweight and portable.

- **Dimensions:** 9.48 x 6.28 x 0.3 inches
- **Weight:** 0.95 lbs (1.74 pounds as per specifications, using the lighter value from feature bullets for consistency with "lightweight")
- **Material:** Metal Shell




Image: Side profile of the tablet highlighting its 0.3-inch thickness and 0.95 lb weight, along with the Type-C port.

3.2 Key Components

- **Display:** 10-inch HD LCD screen (800x1280 resolution) with In-cell multi-touch technology.
- **Processor:** Spreadtrum T606 Octa-core processor (Dual-core A75 1.6GHz + Six-core A55 1.6GHz) and Mali-G57 GPU.
- **Memory & Storage:** 8GB RAM (4+4) and 128GB internal storage, expandable up to 1TB via Micro SD card.
- **Cameras:** 8MP rear autofocus camera and 2MP front camera.
- **Battery:** 6000mAh for extended usage.
- **Connectivity:** Dual-band Wi-Fi (2.4G/5G), Bluetooth 5.0, GPS/GLONASS/BDS.
- **Audio:** Dual 1W speakers.

Powerful T606 Octa-Core Processor



Playstores



Data Protection



Enhance User Experience



Image: Visual representation of the tablet's powerful T606 Octa-Core Processor and Android 15 operating system.

4. SETUP

4.1 Initial Charge

Before first use, fully charge your tablet using the provided power adapter and USB Type-C cable. The charging indicator will show the charging status.

4.2 Power On/Off

- To Power On:** Press and hold the Power button located on the side of the tablet until the screen lights up.
- To Power Off:** Press and hold the Power button, then select 'Power off' from the options that appear on the screen.
- To Restart:** Press and hold the Power button, then select 'Restart' from the options.

4.3 Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup wizard. Follow the on-screen prompts to:

1. Select your language.
2. Connect to a Wi-Fi network.
3. Sign in with your Google account (or create a new one).
4. Set up screen lock and other security features.
5. Review and accept terms and conditions.

5. OPERATING YOUR TABLET

5.1 Navigating the Interface


The FUNYET FUNPAD runs on Android. Navigate using touch gestures:

- **Tap:** Select items, open apps, or press buttons.
- **Swipe:** Scroll through pages, home screens, or menus.
- **Pinch:** Zoom in or out on photos and web pages.
- **Long Press:** Access contextual menus or move icons.


5.2 Display and Visuals

The 10-inch HD LCD screen provides vibrant visuals and good brightness for indoor use. The In-cell multi-touch technology ensures a responsive experience.

Wide View Large Screen



10.1" HD



Incell Multi
Touch



16:10 Aspect
Ratio



1280*800
HD



Face
Recognition




Image: Key display features of the FUNYET FUNPAD, including its 10.1-inch HD screen and In-cell multi-touch capability.

5.3 Performance and Storage

The Octa-core processor ensures smooth performance for multitasking, gaming, and streaming. With 128GB of internal storage, you have ample space for apps, photos, and videos. Storage can be expanded further using a Micro SD card.

Fast and Smooth, Large Capacity Storage



128GB
ROM



8(4+4)GB
RAM



1TB
Expansion




Image: Details on the tablet's storage capabilities, showing 128GB ROM, 8GB RAM, and up to 1TB expansion.

5.4 Cameras

Capture moments with the 8MP rear autofocus camera, suitable for quick scans or casual photos. The 2MP front camera is ideal for video calls and selfies.

5.5 Connectivity

The tablet supports dual-band Wi-Fi (2.4G/5G) for seamless internet access, Bluetooth 5.0 for connecting wireless accessories, and GPS/GLONASS/BDS for navigation.

5.6 Battery Life

The 6000mAh battery provides extended usage, allowing you to stay connected and entertained throughout the day without frequent recharging.

Video: An overview of the Funpad T606 Tablet, demonstrating its features and design. This video is provided by the seller, FUNYET TECH.

6. MAINTENANCE

- Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive cleaners or solvents.
- Storage:** Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures.
- Battery Care:** To prolong battery life, avoid fully discharging the tablet frequently. Charge it regularly, even if not in use for extended periods.
- Software Updates:** Keep your tablet's software updated to ensure optimal performance and security. Check for updates in the device settings.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Tablet won't turn on	Low battery; System crash	Charge the tablet for at least 30 minutes; Press and hold the Power button for 10-15 seconds to force restart.
Screen is unresponsive	Temporary software glitch	Restart the tablet; Perform a factory reset (backup data first).
Wi-Fi connection issues	Incorrect password; Router issue; Out of range	Verify Wi-Fi password; Restart router; Move closer to the Wi-Fi source.
Apps crashing or freezing	Insufficient RAM; App bug	Close background apps; Clear app cache/data; Reinstall the app; Update the app or system software.
Slow performance	Too many apps running; Low storage	Close unused apps; Free up storage space; Restart the tablet.

8. SPECIFICATIONS

Feature	Specification
Screen Size	10 Inches
Screen Resolution	800x1280 Pixels
Processor	1.6 GHz Octa-Core (Unisoc T606)
Graphics Coprocessor	Mali-G57
RAM	8GB
Storage	128GB (Expandable up to 1TB via Micro SD)
Operating System	Android
Rear Camera	8MP Autofocus
Front Camera	2MP Fixed Focus
Battery Capacity	6000mAh
Average Battery Life	8 Hours

Feature	Specification
Wireless Type	802.11ac (Dual-band 2.4G/5G)
Bluetooth	Bluetooth 5.0
GPS	GPS/GLONASS/BDS
Item Weight	1.74 pounds
Product Dimensions	9.48 x 6.28 x 0.3 inches
Color	Gray

9. WARRANTY & SUPPORT

FUNYET offers a **30-day free exchange** and a **1-year free repair** for all its products. If you have any questions or require assistance with your FUNYET FUNPAD, please feel free to contact FUNYET support. They aim to reply within 24 hours. For further support, visit the official FUNYET Store:[FUNYET Store on Amazon](#)