

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Sweecci](#) /

› [Sweecci 120"x118" Outdoor Dog Kennel Instruction Manual](#)

## Sweecci 120"x118"

# Sweecci Outdoor Dog Kennel Instruction Manual

MODEL: 120"x118"

## Introduction

---

This manual provides essential information for the safe assembly, operation, and maintenance of your Sweecci 120"x118" Outdoor Dog Kennel. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper installation and care will ensure the longevity and safety of your pet's enclosure.

## Safety Information

---

- Always ensure all connections are securely fastened before placing a pet inside the kennel.
- Regularly inspect the kennel for any signs of wear, damage, or loose components. Tighten or replace as necessary.
- Do not allow children to play unsupervised near or inside the kennel.
- Position the kennel on a level, stable surface to prevent tipping.
- Ensure adequate ventilation and protection from extreme weather conditions.
- This kennel is designed for pets. Do not use it for purposes other than its intended use.

## Package Contents

---

Verify that all components are present before starting assembly. If any parts are missing or damaged, contact customer support.

- Steel Frame Panels (various sizes for walls and doors)
- Roof Frame Components
- Weatherproof Roof Cover
- Connecting Hardware (bolts, nuts, washers)
- Ground Stakes (12 included)
- Feeding Door Mechanism
- Double Lock System Components
- Assembly Tools (e.g., wrench)
- Instruction Manual

## Setup and Assembly

Follow these steps for proper assembly. It is recommended to have at least two people for assembly.

1. **Site Preparation:** Choose a level, clear area for the kennel. Ensure the chosen location can accommodate the kennel's dimensions of approximately 120 inches (L) x 118 inches (W) x 72 inches (H).



Image: Kennel dimensions for site planning.

2. **Assemble Wall Panels:** Connect the individual steel mesh panels using the provided hardware. Ensure the reinforced joints are properly aligned and secured for maximum stability.



Image: Detail of reinforced panel joints.

3. **Install Door Panels:** Integrate the door panels, including the feeding door and main access door, into the wall structure. Ensure the hinges operate smoothly and the locking mechanisms are correctly installed.

# SMART ACCESS DESIGN



Dual Rotating  
Feeding Doors

180°

Convenient feeding  
access with dual swivel doors.

180°  
Swivel Lock

180°

Effortless access with  
a secure, rotating lock.

Image: Smart access design with feeding door and swivel lock.

4. **Assemble Roof Frame:** Construct the heavy-duty top frame for the roof. This frame provides the structural support for the weatherproof cover.




Image: Heavy-duty top frame for roof support.

5. **Attach Roof Cover:** Drape the weatherproof and UV-resistant roof cover over the assembled roof frame. Secure it using the integrated cord locks and ensure it is taut to allow for proper water drainage.



## ALL-WEATHER PROTECTION DESIGN



Durable 250D Fabric

Secure Cord Lock

Drainage Holes

Image: All-weather roof protection features.

6. **Secure with Ground Stakes:** Use the provided ground stakes to firmly anchor the kennel to the ground. This enhances stability, especially in windy conditions.

# SECURE GROUND STAKES INCLUDED



Keeps the kennel firmly in place, even in windy conditions.



Provides extrastability for outdoor use



12 ground spikes included

Image: Ground stakes for enhanced stability.

7. **Final Inspection:** Double-check all bolts, nuts, and connections to ensure they are tight. Confirm that all doors open and close smoothly and that the locking mechanisms function correctly.

The modular structure is designed for quick assembly and disassembly, as shown in the overview.



Image: Quick assembly overview.

## Operating Instructions

- **Main Access Door:** To open the main door, disengage the double lock system. The door features a 180-degree swivel lock for secure closure. Always ensure the door is securely locked when your pet is inside.

# SMART ACCESS DESIGN



Dual Rotating  
Feeding Doors

Convenient feeding  
access with dual swivel doors.

180°  
Swivel Lock

Effortless access with  
a secure, rotating lock.

Image: Detail of the main door's swivel lock.

- **Feeding Door:** The kennel includes a built-in dual rotating feeding door. This allows you to feed your pet without fully opening the main gate, enhancing security and convenience. Simply unlatch and rotate the smaller door to access the feeding area.

# SMART ACCESS DESIGN



Dual Rotating Feeding Doors

Convenient feeding access with dual swivel doors.

180° Swivel Lock

Effortless access with a secure, rotating lock.

Image: Detail of the dual rotating feeding door.

- **Security:** The double-lock system on the main door provides enhanced security, ensuring your pet remains safely contained. Always engage both locks when the kennel is in use.

## Maintenance

- **Cleaning:** The kennel features easy-clean materials. Regularly clean the interior and exterior with mild soap and water. Rinse thoroughly and allow to air dry.
- **Roof Care:** Periodically check the weatherproof roof cover for any tears or damage. Ensure the cord locks are secure to maintain proper tension and drainage.
- **Frame Inspection:** Inspect the steel frame for rust or corrosion. While the frame has a rust-resistant coating, prolonged exposure to harsh elements may require touch-ups.
- **Hardware Check:** Annually, or more frequently if needed, check all bolts, nuts, and connections for tightness. Tighten any loose hardware to maintain structural integrity.
- **Ground Stakes:** Ensure ground stakes remain firmly in place, especially after heavy winds or rain. Re-secure if necessary.

## Troubleshooting

- **Kennel feels unstable:** Ensure all connecting hardware is fully tightened. Verify that the kennel is placed on a level surface. Re-insert and secure all ground stakes.
- **Roof cover sags or collects water:** Check the tension of the roof cover cords. Adjust the cord locks to ensure the cover is taut and properly sloped for drainage.
- **Door not closing properly:** Inspect hinges for damage or obstruction. Ensure the frame is square and level. Check the locking mechanism for any debris or misalignment.
- **Rust spots appearing:** Clean the affected area and apply a rust-inhibiting paint or coating to prevent further spread.

## Specifications

Feature	Detail
Brand	Sweecci
Model	120"x118"
Product Dimensions (L x W x H)	120" x 118" x 72"
Material	Steel (frame), Nylon (roof cover)
Color	Grey
Special Features	Durable, Easy to Clean, Weather Resistant, Double Lock, Feeding Door
Target Audience	Dogs (Large Breed Recommendation)
Specific Uses	Outdoor

## Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact Sweecci customer service. Keep your purchase receipt as proof of purchase.