

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [jodiyece](#) /

› [jodiyece AI Sync Male Masturbator User Manual BLACK-139-A](#)

jodiyece BLACK-139-A

jodiyece AI Sync Male Masturbator User Manual BLACK-139-A

Model: BLACK-139-A

INTRODUCTION

Thank you for choosing the jodiyece AI Sync Male Masturbator. This device is designed to provide a comprehensive experience with multiple modes and intelligent features. This manual provides detailed instructions for safe and effective use, maintenance, and troubleshooting of your device.

SAFETY INFORMATION

- Read all instructions before first use.
- Clean the device thoroughly before and after each use with mild soap and water. Ensure it is completely dry before storage.
- Use only water-based lubricants with this product. Oil-based lubricants can damage the silicone material.
- Do not use if the device or any component appears damaged.
- Keep out of reach of children.
- If you experience any discomfort or irritation, discontinue use immediately.
- The device is waterproof; however, ensure the charging port is completely dry before charging.

PACKAGE CONTENTS



The package includes the following items:

- jodiyece AI Sync Male Masturbator x 1
- USB Charging Cable x 1
- User Manual x 1

PRODUCT OVERVIEW

The jodiyece AI Sync Male Masturbator features a sleek design with an intuitive control panel and a transparent inner sleeve. It combines multiple stimulation modes for a varied experience.



Figure 1: Main Product View

Components:

- **Control Panel:** Located at the top, featuring an LCD display and control buttons.
- **Inner Sleeve:** Made of soft, transparent silicone with internal textures for varied sensations.
- **Outer Casing:** Durable and waterproof housing.
- **Charging Port:** USB charging port (located on the device, ensure dry before charging).

Control Panel:



Figure 2: Control Panel and LCD Display

The LCD display shows the current mode and intensity level. Buttons allow for power control, mode selection, and intensity adjustment.

SETUP

Initial Charging:

1. Before first use, fully charge the device. Connect the USB charging cable to the device's charging port and a compatible USB power source.
2. The LCD display will indicate charging status. A full charge typically takes approximately 120 minutes.
3. Ensure the charging port is dry before connecting the cable.

Preparation for Use:

1. Clean the inner sleeve as described in the "Maintenance & Cleaning" section.

2. Apply a generous amount of water-based lubricant to the entrance of the inner sleeve and to yourself for optimal comfort and sensation.

OPERATING INSTRUCTIONS

Basic Operation:

1. **Power On/Off:** Press and hold the power button on the control panel to turn the device on or off. The LCD display will illuminate.
2. **Mode Selection:** Use the mode buttons to cycle through the various functions:
 - **Thrusting:** 7 modes of in-and-out motion.
 - **Rotating:** 7 modes of internal rotation.
 - **Vibrating:** 7 modes of vibration.
 - **Sucking:** 7 modes of vacuum suction.
 - **Licking:** 7 modes mimicking licking sensations.
3. **Intensity Adjustment:** Once a mode is selected, use the intensity buttons (usually +/- or up/down arrows) to adjust the strength or speed of the chosen mode.

7 Powerful Thrusting & Rotating & Vibrating Modes



Dual motors
for stronger feeling

Figure 3: Thrusting and Rotating Modes



Figure 4: Sucking and Licking Modes

Vacuum Pump Function:

The device includes a vacuum pump feature designed to create suction around the inner sleeve, enhancing sensations. Activate this mode via the control panel and adjust intensity as desired. This function can also be used for training purposes.



Figure 5: Vacuum Pump Operation

Water Massage (Waterproof Feature):

The device is fully waterproof, allowing for use in water for a unique water massage experience. It can be used with warm or cold water to vary sensations. Ensure the charging port cover is securely closed before immersion.



Figure 6: Waterproof Feature and Water Massage

AI SYNC & APP CONTROL

The jodiyece AI Sync Male Masturbator can be connected to a smartphone application (JoyHub App) for enhanced control and interactive features.

AI Sync Video Integration:

The AI Sync feature allows the device's movements to synchronize with on-screen video content when used with the JoyHub App. This creates a dynamic and immersive experience where the physical sensations align with visual stimuli.

AI Ultra Interactive AI Lover*Video Sync*APP Control

Interactive-AI Sync-APP Control



Figure 7: AI Sync Video Integration

JoyHub App Features:

- **Remote Control:** Control all device functions and modes directly from your smartphone.
- **Custom Programs:** Create and save personalized programs with unique combinations of thrusting, rotating, vibrating, sucking, and licking modes.
- **AI Companion:** Engage in real-time voice/text chat with an AI companion that learns your preferences.
- **Community & Sharing:** Explore content and interact with other users within the app (optional).



Figure 8: JoyHub App Interface

MAINTENANCE & CLEANING

Proper cleaning and maintenance will ensure the longevity and hygiene of your device.

1. **Disassembly:** The inner sleeve is detachable for easy cleaning. Gently twist and pull to separate the inner sleeve from the main body.
2. **Cleaning:** Wash the inner sleeve and the interior of the main body with warm water and mild, antibacterial soap. Rinse thoroughly to remove all soap residue.
3. **Drying:** Allow all components to air dry completely before reassembly and storage. You may use a soft, lint-free cloth to pat dry.
4. **Reassembly:** Align the inner sleeve with the main body and gently push and twist until it is securely in place.
5. **Storage:** Store the device in a clean, dry place away from direct sunlight and extreme temperatures.



Figure 9: Cleaning and Disassembly Steps

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or no charge.	Charge the device fully using the provided USB cable.
Device not responding to controls.	Device may be in standby mode or battery is low.	Press the power button to wake up. If unresponsive, charge the device.
App connection issues.	Bluetooth not enabled, app not updated, or device not paired.	Ensure Bluetooth is on. Update the JoyHub App. Follow in-app instructions to pair the device.
Weak or inconsistent sensations.	Insufficient lubricant, low battery, or inner sleeve not properly installed.	Apply more water-based lubricant. Charge the device. Reassemble the inner sleeve correctly.
Unusual noise during operation.	Inner sleeve misalignment or foreign object.	Disassemble and reassemble the inner sleeve. Inspect for any obstructions. If noise persists, contact support.

SPECIFICATIONS

- **Model Number:** BLACK-139-A
- **Material:** Silicone
- **Color:** Blackred
- **Water Resistance Level:** Waterproof
- **Package Dimensions:** 12.24 x 4.53 x 4.13 inches
- **Item Weight:** 2.2 Pounds
- **Charging Time:** Approximately 120 minutes
- **Working Time:** Approximately 60 minutes (varies by mode and intensity)
- **Noise Level:** <50dB



Figure 10: Advanced Technology Features

WARRANTY & SUPPORT

For any questions, concerns, or technical support, please contact jodyece customer service.

Customer Service:

- **Phone Support:** +1 (888) 867-5827 (as indicated in promotional material, verify for official support)
- **Online Support:** Visit the jodyece store on Amazon and use the "Ask a question" feature.



Figure 11: 7*24H Customer Service



Figure 12: How to Contact Us (Step 1)

Please have your model number (BLACK-139-A) and purchase information ready when contacting support.