

[Manuals.plus](#) /

› [ELEMARA](#) /

› ELEMARA 2 Seater Electric 4 Wheeler S615 User Manual

ELEMARA S615

ELEMARA 2 Seater Electric 4 Wheeler S615 User Manual

Model: S615

1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your ELEMARA 2 Seater Electric 4 Wheeler, Model S615. Please read this manual thoroughly before first use and retain it for future reference. Ensure all users understand the safety warnings and operating procedures.



Figure 1: The ELEMARA 2 Seater Electric 4 Wheeler S615.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not suitable for children under 37 months. The product contains small parts; keep children away during assembly.

- Always supervise children when operating the vehicle.
- Ensure the vehicle is used on flat, dry surfaces away from traffic, pools, or steep inclines.
- Only use the charger and battery supplied by the manufacturer.
- Do not modify the electrical system or any components of the vehicle.
- Ensure all fasteners are securely tightened before each use.
- Recommended age: 3 years and up.
- Maximum weight capacity: 130 lbs.

3. WHAT'S IN THE BOX

Carefully unpack all components and verify that all items are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- ELEMARA 2 Seater Kids ATV (Main Unit) x 1
- 12V Battery x 1 (pre-installed or separate)
- Charger x 1
- Assembly Hardware (screws, nuts, washers)
- Instruction Manual x 1

4. ASSEMBLY INSTRUCTIONS

Follow these steps for proper assembly. It is recommended that two adults perform the assembly.

1. **Wheel Installation:** Attach the wheels to the axles, ensuring all washers and locking pins are securely in place. Refer to the diagram for correct orientation.
2. **Steering Wheel Attachment:** Connect the steering column to the vehicle body and secure the steering wheel. Ensure the steering mechanism operates smoothly.
3. **Seat Installation:** Place the seat onto the designated area and secure it with the provided fasteners.
4. **Battery Connection:** If the battery is not pre-connected, locate the battery compartment and connect the positive (red) and negative (black) terminals. Ensure connections are tight.
5. **Final Checks:** Before first use, inspect all connections, fasteners, and electrical components to ensure they are secure and functioning correctly.

5. OPERATING INSTRUCTIONS

Familiarize yourself with the controls before operating the vehicle.




Figure 2: Detailed view of the control board, gas pedal, LED headlight, and double pedal.

5.1. Controls Overview

- **Power Button:** Turns the vehicle on/off.
- **Speed Control:** Adjusts between high and low speed settings.
- **Forward/Backward Switch:** Selects driving direction.
- **Gas Pedal:** Press to accelerate. Release to brake.
- **Battery Display:** Indicates remaining battery charge.
- **LED Headlights:** Provide illumination.
- **Music/Megaphone:** Integrated sound features.

5.2. First Ride

1. Ensure the battery is fully charged.
2. Turn on the vehicle using the Power Button.
3. Select the desired speed (low for beginners) and direction (forward).
4. Gently press the gas pedal to start moving. Release the pedal to stop.
5. Always ensure the child is wearing appropriate safety gear, including a helmet.

5.3. Terrain Suitability

The ELEMARA S615 is designed for various terrains, including concrete, gravel, grass, and shallow sand ground, thanks to its 12-inch large treaded wheels.



Figure 3: The vehicle's large treaded wheels are suitable for multiple surfaces.

5.4. Two-Seater Feature

This model features a double seat, allowing two children to ride comfortably, provided the combined weight does not exceed 130 lbs.



Figure 4: The spacious double seat accommodates two riders.

5.5. Product Video

For a visual guide on the features and operation of the ELEMARA 2 Seater Electric 4 Wheeler, please watch the official product video below.

Your browser does not support the video tag.

Video 1: Official product video showcasing the ELEMARA 2 Seater 4 Wheeler Kids Ride on ATV in action, demonstrating its features and two-seater capability.

6. CHARGING INSTRUCTIONS

The vehicle is powered by a 12V 10AH battery. Proper charging ensures optimal performance and battery longevity.



Figure 5: Information on the 12V 10AH battery and estimated playtime.



Figure 6: The vehicle features two charging ports for convenience.

1. Locate the charging port(s) on the vehicle.
2. Connect the charger to the charging port and then plug the charger into a standard wall outlet.
3. The charging indicator light on the charger will typically show red during charging and turn green when fully charged.
4. Initial charge time should be 8-12 hours. Subsequent charges should be 8-10 hours. Do not charge for more than 18 hours.
5. Disconnect the charger once charging is complete.

7. MAINTENANCE

Regular maintenance helps prolong the life of your electric 4 wheeler.

- **Cleaning:** Wipe the vehicle with a soft, damp cloth. Do not use abrasive cleaners or spray water directly onto electrical components.
- **Battery Care:** Charge the battery after each use. If storing for an extended period, charge the battery once a month to maintain its health.
- **Storage:** Store the vehicle in a dry, cool place away from direct sunlight and moisture.
- **Inspection:** Periodically check all screws, nuts, and electrical connections for tightness and wear.

8. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Vehicle does not move	Battery is low or disconnected	Charge the battery; check battery connections.
Vehicle moves slowly	Low battery charge; overloaded vehicle	Recharge battery; ensure weight limit is not exceeded.
No sound/lights	Loose wire connection; battery issue	Check all electrical connections; ensure battery is charged.
Charger not working	Faulty outlet; damaged charger	Try a different outlet; contact customer support for a replacement charger.

If the problem persists after attempting these solutions, please contact ELEMARA customer support.

9. SPECIFICATIONS

Feature	Detail
Model Number	S615
Product Dimensions	43 x 26 x 27 inches
Item Weight	30 pounds
Battery	1 x 12V (included)
Recommended Age	3 years and up
Maximum Weight Capacity	130 lbs
Motors	2*80W (inferred from image)
Speed	3.1-4 MPH (inferred from image)

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official ELEMARA website. You can also contact customer service via the details provided on the packaging.

Manufacturer: ELEMARA

Release Date: January 19, 2025