Giraffe Tools HBA5010US

Giraffe Tools Commercial Electric Ultraflow Pressure Washer

MODEL: HBA5010US

Introduction

The Giraffe Tools Commercial Electric Ultraflow Pressure Washer is engineered for superior cleaning performance and versatility. With its robust all-copper pump, quiet brushless motor, and dual mounting options, this unit provides efficient and powerful cleaning for a wide range of applications, from residential patios to commercial vehicles. This manual provides essential information for safe and effective operation, maintenance, and troubleshooting.

Important Safety Information

WARNING: Read and understand all safety instructions carefully before operating this pressure washer.

- **Eye Protection:** Always wear proper eye protection (safety glasses or goggles) during operation.
- **Hearing Protection:** Consider wearing hearing protection, especially during extended use, due to operational noise.
- **Footwear:** Ensure proper, sturdy footwear is worn to prevent slipping and protect feet from high-pressure spray.
- **Nozzle Safety:** Do not point the nozzle at people or animals. High-pressure spray can cause serious injury.
- **Electrical Safety:** Must be adapted to the grounded power supply to prevent leakage of electricity. Features built-in GFCI protection for ultimate jobsite safety.
- **Temperature:** Use at the proper temperatures, avoiding temperatures of 32°F (0°C) and below. Must be drained from the pump and high-pressure hose to prevent freezing.
- **Nozzle Changes:** Do not change the nozzle at random. Only use the nozzle provided by the company to prevent equipment damage.


Product Features



Overall Product View: The Giraffe Tools Commercial Electric Ultraflow Pressure Washer shown with its main components including the pressure washer unit, spray gun, hose, and various nozzles.



Dual-Use Versatility: This pressure washer offers flexible operation, allowing it to be mounted on a wall for space-saving storage or used freely on the ground for portable cleaning tasks.



Stable All-Copper Pump: Engineered for extreme durability, its solid copper core resists heat, corrosion, and wear, delivering stable high-pressure performance for up to 1000 hours.



High-efficiency Brushless Motor Technology: The advanced brushless motor delivers friction-free power, higher speeds, and heavy-duty endurance with minimal maintenance, converting more energy into cleaning force.



Ultra-Quiet 60dB Operation: This electric cleaner operates at just 60dB, significantly quieter than diesel models, allowing for comfortable use without earplugs.



Maximize Efficiency & Convenience: With a high-efficiency 2.6 Gallons Per Minute (GPM) flow rate and 1650 PSI, this unit tackles tough grime faster, boosting productivity. The auto-retractable hose system eliminates messy tangles.



Plug & Play Clean Power: Simply plug in for powerful cleaning with zero emissions, offering a cleaner, greener alternative to gas models. Features built-in GFCI protection and a TSS pump system for automatic shutdown.

GIRAFFE TOOLS 2.6GPM PRESSURE WASHER

1650 MAX PSI



Key Components: Features include a durable steel frame, 15°, 25°, 40° & Turbo Nozzles, a brushless motor, a 50ft burst-resistant steel hose, and a simple On/Off switch.

Official Product Videos

Brushless motor with full-copper pump: This video highlights the internal workings of the pressure washer, showcasing its durable full-copper crankshaft pump and efficient brushless motor, designed for heavy-duty cleaning tasks.

Maximize Efficiency: 2.6GPM Flow Cleans in Seconds!: This video demonstrates the high-efficiency 2.6 GPM flow rate of the pressure washer, showing how it quickly and effectively cleans various surfaces, saving time and effort.

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all parts listed in the packing list are present and undamaged.

2. **Mounting (Optional):** If wall-mounting, use the provided bracket and appropriate hardware to secure the unit to a sturdy wall. Ensure it is level and securely fastened.
3. **Water Connection:** Connect a standard garden hose to the water inlet on the pressure washer. Ensure all connections are tight to prevent leaks.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. The unit features built-in GFCI protection.
5. **Hose and Spray Gun Assembly:** Connect the high-pressure hose to the pressure washer unit and the spray gun. Attach your desired nozzle (15°, 25°, 40°, or Turbo) to the spray gun.
6. **Soap Dispenser (Optional):** If using soap, fill the foam cannon with appropriate pressure washer detergent and attach it to the spray gun.

Operating Instructions

1. **Prepare for Use:** Ensure the water supply is turned on and the pressure washer is connected to power.
2. **Start the Unit:** Press the power button to turn on the pressure washer. The motor will start when the spray gun trigger is pressed.
3. **Using Nozzles:** Select the appropriate nozzle for your task. The 15° nozzle provides a concentrated stream for tough spots, the 25° and 40° nozzles offer wider spray patterns for general cleaning, and the Turbo Nozzle provides maximum cleaning power for stubborn dirt.
4. **Cleaning Technique:** Hold the spray gun firmly and maintain a safe distance from the surface being cleaned. Move the spray gun in a sweeping motion to ensure even cleaning.
5. **Applying Soap:** If using the foam cannon, ensure it is filled with detergent. The unit will draw soap when the low-pressure nozzle is selected. Apply soap to the surface, allow it to dwell, then rinse thoroughly with a high-pressure nozzle.
6. **Automatic Rewind:** To retract the hose, give it a slight tug to disengage the lock, and it will automatically rewind into the unit.
7. **Shutting Down:** After use, turn off the water supply, release any remaining pressure by pressing the spray gun trigger, and then turn off the power switch.

Maintenance

- **Cleaning:** Regularly clean the exterior of the pressure washer with a damp cloth.
- **Nozzle Care:** Clean nozzles regularly to prevent clogging. Use the included nozzle cleaning tool if necessary.
- **Winterization:** In cold climates, drain all water from the pump and hose before storing to prevent freezing and damage.
- **Storage:** Store the pressure washer in a dry, protected area away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
No pressure	Insufficient water supply	Ensure water supply is fully open and hose is not kinked.
Motor not starting	No power or tripped GFCI	Check power connection and reset GFCI if tripped.

Problem	Possible Cause	Solution
Pulsating pressure	Air in pump or clogged nozzle	Purge air by running unit with spray gun open until steady flow. Clean or replace nozzle.
Water leaks	Loose connections or damaged O-rings	Tighten all connections. Inspect and replace O-rings if damaged.

Specifications

Specification	Detail
Brand	Giraffe Tools
Model Number	HBA5010US
Power Source	Corded Electric
Maximum Pressure	1650 PSI
Maximum Flow Rate	2.6 Gallons Per Minute (GPM)
Hose Length	50 Feet
Item Weight	71.9 Pounds
Product Dimensions	21.93"L x 18.58"W x 19.41"H
Motor Type	Brushless
Pump Type	All-Copper Crankshaft
Noise Level	60dB

Warranty and Support

The Giraffe Tools Commercial Electric Ultraflow Pressure Washer is backed by a **3-Year Professional Support** commitment. Our dedicated customer service team is always ready to help, ensuring you get the support you need, when you need it. For any inquiries or assistance, please refer to the contact information provided in your product packaging or visit the official Giraffe Tools website.

© 2025 Giraffe Tools. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question