

[Manuals.plus](#) /

› [PowerA](#) /

› PowerA Enhanced Wireless Controller for Nintendo Switch/Switch 2 / Switch Lite/OLED Model - Pikachu vs. Gengar - Instruction Manual

PowerA NSGP0420-01R

PowerA Enhanced Wireless Controller for Nintendo Switch - Pikachu vs. Gengar

Model: NSGP0420-01R

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your PowerA Enhanced Wireless Controller, featuring the unique Pikachu vs. Gengar design. This officially licensed controller is designed to enhance your gaming experience on Nintendo Switch, Nintendo Switch Lite, and Nintendo Switch (OLED Model) consoles.




The PowerA Enhanced Wireless Controller with Pikachu vs. Gengar artwork.

KEY FEATURES

- **Wireless Connectivity:** Utilizes Bluetooth 5.0 technology for a stable connection.
- **Rechargeable Battery:** Integrated lithium-ion battery provides up to 30 hours of gameplay per charge.
- **Mappable Advanced Gaming Buttons:** Two programmable buttons on the back for custom control.
- **Ergonomic Design:** Superior ergonomics for extended comfortable gaming sessions.
- **Smooth Thumbstick Control:** Embedded anti-friction rings ensure precise and fluid movement.
- **Motion Controls:** Supports intuitive motion controls for compatible games.



Ergonomic design for comfortable gameplay.



Enjoy wireless freedom with Bluetooth 5.0 technology.

SETUP AND PAIRING

1. Ensure your Nintendo Switch console is powered on and updated to the latest system software.
2. From the HOME Menu, select **Controllers**, then **Change Grip/Order**.
3. Press and hold the **SYNC Button** on the top edge of your PowerA Enhanced Wireless Controller for at least one second. The Player LED(s) will flash.
4. Once paired, the Player LED(s) corresponding to the controller number will remain lit.
5. Press the **A Button** to confirm and exit the menu. Your controller is now ready for use.

CHARGING THE CONTROLLER

The controller features an internal 900mAh lithium-ion rechargeable battery, providing up to 30 hours of gameplay on a single charge. To charge your controller:

1. Connect the included 10ft (3m) USB-C charge cable to the USB-C port on the top of the controller.
2. Connect the other end of the USB-C cable to a USB power source (e.g., Nintendo Switch dock, USB wall adapter, or computer USB port).
3. The LED indicator on the controller will show charging status. It will typically turn off or change color when fully charged.



Connect the USB-C cable to charge your controller.

ADVANCED GAMING BUTTONS

Your PowerA Enhanced Wireless Controller includes two mappable Advanced Gaming Buttons (AGBs) on the back, allowing you to assign specific button functions for quick access during gameplay.

Programming AGBs:

1. Press the **Program Button** on the back of the controller. The Program LED will flash, indicating programming mode.
2. Press the button you wish to map (A/B/X/Y/L/R/ZL/ZR/Left Stick Click/Right Stick Click/D-Pad). The Program

LED will flash rapidly.

3. Press the Advanced Gaming Button (AGB L or AGB R) you want to assign the function to. The Program LED will stop flashing, indicating the AGB is now programmed.

Resetting AGBs:

To reset all Advanced Gaming Buttons to their default (no function) state, press and hold the **Program Button** for five seconds. The Program LED will flash slowly, then turn off, confirming the reset.



MAPPABLE ADVANCED GAMING BUTTONS

Mappable Advanced Gaming Buttons for personalized control.

COMPATIBILITY

This PowerA Enhanced Wireless Controller is compatible with the following Nintendo consoles:

- Nintendo Switch
- Nintendo Switch Lite
- Nintendo Switch (OLED Model)
- Nintendo Switch 2 (Note: C button not available)



WORKS WITH NINTENDO SWITCH 2 C BUTTON NOT AVAILABLE

The controller is compatible with Nintendo Switch 2, though the C button functionality is not available.

SPECIFICATIONS

Feature	Detail
Compatible Devices	Nintendo Switch
Controller Type	Gamepad
Connectivity Technology	Bluetooth, USB
Additional Features	Ergonomic, Wireless
Button Quantity	12
Hardware Platform	Gaming Console

Power Source	Battery Powered (Rechargeable Lithium-ion)
Compatible Video Game Console Models	Nintendo Switch, Nintendo Switch Lite
Item Weight	0.68 Pounds
Item Dimensions	6.02 x 4.41 x 2.48 inches
Color	Pikachu vs Gengar
Model Name	Pikachu vs. Gengar
Model Number	NSGP0420-01R

CARE AND MAINTENANCE

- Keep the controller dry. Avoid exposure to moisture or extreme temperatures.
- Clean the controller with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the controller in a safe place when not in use to prevent damage.

TROUBLESHOOTING

Controller Not Connecting:

- Ensure the controller is fully charged.
- Verify the controller is within the Bluetooth range of your Nintendo Switch console.
- Attempt to re-pair the controller following the "Setup and Pairing" instructions.

Unresponsive Buttons/Joysticks:

- Check for any physical obstructions or debris around the buttons or joysticks.
- Perform a hard reset by holding the SYNC button for 10 seconds, then attempt to re-pair.
- Ensure the controller's firmware is up to date (check PowerA's official website for updates).

WARRANTY AND SUPPORT

This PowerA Enhanced Wireless Controller comes with a **Two-year limited warranty**. For detailed warranty information, product support, and troubleshooting assistance, please visit the official PowerA support website:

[PowerA.com/Support](https://www.powera.com/support)