

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### Manuals.plus /

- › [Supor](#) /
- › SUP0R Cooking Blender HBR702US User Manual

## Supor HBR702US

# SUP0R Cooking Blender User Manual

Model: HBR702US | Brand: Supor

## 1. PRODUCT OVERVIEW

The SUP0R Cooking Blender HBR702US is a versatile kitchen appliance designed for blending and cooking various ingredients, including soymilk, juice, and soups. It features a soundproof shield for quiet operation, a durable borosilicate glass cup, and a powerful motor with stainless steel blades for efficient processing. The split design allows for easy cleaning and maintenance.



This image displays the SUPOR Cooking Blender, featuring its main unit with a digital control panel, a transparent blending cup, and a clear soundproof shield. The cup contains various fruits, indicating its blending capability.

## 2. IMPORTANT SAFETY INSTRUCTIONS

**Please read all instructions carefully before using the appliance and retain for future reference.**

- Always ensure the blender is unplugged before assembly, disassembly, or cleaning.
- Do not immerse the motor base in water or other liquids. Clean with a damp cloth only.
- Keep hands and utensils out of the blending cup while operating to prevent injury.
- Ensure the lid and soundproof shield are properly secured before starting the blender.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Do not operate the blender with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Avoid contact with moving parts.
- Do not use attachments not recommended or sold by the manufacturer.
- The blender will automatically stop working when the jar is picked up or the lid is open, as a safety measure.

# SUPOR

## 高速降噪加熱破壁調理機 Double Sound Covered Heating Blender




霍爾恆速  
降噪電機

Hall motor,  
constant speed  
and noise  
reduction



消音風道&  
智巧消音蓋

Noise reduction  
duct and box



可拆洗&  
高溫蒸氣清洗

Detachable blade&  
High temp. steam  
cleaning



高速擊碎食材  
幹豆免泡直打

High speed to  
crush, beans soak  
free

**⚠ WARNING:**

This product can expose you to chemicals including Bisphenol A, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).



The back of the product packaging highlights key safety features and specifications. Text indicates 'Auto stops working when the jar is picked up' and 'Auto stops working when the lid is open'. It also mentions 'Silicone anti-slip mats' and 'Approx. 6mm thick high borosilicate glass'. Essential product details like Model HBR702US, Rated Voltage 120V/60Hz, Power 350W, Heating Power 600W, and Capacity Range 0.5L-1.5L are listed.

### 3. PRODUCT COMPONENTS

The SUPOR Cooking Blender consists of the following main parts:

1. **Motor Base:** Contains the motor, control panel, and power cord.
2. **Blending Cup:** Made of 6mm thickened high borosilicate glass, with a non-stick bottom. It has a capacity

of 1.5 liters.

3. **Blade Assembly:** Three-layer, 8-blade stainless steel design for efficient blending. This is detachable for cleaning.
4. **Lid:** Secures the blending cup during operation.
5. **Soundproof Shield:** A transparent outer cover that reduces operational noise.

## 4. SETUP

---

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash the blending cup, lid, and blade assembly with warm, soapy water. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.
3. **Placement:** Place the motor base on a stable, flat, and dry surface. Ensure there is adequate ventilation around the appliance.
4. **Assembly:**
  - Place the blending cup onto the motor base, ensuring it is securely seated.
  - Add ingredients to the blending cup.
  - Place the lid onto the blending cup and ensure it is properly sealed.
  - Lower the soundproof shield over the blending cup and onto the motor base until it clicks into place.
5. **Power Connection:** Plug the power cord into a standard 120V/60Hz electrical outlet.

## 5. OPERATING INSTRUCTIONS

---

The SUP0R Cooking Blender features a digital control panel with various pre-set functions and manual controls.



A detailed view of the blender's digital control panel. It shows various pre-set functions like Soup, Beans Paste, Rice Milk, Rice Paste, Mung Bean Soup, Nuts Milk, Veggie Juice, and High Temp. Clean. Below these, buttons for Schedule, Speed, Menu, Quick Soya, and Start/Stop are visible.

### 5.1 Basic Operation

1. **Power On:** After plugging in, the display will illuminate.
2. **Adding Ingredients:** Ensure ingredients do not exceed the maximum fill line (1.5L capacity). For hot liquids, fill to a lower level to allow for expansion.
3. **Selecting a Program:**

- Press the 'Menu' button to cycle through the pre-set functions displayed on the screen (e.g., Soup, Beans Paste, Rice Milk, Nuts Milk, Veggie Juice).
  - Alternatively, for quick soymilk, press the 'Quick Soya' button.
4. **Adjusting Speed (if applicable):** For certain programs or manual blending, press the 'Speed' button to adjust the blending intensity.
  5. **Scheduling (Optional):** Use the 'Schedule' button to set a delayed start time for your blending program.
  6. **Start/Stop:** Press the 'Start/Stop' button to begin or pause the selected program. The blender will automatically stop when the program is complete.

## 5.2 Blending Tips

- For best results, cut larger ingredients into smaller pieces before blending.
- When blending thick mixtures, you may need to add more liquid to achieve the desired consistency.
- The blender's high-speed crushing allows for dry beans to be processed directly without soaking for certain recipes.



This image shows a person carefully pouring a freshly blended mixture from the blender's cup into a small serving bowl. The blender's base and soundproof shield are visible on a kitchen counter, highlighting its practical use.

## 6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your blender. The split design allows for easy cleaning.

## 6.1 Daily Cleaning

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Disassemble:** Remove the soundproof shield, then lift the blending cup from the motor base. The blade assembly is detachable from the cup.
3. **Wash Cup and Blades:** Wash the blending cup, lid, and detachable blade assembly with warm, soapy water. Use a brush for thorough cleaning around the blades. Rinse well and dry completely.
4. **Clean Motor Base:** Wipe the motor base with a soft, damp cloth. Do not immerse the motor base in water.

## 6.2 High Temperature Steam Cleaning


The blender features a convenient 'High Temp. Clean' function for softening and flushing residue.

1. After use, add a small amount of water (and a drop of dish soap, if desired) to the blending cup.
2. Place the cup back on the base, secure the lid and soundproof shield.
3. Select the 'High Temp. Clean' program from the menu.
4. Press 'Start/Stop' to begin the cleaning cycle.
5. Once complete, discard the water, rinse the cup, and dry.

# SUPOR

## 高速降噪加熱破壁調理機

Double Sound Covered Heating Blender




### 提杯停止運行

Auto stops working when the jar is picked up



### 安全開蓋保護

Auto stops working when the lid is open



### 硅膠防滑腳墊

Silicone anti-slip mats



### 約6mm高硼硅玻璃

Approx. 6mm thick high borosilicate glass

型號: HBR702US

Model: HBR702US

攪拌功率: 350W

Blending Power: 350W

額定電壓: 120V/60Hz

Rated Voltage: 120V/60Hz

製造商: 浙江紹興蘇泊爾生活電器有限公司

Manufacturer: Zhejiang Shaoxing Supor Domestic Electrical Appliance Co., Ltd

地址: 浙江省紹興市世紀西街3號

Address: No.3, Shiji West Street, Shaoxing, Zhejiang, 312071, China

客服專線: 1(626)278-3886

TEL: 1(626)278-3886

容量範圍: 0.5L-1.5L

Capacity Range: 0.5L-1.5L

加熱功率: 600W

Heating Power: 600W



The front of the product packaging showcases several key features. Icons and text describe 'Soft sound noise reduction technology', 'Detachable blade & High temp. steam cleaning', 'Hall motor, constant speed and noise reduction', 'Noise reduction duct and box', and 'High speed to crush, beans soak free'.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outage; cup/lid not properly secured.	Check power connection; ensure cup and lid are correctly assembled and soundproof shield is in place.
Blender stops during operation.	Overheating; cup lifted; lid opened; program completed.	Unplug and let cool for 15-20 minutes; ensure cup and lid remain secure during operation.
Ingredients not blending smoothly.	Too little liquid; ingredients too large; overloaded cup.	Add more liquid; cut ingredients into smaller pieces; reduce quantity of ingredients.
Excessive noise during operation.	Improper assembly; foreign object in cup.	Ensure all parts are correctly assembled; check for any foreign objects before blending. The soundproof shield significantly reduces noise.

## 8. SPECIFICATIONS

- **Model Number:** HBR702US
- **Brand:** Supor
- **Capacity:** 1.5 Liters (1200ml)
- **Power Source:** 120V / 60Hz
- **Rated Power:** 350W
- **Heating Power:** 600W
- **Motor Speed:** Up to 28,000 rpm
- **Product Dimensions:** 8.5"D x 8.5"W x 16"H
- **Item Weight:** 10.34 pounds
- **Blade Material:** Stainless Steel
- **Cup Material:** 6mm Thick High Borosilicate Glass
- **Special Features:** Auto Shut Off, Automatic Cleaning, Detachable Attachment, Multiple Speeds, Touch Control Panel, Soundproof Shield, Non-stick Cup Bottom.
- **UPC:** [6950610232961](#)

## 9. WARRANTY AND SUPPORT

This SUP0R Cooking Blender HBR702US comes with a **1 Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover:

- Damage caused by accident, abuse, misuse, or neglect.
- Damage from unauthorized repair or modification.
- Normal wear and tear.

For warranty claims or technical support, please contact your retailer or the manufacturer's customer service. Please have your model number (HBR702US) and proof of purchase ready.

