



Manuals.plus /

› Aiwa /

› Aiwa AWS40BT Portable Bluetooth Speaker Instruction Manual

## Aiwa AWS40BT

# Aiwa AWS40BT Portable Bluetooth Speaker

Instruction Manual

Overview	Setup	Introduction Operation	Features Maintenance	Package Contents Troubleshooting	Product Specifications	Warranty & Support
----------	-------	---------------------------	-------------------------	-------------------------------------	---------------------------	-----------------------

## 1. INTRODUCTION

Thank you for choosing the Aiwa AWS40BT Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your device. Please read it thoroughly before use to ensure optimal performance and longevity of your speaker.

## 2. KEY FEATURES

- **Powerful 12W RMS Sound:** Enjoy clear and immersive audio with a signal-to-noise ratio greater than 80 dB, ensuring precision in every note and rhythm. Ideal for setting the mood at gatherings, parties, or trips with consistent quality music.
- **Karaoke Function with Microphone:** Connect your microphone and sing your favorite songs anywhere. Perfect for family gatherings, home parties, or trips, turning every moment into a fun and energetic experience.
- **Bluetooth 5.3 Connectivity and Versatile Inputs:** Offers stable connection up to 10 meters and compatibility with USB memory sticks up to 64 GB, plus an auxiliary input. Enjoy your music from multiple sources with ease and without interruptions.
- **3600 mAh Battery with USB-C Charging:** Provides up to 6.5 hours of continuous playback to accompany you all day. Its fast and practical USB-C recharge ensures it's always ready for the next party or gathering.
- **Compact Design with Integrated LED Lighting:** Weighing just 1.09 kg, it is light and easy to

transport. Its LED lights create the perfect ambiance, adding style and fun to transform any space into a vibrant stage.

### 3. PACKAGE CONTENTS

---

Please check the box for the following items:

- Aiwa AWS40BT Portable Bluetooth Speaker
- Wireless Microphone
- USB-C Charging Cable
- User Manual

### 4. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your Aiwa AWS40BT speaker.




**Figure 4.1:** Aiwa AWS40BT Speaker with Wireless Microphone. This image shows the speaker from an angled perspective, highlighting its compact design and the microphone attached to its side.



**Figure 4.2:** Front View of the Speaker. The front panel features the Aiwa logo and a prominent RGB LED light strip, showcasing its aesthetic appeal.



**Figure 4.3:** Top Control Panel. This image displays the intuitive control buttons on the top surface of the speaker, including power, volume, play/pause, mode, and light controls.



**Figure 4.4:** Speaker Dimensions. An image illustrating the compact size of the speaker with its length, width, and height measurements.

## 5. SETUP GUIDE

### 5.1 Charging the Speaker

1. Locate the USB-C charging port on the speaker.
2. Connect the provided USB-C cable to the speaker and a compatible USB power adapter (not included).
3. The LED indicator will show charging status. A full charge provides up to 6.5 hours of playback.

### 5.2 Bluetooth Pairing

1. Power on the speaker by pressing and holding the power button.
2. The speaker will enter Bluetooth pairing mode automatically, indicated by a flashing LED.
3. On your smartphone or other Bluetooth-enabled device, search for "Aiwa AWS40BT" in the Bluetooth settings.
4. Select the speaker to pair. Once connected, you will hear an audible confirmation, and the LED will stop flashing.

### 5.3 Connecting the Wireless Microphone

1. Ensure the speaker is powered on.
2. Power on the wireless microphone. It should automatically connect to the speaker.
3. Test the microphone by speaking into it to ensure sound is output through the speaker.

## 6. OPERATING INSTRUCTIONS

---

### 6.1 Basic Controls

- **Power Button (O):** Press and hold to turn the speaker ON/OFF.
- **Play/Pause (▶):** Press to play or pause music.
- **Volume Up (+):** Press to increase volume.
- **Volume Down (-):** Press to decrease volume.
- **Mode Button (M):** Press to switch between Bluetooth, USB, and Auxiliary input modes.
- **Light Button (☆):** Press to cycle through different RGB lighting modes or turn them off.

### 6.2 Music Playback

- **Bluetooth Mode:** After successful pairing, play music from your connected device.
- **USB Mode:** Insert a USB memory stick (up to 64 GB) into the USB port. The speaker will automatically switch to USB mode and begin playback.
- **Auxiliary Input:** Connect an audio device using a 3.5mm auxiliary cable (not included) to the AUX port. Press the Mode button to select AUX input.

### 6.3 Karaoke Function

With the wireless microphone connected, you can use the speaker for karaoke. Adjust microphone volume using the controls on the microphone itself.

### 6.4 RGB Lighting

Press the Light button (☆) on the speaker's control panel to change the RGB lighting effects. Multiple dynamic modes are available to enhance your listening experience.

## 7. PRODUCT DEMONSTRATIONS

---

Your browser does not support the video tag.

**Video 7.1:** Aiwa AWS40BT Speaker Features Overview. This video provides a quick overview of the speaker's main features, including its portable design, sound quality, Bluetooth connectivity, and integrated LED lights. It also demonstrates the included wireless microphone for karaoke.

## 8. MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The speaker is resistant to splashes. Do not submerge it in water. Ensure all port covers are securely closed when exposed to moisture.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.

## 9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on	Low battery	Charge the speaker using the USB-C cable.
No sound	Volume too low; Incorrect input mode; Device not connected	Increase volume; Press 'M' button to select correct input; Re-pair Bluetooth device.
Bluetooth connection unstable	Device too far; Obstructions; Interference	Move device closer to speaker (within 10m); Remove obstructions; Avoid other wireless devices.
Microphone not working	Microphone not powered on; Not paired	Ensure microphone is charged and powered on; Re-pair if necessary.
LED lights not working	Lights turned off; Malfunction	Press the Light button (☆) to cycle through modes; If issue persists, contact support.

## 10. SPECIFICATIONS

Feature	Detail
Brand	Aiwa
Model	AWS40BT
Dimensions (L x W x H)	27 x 13 x 11 cm
Connectivity Technology	Bluetooth 5.3, USB
Color	Black
Compatible Devices	Smartphone
Power Source	Battery
Connector Type	USB Type-C (charging), USB (playback)
Number of Channels	1
Frequency Response	80 KHz
Impedance	4 Ohms
Output Wattage	12W RMS (24W PMPO)
Item Weight	1.3 Kilograms
Material	Plastic
Battery Capacity	3600 mAh
Playback Time	Up to 6.5 hours

## 11. WARRANTY AND SUPPORT

---

### 11.1 Warranty Information

This product comes with a **1-year warranty** directly from the manufacturer. Please retain your proof of purchase for warranty claims.

### 11.2 Customer Support

For technical assistance, warranty claims, or further inquiries, please contact Aiwa customer support through their official website or the contact information provided with your product packaging.