

[Manuals.plus](#) /

› [AIPER](#) /

› Aiper Scuba X1 Pro Max All-in-One Pool Cleaning Robot User Manual

AIPER PRX9

Aiper Scuba X1 Pro Max All-in-One Pool Cleaning Robot

Brand: AIPER | Model: PRX9

1. PRODUCT OVERVIEW

The Aiper Scuba X1 Pro Max is an advanced all-in-one pool cleaning robot designed for comprehensive pool maintenance. It features intelligent pool mapping, adaptive cleaning paths, and powerful suction to ensure a spotless clean for all inground pools.



Image: The Aiper Scuba X1 Pro Max robotic pool cleaner with its charging dock and a smartphone displaying the control app.

Key Features:

- **Pool Mapping and Adaptive Path:** Utilizes advanced scanning technology to map the entire pool structure, dynamically adapting its cleaning path for comprehensive coverage.
- **All-in-One Cleaning System:** Efficiently cleans pool walls, floors, waterlines, platforms, and surfaces, ensuring a comprehensive and spotless clean.
- **Superior Filtration and Power:** Equipped with an Extra MicroMesh Ultra-Fine Filter for superior particle filtration and 8,500 GPH suction power.
- **Aviation Tech Inspired TVC Engine:** Delivers powerful suction, precise navigation, and superior maneuverability.
- **Smart Surface Parking:** Automatically returns to the surface and parks when cleaning is complete for easy retrieval.

All-in-One Comprehensive Pool Care




Image: Visual representation of the robot cleaning various areas of the pool including waterline, surface, wall, floor, and platform.

2. SETUP AND INITIAL USE

Before first use, ensure the Aiper Scuba X1 Pro Max is fully charged. Place the robot on its wireless charging dock, ensuring proper alignment. The indicator lights will confirm charging status.

First Time Operation:

1. Ensure the robot is fully charged.
2. Carefully place the robot into the pool. It will sink and begin its initial mapping process.
3. For advanced control and monitoring, download the Aiper App from your device's app store and follow the in-app instructions to connect to your robot.

Your browser does not support the video tag.

Video: A comprehensive overview of the Aiper Scuba X1 Pro Max, demonstrating its unboxing, initial setup, and various cleaning capabilities in a pool environment.

3. OPERATING INSTRUCTIONS

The Aiper Scuba X1 Pro Max offers multiple cleaning modes and smart features to optimize your pool cleaning experience.

Cleaning Modes:

- **Eco Mode:** Energy-efficient cleaning for light debris.
- **Auto Mode:** Standard comprehensive cleaning.
- **Max Mode:** Intensive cleaning for heavy debris.
- **Floor Cleaning:** Focuses solely on the pool floor.
- **Wall Cleaning:** Targets pool walls and vertical surfaces.
- **Floor+Wall Cleaning:** Combines floor and wall cleaning for a thorough clean.
- **Skimming Mode:** Operates on the water surface to collect floating debris.




Image: An illustration showing the seven distinct cleaning modes available for the Aiper Scuba X1 Pro Max.

Smart Control with Aiper App:

The Aiper App provides enhanced control and monitoring capabilities for your robot. Through the app, you can:

- **View Pool Map:** See the robot's cleaning progress and mapped areas.
- **Access Cleaning Logs:** Review past cleaning cycles.
- **Select Modes:** Easily switch between different cleaning modes.
- **OTA Upgrade:** Receive over-the-air firmware updates.
- **Device Monitoring:** Keep track of the robot's status.

Smart Control with Aiper App

- View Pool Map
- Cleaning Logs
- Select Modes
- OTA Upgrade
- Device Monitoring

Note: App control is available only out of water.
With Aiper HydroComm™ Pro, underwater connection and control are enabled.




Image: A user interacting with the Aiper App on a smartphone, demonstrating features like pool map viewing and mode selection.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Aiper Scuba X1 Pro Max.

Filter Cleaning:

The robot is equipped with a dual filtration system. After each cleaning cycle, it is recommended to clean the filter basket to remove collected debris.

1. Open the robot's top cover.
2. Remove the filter basket.
3. Empty large debris and rinse the filter screens thoroughly with a hose.
4. Ensure the filters are completely clean before reinserting the basket and closing the cover.

Double Filtration Ultra-Fine for Ultra Clean

With two interchangeable filters, it captures everything from large debris to microscopic particles. The ultra-fine filter ensures your pool water stays crystal clear.




Image: A visual guide to the robot's double filtration system, showing both the 180µm standard filter for heavy debris and the 3µm ultra-fine filter for enhanced clarity.

5. TROUBLESHOOTING

If you encounter any issues with your Aiper Scuba X1 Pro Max, please refer to the detailed troubleshooting guide in the full user manual available on the Aiper website. Common issues often relate to filter cleanliness, battery charge, or proper placement in the pool. For persistent problems, contact Aiper customer support.

6. SPECIFICATIONS

Attribute	Detail
Power Source	Battery Powered
Control Method	App
Battery Type	1 Lithium Ion battery (included)
Lithium Battery Energy Content	262 Watt Hours
Product Dimensions	19.7 x 16.9 x 11.7 inches
Item Weight	55 pounds
Material	Plastic
Color	Blue

7. WARRANTY AND SUPPORT

Warranty Information:

The Aiper Scuba X1 Pro Max comes with a**Lifetime Warranty**, ensuring long-term peace of mind for your investment.

Customer Support:

For any questions, technical assistance, or warranty claims, please visit the official Aiper website or contact their customer support team directly. Refer to the packaging or the full digital manual for specific contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question