

[Manuals.plus](#) /

› [Diveblues](#) /

› Diveblues iTurbo Handheld Turbo Fan Instruction Manual

Diveblues D5022

Diveblues iTurbo Handheld Turbo Fan

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Diveblues iTurbo Handheld Turbo Fan. This manual provides essential information for the safe and efficient operation of your new portable fan. Please read it thoroughly before use and keep it for future reference.

Included Components

- 1x iTurbo Fan
- 1x USB Charging Cable
- 1x Lanyard
- 1x Instruction Manual (this document)

Specifications

Brand	Diveblues
Model Name	iTurbo
Model Number	D5022
Color	Green
Power Source	Battery Powered
Battery Capacity	2000mAh
Using Time	2-6 Hours (Up to 12 hours for 4000mAh variant, 2-6 hours for 2000mAh variant)
Number of Power Levels	5
Product Dimensions	1.7"D x 1.9"W x 6"H

Item Weight	4.2 ounces (0.25lbs)
-------------	----------------------

Setup

Before first use, fully charge your Diveblues iTurbo fan. Connect the provided USB-C charging cable to the fan's charging port and plug the other end into a compatible USB power adapter (not included).



Image: The fan's USB-C charging port located on the side of the handle.

To attach the lanyard, thread the thin loop of the lanyard through the small hole on the side of the fan's handle. Then, pass the larger part of the lanyard through the thin loop and pull to secure.



Image: The fan with its adjustable lanyard, demonstrating how it can be worn around the neck.

Operating Instructions

The Diveblues iTurbo fan features a single button for all operations and an LED display for easy monitoring.

- **Power On/Off:** Press the power button once to turn on the fan at speed 1. The LED display will show the current

speed and battery level.

- **Adjusting Fan Speed:** While the fan is on, press the power button repeatedly to cycle through speeds 1 to 5. Each press increases the speed.
- **Power Off:** To turn off the fan, press and hold the power button for 2 seconds. The device will remember the last used speed setting when turned back on.
- **LED Display:** The display shows the current fan speed (1-5) and the remaining battery percentage (indicated by green bars).

Travel-Ready Ultra-Portable

Take it anytime, anywhere.
6.0*1.9*1.7In

Only
0.25 lbs



Image: The fan's LED display showing different speed settings and their respective airflow in meters per second.

Versatility

The iTurbo fan is designed for multi-use convenience:

- **Handheld:** Use it directly in your hand for immediate cooling.
- **Desk Fan:** Fold the fan head to create a stable base, allowing it to stand on a desk or flat surface.
- **Neck Fan:** Attach the included lanyard to wear the fan around your neck for hands-free cooling. The fan head can be adjusted to direct airflow.

Breeze Your Way, Your Style



Image: The fan demonstrating its three versatile uses: handheld, as a desk fan, and worn around the neck.

Your browser does not support the video tag.

Video: Official Diveblues video demonstrating the mini portable fan's features and uses, including its compact size and various modes.

Your browser does not support the video tag.

Video: Official Diveblues video showcasing the powerful turbo airflow of the portable fan, highlighting its 9m/s airflow capability.

Maintenance

- **Cleaning:** Ensure the fan is turned off before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use harsh chemicals or abrasive materials. Do not immerse the fan in water or any other liquid.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place away from direct sunlight and extreme temperatures.
- **Safety Warning:** Do not put fingers or hard objects into the fan net cover to avoid injury. Children under 14 must be supervised when using this product.

Troubleshooting

- **Fan not turning on:** Ensure the battery is charged. Connect the fan to a power source using the USB-C cable.
- **Low airflow:** Check the fan speed setting on the LED display and increase it if necessary. Ensure the fan intake and output are not obstructed.
- **Not charging:** Verify that the USB-C cable is securely connected to both the fan and the power adapter. Try a different USB port or power adapter.

Warranty

Diveblues offers a limited warranty for this product:

- **US/CA:** 12-month limited warranty
- **EU/UK:** 24-month limited warranty

This warranty covers equipment failure or damage under normal use conditions. It does not cover damage caused by improper installation, storage, misuse, accidents, or natural disasters.

Support

For customer service or technical support, please contact us:

- **Email:** support@diveblues.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question