

- Manuals.plus /
- › SoarFlash /
- › SoarFlash Chenille Modular Sofa (Model 31) User Manual

SoarFlash 31

SoarFlash Chenille Modular Sofa User Manual

Model: 31 | Brand: SoarFlash

1. INTRODUCTION

Thank you for choosing the SoarFlash Chenille Modular Sofa. This manual provides essential information for the safe assembly, operation, and maintenance of your new sofa. Please read these instructions carefully before use and retain them for future reference.



Image: Front view of the SoarFlash Chenille Modular Sofa.

2. SAFETY INFORMATION

- Keep away from open flames or high heat sources to prevent fire hazards.
- Supervise children and pets to avoid entrapment risks or injury.
- Allow vacuum-packed cushions and pillows to fully expand before use. This process may take 2-7 days.
- Keep small components and packaging materials out of reach of children and pets during assembly and when not in use.

3. PACKAGE CONTENTS

Your SoarFlash Chenille Modular Sofa (2-Seat model) typically includes the following components. Please verify all parts are present before beginning assembly.

- Seat Modules (2 units)
- Backrests (2 units)
- Armrests (2 units)
- Seat Cushions (2 units)
- Back Cushions/Throw Pillows (quantity may vary)
- Sofa Legs (8 units)
- Assembly Hardware (bolts, washers, Allen wrench)

Note: Multiple packages may arrive separately. Please wait patiently for all boxes to be delivered before starting assembly. If any parts are missing or damaged, please contact SoarFlash customer support.



Image: Illustration of typical sofa components including seat base, backrest, armrests, and cushions.

4. SETUP AND ASSEMBLY

Assembly is required for this product. While some tools may be included, additional tools might be necessary. Follow these general steps for assembly:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Attach Legs:** Securely attach the sofa legs to the bottom of each seat module. Ensure they are tightened properly.
3. **Connect Seat Modules:** Align the connectors on the sides of the seat modules and slide them together until they lock.
4. **Install Backrests:** Slide the backrests into the designated slots on the seat modules. Ensure they are fully seated and stable.
5. **Attach Armrests:** Connect the armrests to the sides of the sofa using the provided hardware.
6. **Place Cushions:** Arrange the seat cushions and back cushions/throw pillows on the sofa. Allow vacuum-packed cushions 2-7 days to fully expand to their original shape.

Assembly Video Resources:

Your browser does not support the video tag.

Video: SoarFlash 2-Seat Sofa Installation Video. This video demonstrates the assembly process for a 2-seat modular sofa.

Your browser does not support the video tag.

Video: SoarFlash 3-Seat Sofa Installation Video. While for a 3-seat model, the assembly steps are largely similar and can provide guidance.

5. OPERATING INSTRUCTIONS

Your SoarFlash Chenille Modular Sofa is designed for comfort and versatility.

Modular Design:

The modular design allows you to rearrange the seat modules and ottoman (if included) to suit your space and preferences. You can create various configurations such as a 2-seat loveseat, or combine with additional modules for larger setups. Simply disconnect the modules and reconfigure as desired.



Image: Examples of flexible modular configurations for the sofa.

Comfort Features:

- **Deep Seating:** Enjoy the generous 25-inch deep seats for enhanced relaxation.
- **High-Density Foam:** The cushions are crafted with high-density foam and a dual-layer construction for optimal support and pressure relief.
- **Chenille Upholstery:** The soft, breathable chenille fabric provides a comfortable and luxurious feel.

Ultra-comfortable Seats



Image: Close-up view of the chenille fabric texture and icons highlighting soft, durable, breathable, and comfortable features.

Your browser does not support the video tag.

Video: SoarFlash Sofa Material Detail. This video showcases the chenille fabric and cushion construction.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your sofa.

- **General Cleaning:** For routine cleaning, vacuum the sofa regularly using an upholstery attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain. For stubborn stains, consult a professional upholstery cleaner.
- **Cushion Covers:** Removable cushion covers can be machine washed on a gentle cycle. Always follow the care instructions on the label.

- **Overall Fabric Care:** The chenille upholstery is recommended for dry clean only for best results.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading. Position your sofa away from direct sunlight or use curtains/blinds.

7. TROUBLESHOOTING

Cushions Not Fully Expanded:

If your cushions appear flat or not fully shaped after unpacking, this is normal. They are vacuum-packed for shipping. Allow 2-7 days for the high-density foam to fully expand to its original shape. Gently fluffing and rotating the cushions can help accelerate this process.

Sofa Appears Low:

The sofa is designed with a modern low profile. If you prefer a higher seating position, consider replacing the existing legs with taller furniture legs (not included). Ensure any replacement legs are compatible and provide adequate support.

Loose Connections:

Periodically check all bolts and connections to ensure they remain tight. Retighten as necessary to maintain stability and safety.

8. SPECIFICATIONS

Brand	SoarFlash
Model Number	31
Type	Loveseat (Modular Sectional Sofa)
Color	Black
Upholstery Fabric Type	Chenille
Frame Material Type	Wood
Fill Material	High Density Foam
Product Dimensions (D x W x H)	35"D x 76.7"W x 33"H
Seat Depth	25 inches
Seat Height	19 inches
Assembly Required	Yes
Product Care Instructions	Dry Clean Only. Removable Cushions: Machine Wash Gentle Cycle
Item Firmness Description	Medium to Firm

9. WARRANTY AND SUPPORT

Warranty:

This SoarFlash Chenille Modular Sofa comes with a Limited Warranty. Please refer to your purchase documentation or contact customer support for specific warranty terms and conditions.

Customer Support:

For any questions, missing parts, assembly assistance, or warranty claims, please contact SoarFlash customer support. You can typically find contact information through your retailer or the official SoarFlash website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question