

[Manuals.plus](#) /

› [LIKIMIO](#) /

› LIKIMIO Twin XL Over Twin XL Metal Bunk Bed Instruction Manual

LIKIMIO 1062827

LIKIMIO Twin XL Over Twin XL Metal Bunk Bed Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the assembly, safe use, and proper maintenance of your LIKIMIO Twin XL Over Twin XL Metal Bunk Bed. Please read all sections thoroughly before proceeding with assembly or use to ensure safety and product longevity.

SAFETY INFORMATION

Always supervise children when using the top bunk. Exercise caution regarding sharp edges during the assembly and disassembly processes of the bed frame. Ensure adequate clear space around the bed to prevent entrapment or injury. The maximum weight recommendation for this bunk bed is 500 pounds.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. All necessary parts, tools, and detailed instructions are conveniently packaged in one box. Refer to the included installation manual for a complete list of parts.



Image: Fixtures and connection points for LIKIMIO bunk bed assembly.

ASSEMBLY INSTRUCTIONS

The LIKIMIO bunk bed is designed for straightforward assembly. Follow the step-by-step guide provided in the included installation manual. Ensure all connections are securely fastened before use.



Image: Close-up of a connecting device used in bunk bed assembly.



Image: This image highlights the smooth iron parts, ease of assembly, and solid, stable construction of the bunk bed.

OPERATING INSTRUCTIONS

This bunk bed accommodates Twin XL and Twin size mattresses. No box spring is needed as the metal slats provide sufficient support. Always ensure guardrails are properly installed on the top bunk for safety.



Image: Detailed view of the bunk bed's sturdy guardrails, showing their height and spacing for user safety.



Image: The integrated ladder provides safe and easy access to the top bunk.

MAINTENANCE

To maintain the quality and appearance of your bunk bed, wipe it with a dry cloth as needed. Periodically check all bolts and screws to ensure they remain tight and secure. Avoid using harsh chemicals or abrasive cleaners.

TROUBLESHOOTING

If you encounter any issues during assembly or use, first re-check all connections and ensure all parts are correctly installed according to the manual. For persistent problems, refer to the contact information provided by LIKIMIO for customer support.

SPECIFICATIONS

The following table details the key specifications of the LIKIMIO Twin XL Over Twin XL Metal Bunk Bed.



Image: Technical diagram illustrating the length, width, and height of the bunk bed.

Feature	Detail
Model Number	1062827
Size	Twin XL over Twin XL
Material	Metal
Product Dimensions (L x W x H)	81.9"L x 40.7"W x 71.7"H
Item Weight	72.5 Pounds
Maximum Weight Recommendation	500 Pounds

Feature	Detail
Compatible Mattress Size	Twin XL, Twin
Box Spring Required	No
Color	White
Assembly Required	Yes

OFFICIAL PRODUCT VIDEO

For a visual overview of the LIKIMIO Twin XL Over Twin XL Metal Bunk Bed, please watch the official product video below.

Your browser does not support the video tag.

Video: Official product overview of the LIKIMIO Twin XL Over Twin XL Bunk Bed, highlighting its features and design.

WARRANTY AND SUPPORT

LIKIMIO products are designed for quality and durability. For warranty information, technical support, or assistance with parts, please contact LIKIMIO customer service directly. Refer to the packaging or the official LIKIMIO website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question