YITAHOME MAYIHpQQQa

YITAHOME Manual Recliner Chair User Manual

Model: MAYIHpQQQa

1. Introduction

Thank you for choosing the YITAHOME Manual Recliner Chair with Massage and Heat. This chair is designed to provide ultimate comfort and relaxation with its adjustable recline, rocking function, integrated massage and heating features, and convenient amenities like USB charging ports, cup holders, and side pockets. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure a safe and enjoyable experience with your new recliner.

2. Safety Instructions

- Always read and understand all instructions before assembly and use.
- Do not exceed the maximum weight capacity of 300 lbs (136 kg).
- Keep children and pets away from the chair's moving parts, especially during recline and return.
- Ensure the power cord for massage, heat, and USB functions is properly connected and not pinched or damaged.
- Unplug the chair from the power outlet when not in use or before cleaning.
- Do not stand on the chair or use it as a step stool.
- Avoid spilling liquids on electrical components.
- For indoor use only.

3. Package Contents

Your YITAHOME recliner chair is designed for simple assembly and typically ships in one unit. Please verify that all components are present upon delivery. Refer to the packing list included with your physical manual for a detailed breakdown of parts.
Expected components generally include:

- Main Recliner Body
- Armrests (if detachable)
- Backrest (if detachable)
- Power Adapter and Cord
- Assembly Hardware (if required)

4. Assembly Instructions

The YITAHOME recliner is designed for quick and easy assembly. Typically, the chair arrives in a single package, requiring minimal setup. For detailed, step-by-step assembly instructions, please refer to the dedicated assembly guide included in the product packaging.



Figure 4.1: Product dimensions of the YITAHOME Recliner Chair.

5. Operating Instructions

5.1. Recline and Rocking Function

To recline the chair, simply pull the side handle located on the armrest. The footrest will lift, and you can lean back to your desired angle, up to 160 degrees. The chair also features a 30-degree rocking function for added comfort and relaxation.



Figure 5.1: Illustration of the 30-degree rocking function and various recline angles (90°, 120°, 160°).

5.2. Vibrational Massage and Lumbar Heating

The recliner is equipped with 8 vibrating points and lumbar heating to provide soothing comfort. It offers 5 massage modes: Pulse, Press, Wave, Auto, and Normal. The heating function can be operated independently of the massage.



Figure 5.2: Visual representation of the 8 massage points, lumbar heat, 5 massage modes, and 2 vibration levels.



Figure 5.3: The recliner chair with active massage points and lumbar heating area indicated.

5.3. USB Charging Ports, Cup Holders, and Side Pockets

The chair includes 2 USB ports for convenient charging of your electronic devices. Two cup holders are integrated into the armrests, and side pockets provide storage for magazines, remote controls, or other small items.



Figure 5.4: Close-up view of the dual USB charge ports, cup holders, and side pockets for storage.

5.4. Product Overview Video

Watch this official product video from YITAHOME for a visual demonstration of the recliner chair's features and functionality.

Your browser does not support the video tag.

Video 5.1: An overview of the YITAHOME Glider Rocker Recliner Chair, demonstrating its rocking, reclining, and comfort features.

6. Maintenance and Care

- **Cleaning:** Spot clean only. Use a mild detergent and a damp cloth for spills and stains. Do not use harsh chemicals or abrasive cleaners.
- **Regular Inspection:** Periodically check all bolts and connections to ensure they are tight. Retighten if necessary.
- **Fabric Care:** Avoid direct sunlight exposure for prolonged periods to prevent fading.
- **Electrical Components:** Keep the power cord and electrical connections dry and free from obstruction.

7. Troubleshooting

If you encounter any issues with your YITAHOME recliner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not recline or footrest does not extend.	Recline handle not fully engaged; obstruction under footrest.	Ensure handle is pulled completely. Check for any objects blocking the footrest mechanism.
Massage or heat function not working.	Power cord disconnected; power outlet issue; control panel malfunction.	Check if the power cord is securely plugged into the chair and a working outlet. Try a different outlet. Ensure the control panel is not damaged.
USB ports not charging devices.	Chair not plugged in; device cable faulty; device not compatible.	Verify the chair is plugged into a power source. Try a different USB cable or device.
Unusual noises during operation.	Loose hardware; mechanism friction.	Check and tighten any loose bolts. Apply a small amount of silicone lubricant to moving metal parts if friction is suspected.

If the problem persists after attempting these solutions, please contact YITAHOME customer support for further assistance.

8. Specifications

Feature	Detail
Model Name	Recliner Chair
Model Number	MAYIHpQQQa
Color	Brown2
Product Dimensions (D x W x H)	36" x 35.3" x 42.5"
Item Weight	82.7 pounds
Maximum Weight Recommendation	300 pounds
Fabric Type	Fabric
Fill Material	Sponge
Reclining Position Count	2+ (up to 160 degrees)
Rocking Function	30 degrees
Massage Points	8 Vibrating Points

Feature	Detail
Massage Modes	Pulse, Press, Wave, Auto, Normal
Heating Function	Lumbar Heat (independent operation)
USB Ports	2
Cup Holders	2
Assembly Required	Yes
Batteries Required	No
Product Care Instructions	Spot Clean

9. Warranty and Support

YITAHOME stands behind the quality of its products. For information regarding warranty coverage, claims, or technical support, please refer to the warranty card included with your purchase or visit the official YITAHOME website. You may also contact customer service directly through the retailer where the product was purchased.

Customer Support:

- Please refer to your purchase documentation for specific contact details.
- When contacting support, please have your model number (MAYIHpQQQa) and purchase date ready.

© 2025 YITAHOME. All rights reserved.