

OutVue 27 inch Stainless Steel Smokeless Fire Pit (Vertical Hole)

OutVue 27 Inch Stainless Steel Smokeless Fire Pit User Manual

Model: 27 inch Stainless Steel Smokeless Fire Pit (Vertical Hole)

1. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembling or operating this product. Failure to follow these instructions may result in property damage, personal injury, or death.

- Maintain a safe distance of at least 0.5 meters (approximately 20 inches) from the smokeless fire pit, especially for children and pets.
- Do not use this outdoor wood burning fire pit on grass, wooden floors, or any other combustible surfaces.
- Keep the fire pit away from flammable materials and furniture.
- Ensure the fire pit is placed on a stable, non-combustible surface.
- Never leave a burning fire pit unattended.
- Store the assembled fire pit in a cool, dry location away from children and pets when not in use.
- Keep the fire pit covered when it has cooled down and is not in use to protect it from elements.



Image: The OutVue smokeless fire pit shown with its included fire poker and a waterproof cover, essential for safe handling and storage.

2. PRODUCT OVERVIEW

The OutVue 27 inch Stainless Steel Smokeless Fire Pit is designed for outdoor use, providing efficient warmth with minimal smoke. Its durable construction and thoughtful design make it suitable for various outdoor gatherings.

2.1 Key Features

- **Low Smoke Design:** Features a unique internal airflow system for a cleaner, low-smoke flame.
- **Durable Material:** Constructed from stainless steel for stable heat resistance, corrosion resistance, and long service life.
- **Portable & Easy Assembly:** Can be assembled in seconds without tools, facilitating easy transport and storage.
- **Efficient Heating:** Delivers powerful warmth for outdoor spaces.
- **Easy to Clean:** Designed with a removable ash tray for convenient cleaning.

2.2 Components

The OutVue Smokeless Fire Pit consists of several key components that work together to create an efficient and low-smoke burn.



Image: An exploded diagram illustrating the main components of the fire pit: the top ring, the ash tray, the main fire bowl, and the support base.

- **Ring:** The top rim of the fire pit.
- **Ashtray:** Collects ash for easy disposal.
- **Fire Bowl:** The main chamber where wood is burned.
- **Support:** The base that elevates the fire pit from the ground.

2.3 Specifications

Specification	Detail
Material	Stainless Steel
Product Dimensions (D x W x H)	27"D x 27"W x 19.2"H
Item Weight	47.5 Pounds
Fuel Type	Wood
Color	Silver

Shape	Round
Model Number	ABCDEFGG




Image: The OutVue fire pit with its key dimensions, 27 inches in diameter and 19.2 inches in height, clearly indicated.

3. SETUP

3.1 Assembly Instructions

The OutVue Smokeless Fire Pit is designed for quick and easy assembly without the need for tools. Follow these steps:

1. Unpack all components from the packaging. Verify that all parts listed in Section 2.2 are present.
2. Attach the support base to the bottom of the fire bowl. The design allows for a simple, tool-free connection.
3. Place the ash tray inside the fire bowl, ensuring it sits correctly at the bottom.
4. Position the top ring onto the upper edge of the fire bowl.
5. Ensure all components are securely seated before use.

3.2 Placement Guidelines

Proper placement of your fire pit is crucial for safety and optimal performance.

- Always place the fire pit on a level, non-combustible surface such as concrete, pavers, or gravel.
- Never place the fire pit directly on grass, wooden decks, or other flammable surfaces.
- Ensure there is adequate clearance from overhead structures, trees, and any other combustible materials.
- Position the fire pit in an open area to allow for proper ventilation and smoke dissipation.

4. OPERATING INSTRUCTIONS

4.1 Fueling the Fire Pit

The OutVue fire pit is designed for burning wood or burn pellets.

- Use only dry, seasoned hardwood for best results and minimal smoke.
- Avoid using softwoods, treated wood, or trash, as these can produce excessive smoke, sparks, and harmful chemicals.
- Do not overfill the fire pit. Keep the fuel below the top air vents to ensure proper airflow and secondary combustion.

4.2 Lighting the Fire Pit

To light your fire pit:

1. Place a small amount of kindling (e.g., newspaper, small dry twigs) at the bottom of the fire bowl, on top of the ash tray.
2. Add a few small pieces of dry firewood on top of the kindling, arranged to allow air circulation.
3. Carefully ignite the kindling using a long lighter or match.
4. Once the kindling is burning steadily, gradually add larger pieces of wood, ensuring not to smother the flames.

4.3 Understanding the Low Smoke Design

The OutVue fire pit utilizes a unique double-wall construction and a 360-degree air inlet design to achieve its low-smoke performance. Air enters through the bottom vents, travels up between the double walls, and exits through the top vents, providing a secondary burn of smoke particles. This process results in a more complete combustion and significantly reduces visible smoke.



Image: A detailed diagram showcasing the internal airflow system, highlighting how air enters from below, circulates through the double walls, and fuels both the primary and secondary combustion for a low-smoke experience.

4.4 Extinguishing the Fire

Allow the fire to burn down naturally. Do not use water to extinguish the fire, as this can damage the stainless steel and create excessive steam. Once the flames have died down and only embers remain, allow the fire pit to cool completely before attempting to clean or cover it.

5. MAINTENANCE

5.1 Cleaning

Regular cleaning will help maintain the appearance and functionality of your fire pit.

1. Ensure the fire pit is completely cool before cleaning.
2. Lift the fire pit and remove the ash tray.
3. Dispose of the ash and debris from the ash tray responsibly.
4. Wipe down the exterior of the fire pit with a damp cloth. For stubborn stains, a mild stainless steel cleaner can be used.
5. Avoid abrasive cleaners or scouring pads, as these can scratch the stainless steel finish.

5.2 Storage

Proper storage protects your fire pit from the elements and extends its lifespan.

- Once the fire pit is clean and completely cool, place the provided waterproof cover over it.
- Store the covered fire pit in a cool, dry location, away from direct sunlight and harsh weather conditions.
- If storing for an extended period, consider disassembling the fire pit and storing components in their original packaging or a protective container.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your OutVue Smokeless Fire Pit.

Problem	Possible Cause	Solution
Excessive Smoke	Wet or unseasoned wood; too much fuel; blocked air vents.	Use dry, seasoned hardwood. Do not overfill the fire pit. Ensure air vents are clear of ash and debris.
Difficulty Lighting Fire	Insufficient kindling; damp fuel; poor air circulation.	Use ample dry kindling. Ensure wood is dry. Arrange wood to allow air to flow freely.
Fire Pit Not Heating Effectively	Insufficient fuel; poor quality fuel.	Add more dry wood or burn pellets. Ensure fuel is of good quality.
Discoloration of Stainless Steel	Normal heat patina.	This is a natural occurrence with stainless steel exposed to high heat and does not affect performance.

7. WARRANTY AND SUPPORT

OutVue is committed to providing high-quality products. We offer replacement parts for this product.

If you have any questions, require replacement parts, or experience any issues with your OutVue Smokeless Fire Pit, please contact our customer support team. Refer to your purchase documentation or the OutVue brand store on Amazon for contact information.

Please have your model number (ABCDEFGH) and purchase details ready when contacting support to ensure efficient service.