

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› **UPOSOJA** /

› UPOSOJA 5-Drawer Tall Black Dresser with LED Light and Power Outlet Instruction Manual

UPOSOJA 5-Drawer Tall Black Dresser (Model: B0DTP9NSGF)

UPOSOJA 5-Drawer Tall Black Dresser with LED Light and Power Outlet Instruction Manual

Model: 5-Drawer Tall Black Dresser (B0DTP9NSGF)

INTRODUCTION

Thank you for choosing the UPOSOJA 5-Drawer Tall Black Dresser. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The UPOSOJA 5-Drawer Tall Black Dresser, showcasing its modern design and LED lighting.

SAFETY INFORMATION

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury or damage.

- Keep all small parts and packaging materials away from children.
- Assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use.
- Use the included anti-tipping device to secure the dresser to a wall. This is crucial for preventing tip-over accidents, especially in households with children.
- Do not overload drawers. Distribute weight evenly.



Image: Close-up of the anti-dumping safety device, which must be installed to secure the dresser to a wall.

SETUP AND ASSEMBLY

The dresser requires assembly. Detailed instructions and numbered components are included to facilitate the process. It is recommended to have two people for assembly.

Components Overview



Image: Diagram showing the overall dimensions of the dresser (15.7"D x 27.6"W x 48.4"H) and individual drawer dimensions (14.2"D x 7.9"H).

Assembly Video Guide

For a visual guide on assembling your dresser, please refer to the official assembly video below:

Video: Official UPOSOJA assembly video for the Tall Black Dresser. This video provides step-by-step visual instructions for putting together the dresser components.

Key Assembly Steps (Refer to included manual for full details)

1. **Unpack and Identify:** Carefully unpack all components and hardware. Verify against the parts list in your physical manual.
2. **Assemble Frame:** Follow the numbered steps to construct the main frame of the dresser.
3. **Install Drawer Slides:** Attach the drawer slides to the dresser frame using the provided screws. Ensure they are level and aligned.
4. **Assemble Drawers:** Construct each drawer box, then attach the drawer fronts.
5. **Install LED Lights and Power Outlet:** Secure the LED light strip and the power outlet unit as per the instructions. Ensure all wiring is properly routed and secured.
6. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots.
7. **Secure Anti-Tipping Device:** Attach the anti-tipping device to the back of the dresser and to a wall stud using appropriate hardware.

OPERATING INSTRUCTIONS

LED Light Operation

The dresser is equipped with a multi-color RGB LED light strip. The color and brightness can be adjusted using the included buttons or a dedicated application (refer to the physical manual for app details).

- **Power On/Off:** Press the power button on the control unit to turn the lights on or off.
- **Color Selection:** Cycle through various colors using the color selection button or the app.
- **Brightness Adjustment:** Adjust the light intensity using the brightness controls.
- **Special Modes:** Explore features like music sync and timing modes via the application.



Smart LED Lights Strips Add entertainment to your private space



Over 60,000
Colors



Built-in
Mic



KEY / APP CONTROL



Music
Sync



Timing
Mode



Image: The dresser showcasing its smart LED light strips, capable of displaying over 60,000 colors and controlled via key or app.

Charging Station Usage

The sliding top storage area features a hidden charging station with 2 AC power sockets and 2 USB ports (including one Type-C port). This allows for convenient charging of electronic devices.

- **Access:** Slide the top panel of the dresser to reveal the charging station.
- **Connect Devices:** Plug in your laptop, mobile phone, or other small appliances.
- **Cable Management:** Utilize the integrated wire collector to keep cables tidy and prevent clutter.



Built-in ⚡ Charging Station

Floating Desktop & Hidden Storage & Wire Hub



125V / 12A
2 AC OUTLETS



5V / 2A
1 USB PORTS



5V / 2A
1 TYPE-C



6.5 Feet
POWER CORD

Image: The dresser's sliding top revealing a hidden charging station with AC outlets and USB ports, ideal for charging devices.

Drawer Operation

The five drawers are designed for smooth operation and ample storage. They feature a handle-free design for a sleek, modern look.

- **Opening/Closing:** Gently pull or push the drawer fronts to open and close. The upgraded rails support up to 45 lbs per drawer.
- **Storage:** Utilize the spacious interior for organizing clothes, accessories, or other personal items.



Ample Storage Space

5 large drawers to meet all your storage needs



Image: The dresser with its five large drawers partially open, demonstrating ample storage capacity for various items.

Product Overview Video

Watch a brief overview of the dresser's features and design:

Video: A short video showcasing the UPOSOJA Tall Black 5-Drawer Dresser in a home setting, highlighting its design and features.

MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Spills:** Immediately blot any spills with a clean, dry cloth to prevent staining or water damage.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.
- **LED Lights:** If the LED lights malfunction, check the power connection. Do not attempt to repair the LED strip yourself; contact customer support.

TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or loose screws.	Check the alignment of the drawer slides and tighten all screws. Ensure no obstructions are in the way.
LED lights are not working.	Power connection issue, faulty LED strip, or remote/app malfunction.	Verify the power cable is securely plugged in. Check the control unit. If issues persist, contact customer support.
Dresser feels unstable.	Loose assembly screws or anti-tipping device not installed/secured.	Retighten all assembly screws. Ensure the anti-tipping device is correctly installed and anchored to a wall stud.
Power outlets are not providing power.	Dresser not plugged into a wall outlet, or internal wiring issue.	Ensure the dresser's main power cord is plugged into a functional wall outlet. If still no power, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	UPOSOJA
Model Name	Dressers
Material	Engineered Wood
Finish Type	Engineered Wood
Product Dimensions (D x W x H)	15.7"D x 27.6"W x 48.38"H
Number of Drawers	5
Item Weight	93 Pounds
Color	Black
Style Name	Modern
Room Type	Bedroom
Mounting Type	Freestanding (with anti-tipping device)
Drawer Type	Sliding
Additional Features	LED Light Strip, Hidden Charging Station (2 AC, 2 USB), Sliding Top Storage, Anti-dumping safety device
Required Assembly	Yes

WARRANTY AND SUPPORT

Product Support

UPOSOJA offers professional customer service available within 24 hours. If you have any questions or problems regarding your dresser, please feel free to contact us. Refer to your purchase documentation for specific contact details.

Return Policy

This product is eligible for a 30-day easy return policy. Please consult the retailer's return policy for full details and conditions.

Extended Protection Plans

Optional 2-Year and 3-Year Protection Plans may be available for purchase separately. These plans provide extended coverage beyond the standard return period. Please check with your retailer for availability and terms.