CUISUNYO M3-0309

CUISUNYO 1500W Multi-Function Countertop Electric Induction Cooktop Instruction Manual

Model: M3-0309

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your CUISUNYO 1500W Multi-Function Countertop Electric Induction Cooktop, Model M3-0309.

1. Introduction

Thank you for choosing the CUISUNYO 1500W Multi-Function Countertop Electric Induction Cooktop. This versatile appliance is designed to enhance your cooking experience with its multiple functions and efficient heating. To ensure safe and optimal performance, please read this instruction manual thoroughly before using the product and retain it for future reference.

2. Safety Instructions

WARNING: To reduce the risk of fire, electric shock, injury to persons, or damage to the appliance, always follow basic safety precautions.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This infrared cooktop works by far infrared heating and has no electromagnetic radiation, making it flameless and safer for pregnant individuals and children.
- Features an automatic safety shutoff function with temperature regulated by a thermostat.

3. Product Overview

The CUISUNYO Multi-Function Cooktop is a versatile 1500W electric appliance designed for various cooking methods. It features a durable ceramic burner and comes with multiple accessories to expand your culinary options.

Included Components:

- Main Cooktop Unit (1500W, 120V)
- Skillet
- Grill Plate
- Griddle Plate
- Steaming Frame
- 6 Nonstick Plates

Key Features:

- **Multiple Cooking Ways:** Hot pot, indoor BBQ, steaming, frying, grilling.
- **Easy Operation:** 10 levels of power (200W to 1500W) for precise control.
- **Wide Cookware Compatibility:** Works with glass, copper, cast-iron, and aluminum pots and pans.
- **Powerful Heating:** 1500W for rapid heating.
- **Safe & Durable:** No radiation, flameless, automatic safety shutoff, metal body, durable ceramic burner.
- **Portable Design:** Lightweight for maximizing kitchen space and easy storage.



Figure 1: CUISUNYO 1500W Multi-Function Countertop Electric Induction Cooktop with various cooking plates and accessories.



Figure 2: The cooktop showcasing its versatility with different cooking plates for grilling, griddling, and steaming.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Check for any damage during transit. Do not use if damaged.
3. **Placement:** Place the main cooktop unit on a stable, flat, heat-resistant surface, away from flammable materials. Ensure adequate ventilation around the unit.
4. **Initial Cleaning:** Before first use, wipe all cooking plates and the main unit with a damp cloth. Dry thoroughly.
5. **Assemble:** Attach the desired cooking plate (skillet, grill, griddle, or steaming frame) onto the main cooktop unit.
6. **Power Connection:** Plug the power cord into a standard 120V electrical outlet.



Figure 3: An exploded view illustrating the main cooktop unit and its interchangeable cooking plates and accessories.

5. Operating Instructions

1. **Power On:** Ensure the cooktop is properly set up and plugged in. Turn the power knob to the desired setting.
2. **Select Power Level:** The cooktop offers 10 power levels, ranging from 200W to 1500W. Adjust the control knob to select the appropriate power level for your cooking needs.
3. **Cooking with Plates:**
    - **Skillet/Grill/Griddle:** Place your food directly on the nonstick surface of the chosen plate. Monitor cooking progress and adjust heat as needed.
    - **Steaming Frame:** Add water to the main unit, place the steaming frame, and then your food on the frame. Cover with a lid (if applicable) to steam.
4. **Cookware Compatibility:** The cooktop is compatible with various cookware materials including glass, copper, frying pans, cast-iron, and aluminum. Ensure the cookware size is suitable for the top glass plate.
5. **Timer Function:** Use the built-in timer feature for precise cooking durations. Refer to the specific controls on your unit for setting the timer.

6. **Power Off:** Once cooking is complete, turn the power knob to the "OFF" position and unplug the appliance from the wall outlet.



Figure 4: The cooktop actively grilling steak and vegetables, demonstrating its high heat capability.



Figure 5: Examples of diverse meals prepared on the cooktop, including grilled shrimp, steak, fish, and pancakes.



Figure 6: Illustration of the cooktop's compatibility with different types of cookware such as fry pans, stainless steel pots, ceramic pots, aluminum cookware, and glass cookware.



Figure 7: Detailed view of the CUISUNYO Cooktop's dimensions and the layout of its control panel, highlighting insulated handles, fast heat dissipation, and square heating area.

6. Cleaning and Maintenance

Proper cleaning and maintenance will ensure the longevity and optimal performance of your CUISUNYO Cooktop.

1. **Always Unplug:** Before cleaning, ensure the appliance is turned off and unplugged from the power outlet. Allow it to cool completely.
2. **Wipe Surfaces:** Wipe the main unit and control panel with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
3. **Cooking Plates:** The nonstick cooking plates (skillet, grill, griddle, steaming frame, and nonstick plates) are easy to clean. Wash them with warm, soapy water using a soft sponge. Rinse thoroughly and dry completely before storing or re-using.
4. **Avoid Immersion:** Never immerse the main cooktop unit in water or any other liquid.
5. **Storage:** Store the clean and dry appliance in a cool, dry place.

7. Troubleshooting

If you encounter any issues with your CUISUNYO Cooktop, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Cooktop is not heating.	Incorrect power level selected; cookware not compatible.	Adjust the power level. Ensure you are using compatible cookware.
Food is cooking unevenly.	Cookware not centered; uneven heat distribution.	Ensure cookware is centered on the heating zone. Stir or rotate food as needed.
Automatic shutoff activates frequently.	Overheating due to prolonged high heat or lack of food/liquid.	Reduce power level or ensure there is sufficient food/liquid in the cooking plate. Allow to cool if necessary.

If the problem persists after trying these solutions, please contact CUISUNYO customer support for assistance.

8. Specifications

Feature	Specification
Brand	CUISUNYO
Model Number	M3-0309
Wattage	1500W
Power Source	Electric (120V)
Controls Type	Push Button / Rotary Knob
Burner Type	Induction
Heating Elements	2
Product Dimensions	9.8"D x 11"W x 17"H
Material	Carbon Steel
Special Feature	Timer

9. Warranty and Support

CUISUNYO offers a **12-month warranty** on this product. This warranty covers manufacturing defects and malfunctions under normal use. Please note that all warranties are void for improper usage of the product.
If you have any questions, concerns, or require assistance with your CUISUNYO 1500W Multi-Function Countertop

Electric Induction Cooktop, please do not hesitate to contact our customer support team. We are committed to resolving any issues you may encounter and ensuring your satisfaction.
For support, please visit the CUISUNYO store on Amazon or refer to the contact information provided with your product packaging.

© 2025 CUISUNYO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question