

[manuals.plus](#) /

› [Exped](#) /

› [Exped MegaMat Medium Wide - Self Inflating Soft Car Sleeping Mat Instruction Manual](#)

Exped MegaMat

Exped MegaMat Medium Wide - Self Inflating Soft Car Sleeping Mat Instruction Manual

Model: MegaMat | Brand: Exped

INTRODUCTION

This manual provides essential instructions for the proper setup, operation, maintenance, and care of your Exped MegaMat Medium Wide self-inflating sleeping mat. Please read this manual thoroughly before using your mat to ensure optimal performance and longevity.






Image: Exped MegaMat Medium Wide sleeping mat, top view, showcasing its design and color.

IMPORTANT SAFETY INFORMATION

Always follow these instructions to prevent damage to the product or personal injury:

- Always follow the instructions for proper inflation and deflation to avoid damage or injury.
- Do not use this product if it is damaged or punctured.
- Keep away from heat sources and sharp objects.
- This product is not intended for use by children.
- Always ensure the product is properly inflated and deflated before use and storage.
- Do not leave the product inflated for extended periods.
- Always follow the weight and size limitations of the product for safe use.

INCLUDED COMPONENTS

Your Exped MegaMat Medium Wide package includes the following items:

- Exped MegaMat Medium Wide Sleeping Mat
- Top-Up Pump
- Temporary Repair Kit
- SideWinder Stuff Sack



Image: Key components and features of the Exped MegaMat, including the pump, valves, stuff sack, and handle.

SETUP INSTRUCTIONS

1. **Unpack the Mat:** Remove the MegaMat from its SideWinder stuff sack. Unroll the mat on a clean, flat surface where you intend to use it.
2. **Self-Inflation:** Locate the inflation valve(s) on the mat. Open the valve(s) and allow the mat to self-inflate. The open-cell foam inside will expand and draw air into the mat. This process may take several minutes, especially during the first few uses or if the mat has been stored compressed for a long time.

3. **Top-Up Inflation (Optional):** Once the mat has largely self-inflated, use the included Top-Up Pump to add additional air until your desired firmness is achieved. Connect the pump to the inflation valve and compress the pump to push air into the mat. Do not overinflate.
4. **Close Valves:** Once the desired firmness is reached, securely close the inflation valve(s) to prevent air from escaping.

MEGAMAT MW

FIRM • SOFT • PLUSH • LUXURY



With four inches of cored foam, MegaMat provides a soft sleep surface ideal for side sleepers. Dial in this self-inflating mat with the included Top-Up Pump.

Image: The Exped MegaMat during the self-inflation process, demonstrating its initial expansion.

OPERATING INSTRUCTIONS

Adjusting Firmness

The MegaMat allows for customizable comfort. You can adjust the firmness to your preference:

- **For a Firmer Surface:** Use the Top-Up Pump to add more air.
- **For a Softer Surface:** Gently press on the one-way inflate flapper within the inflation valve to release small amounts of air until the desired softness is achieved.

Deflation and Packing

1. **Open Deflation Valve:** Locate and open the deflation valve(s).
2. **Roll the Mat:** Begin rolling the mat tightly from the end opposite the valves. As you roll, the air will be expelled through the open deflation valve(s).
3. **Expel Remaining Air:** Once rolled, you can briefly open the inflation valve(s) to ensure all remaining air is expelled, then quickly close them before unrolling slightly and re-rolling for a tighter pack.
4. **Secure and Store:** Secure the rolled mat with any integrated straps or by placing it directly into the SideWinder stuff sack.



Image: A close-up of a hand pressing on the mat, illustrating its soft, comfortable surface, with the text 'Sleep Better with Exped'.

CARE AND MAINTENANCE

- **Cleaning:** Clean the mat with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Ensure

the mat is completely dry before storage.

- Storage:** For long-term storage, it is recommended to store the mat unrolled with valves open in a cool, dry place. This helps the foam maintain its loft and self-inflating properties. Avoid storing in direct sunlight or extreme temperatures.
- Repair Kit:** A temporary repair kit is included for minor punctures. Follow the instructions provided with the repair kit for proper application. For larger damage, contact Exped customer support.
- Avoid Sharp Objects:** Always place the mat on a surface free of sharp objects to prevent punctures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mat does not fully self-inflate.	Mat has been stored compressed for a long time; cold temperatures.	Allow more time for self-inflation. Use the Top-Up Pump to assist. Store unrolled with valves open when not in use.
Mat loses air during use.	Valve not fully closed; puncture in the mat.	Ensure valves are securely closed. Check for punctures and use the repair kit if necessary.
Difficulty rolling up the mat.	Air not fully expelled; incorrect rolling technique.	Ensure deflation valve(s) are fully open. Roll tightly from the end opposite the valves, kneeling on the mat as you roll to force air out.

SPECIFICATIONS

Feature	Detail
Model Name	MegaMat
Size	Medium Wide
Product Dimensions	72"L x 25.6"W x 4"Th
Item Weight	4.56 pounds
R-Value	8.1
Special Features	3D vertical sidewalls (no tapering) for optimal sleeping surface area, Self-Inflating
Top Material Type	Recycled 50 D tricot polyester, TPU polyether film laminate, honeycomb embossed, Oeko-Tex® 100 certified
Color	Cypress
Specific Uses	Car Camping
Item Firmness Description	Firm, Plush (adjustable)
Water Resistance Level	Not Water Resistant

SPECIFICATIONS

EXPED

R-Value: 8.1	Temperature: -40 °F
Dimensions MW: 72 x 25.6 x 4 in LW: 77.6 x 25.6 x 4 in LXW: 77.6 x 30.3 x 4 in	Weight MW: 73 oz 4 lbs 9 oz LW: 80.2 oz 5 lbs LXW: 91.7 oz 5 lbs 12 oz
Packed Dimensions MW: 26.5 x 7.9 in LW: 26.4 x 8.7 in LXW: 31.1 x 9.8 in	Includes Sleeping mat, Top-Up Pump, temporary repair kit, SideWinder stuff sack

Image: Detailed specifications table for the MegaMat series, including dimensions and weight.

WARRANTY AND SUPPORT



Information regarding the product warranty and customer support details is not available in the provided data. Please refer to the official Exped website or contact your retailer for specific warranty terms and support options.

PRODUCT VIDEOS

No official product videos from the seller were found in the provided data.



Related Documents - MegaMat

	<p>EXPED Orion Extreme & UL Tent: Setup, Teardown, and Care Guide</p> <p>Comprehensive instructions for setting up, taking down, and maintaining your EXPED Orion Extreme and Orion UL tents. Includes tips for optimal performance and longevity.</p>
	<p>Exped Lyra Extreme Tent Instructions and Tips</p> <p>Comprehensive guide for setting up, tearing down, and maintaining the Exped Lyra Extreme tent, including tips for optimal use and care.</p>
	<p>Exped Sleeping Mat Size Guide</p> <p>Find the perfect fit with the Exped sleeping mat size guide. Compare dimensions for all rectangular and mummy mat models, including S, M, MW, LW, LXW, DUO M, DUO LW, DUO LW+, and DUO Queen sizes in both centimeters and inches.</p>
	<p>Exped Ultra Dry Bag Specifications</p> <p>Detailed specifications including weight and dimensions for Exped Ultra Dry Bags of various liter sizes.</p>
	<p>Exped Vista Organizer Size and Weight Specifications</p> <p>Detailed specifications for Exped Vista Organizer sizes including weight and dimensions for Mini, A6, A5, and A4 formats.</p>
	<p>Exped Versa Stuffbag Specifications and Dimensions</p> <p>Detailed specifications and dimensions for the Exped Versa Stuffbag, including weight and size variations for different capacities.</p>