

[Manuals.plus](#) /

› [Dark Project](#) /

› Dark Project SONO Wireless Gaming Headset Instruction Manual

Dark Project SONO Wireless

Dark Project SONO Wireless Gaming Headset Instruction Manual

Model: SONO Wireless

1. INTRODUCTION

The Dark Project SONO Wireless Gaming Headset is engineered to deliver high-quality audio for gaming, entertainment, and communication. Featuring 53mm neodymium drivers and versatile connectivity options, this headset provides a comfortable and immersive audio experience across multiple platforms.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Dark Project SONO Wireless Gaming Headset
- Detachable Omnidirectional Microphone
- USB-A Charging/Data Cable (1.5m)
- 2.4 GHz Wireless USB Dongle
- User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Dark Project SONO Wireless Gaming Headset.



Figure 3.1: Front-left view of the Dark Project SONO Wireless Gaming Headset with the detachable microphone connected.



Figure 3.2: Side view of the headset, highlighting the control buttons located on the ear cup, including volume and mode selection.



Figure 3.3: Interior view of the earcups, showing the soft padding and the 'L' indicator for the left ear.

4. SETUP

4.1. Charging the Headset

Before initial use, fully charge the headset. Connect the supplied USB-A cable to the headset's charging port and to a powered USB port (e.g., computer, wall adapter). The charging indicator light will show the charging status and turn off or change color when fully charged. A full charge provides up to 25 hours of usage.

4.2. Attaching the Microphone

Insert the detachable omnidirectional microphone into the designated port on the left earcup until it clicks securely into place. Ensure the microphone is oriented correctly for optimal voice pickup.

4.3. Connectivity Options

The SONO headset supports three connectivity modes:

- **2.4 GHz Wireless (USB Dongle):** For low-latency wireless connection to PCs, PlayStation (PS4/PS5), Xbox, and Nintendo Switch.
- **Bluetooth 5.3:** For wireless connection to smartphones, tablets, and other Bluetooth-enabled devices.
- **USB-A Wired:** For direct wired connection to compatible devices, also used for charging.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

To power on the headset, press and hold the Power button for approximately 3 seconds. An indicator light will illuminate. To power off, press and hold the Power button again for 3 seconds until the indicator light turns off.

5.2. 2.4 GHz Wireless Connection

1. Plug the 2.4 GHz USB dongle into an available USB port on your PC, console, or compatible device.
2. Power on the headset.
3. The headset should automatically connect to the dongle. The indicator light will show a stable connection.
4. Ensure the headset is selected as the audio input/output device in your device's sound settings.

5.3. Bluetooth Connection

1. Power on the headset.
2. Press and hold the Mode button (or a dedicated Bluetooth button, refer to product diagram) for 5 seconds to enter Bluetooth pairing mode. The indicator light will flash rapidly.
3. On your smartphone, tablet, or Bluetooth-enabled device, go to Bluetooth settings and search for new devices.
4. Select "Dark Project SONO" from the list of available devices.
5. Once paired, the indicator light on the headset will become stable.

5.4. Wired USB-A Connection

Connect the USB-A cable directly from the headset to a USB-A port on your computer or compatible device. The headset will function as a wired audio device and charge simultaneously.

5.5. Volume Control

Use the volume control wheel or buttons on the headset's earcup to adjust the audio output level.

5.6. Microphone Mute

A dedicated mute button for the microphone is located on the headset. Press it to toggle the microphone on or off. An indicator light on the microphone or headset may show its mute status.

6. MAINTENANCE

6.1. Cleaning

- Wipe the headset surfaces with a soft, dry, lint-free cloth.
- For stubborn dirt, lightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- Do not immerse the headset in water or any liquids.
- Clean the earcup cushions gently.

6.2. Storage

When not in use, store the headset in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the headset.

7. TROUBLESHOOTING

If you encounter issues with your headset, refer to the following common solutions:

- **No Sound:**
 - Ensure the headset is powered on and charged.
 - Check volume levels on both the headset and the connected device.
 - Verify the correct audio output device is selected in your computer/console settings.
 - For wireless connections, ensure the headset is properly paired/connected to the dongle or via Bluetooth.
- **Microphone Not Working:**
 - Ensure the microphone is securely attached and not muted.
 - Check microphone input settings on your connected device.
 - Test the microphone in a different application or device.
- **Connection Issues (2.4 GHz/Bluetooth):**
 - Ensure the headset is within range of the dongle or Bluetooth device.
 - Re-pair the headset (for Bluetooth) or re-insert the dongle (for 2.4 GHz).
 - Avoid interference from other wireless devices.
- **Headset Not Charging:**
 - Verify the charging cable is securely connected to both the headset and a powered USB port.
 - Try a different USB port or charging cable.

8. SPECIFICATIONS

Feature	Specification
Model Name	SONO Wireless
Connectivity Technology	Wireless (2.4 GHz RF, Bluetooth 5.3), Wired (USB-A)
Driver Size	53 mm Neodymium
Headphone Frequency Response	20 Hz - 20,000 Hz
Impedance	22 Ohms
Sensitivity	98 dB
Microphone Type	Detachable Omnidirectional
Microphone Frequency Response	100 Hz - 10 kHz
Cable Length	1.5 m (braided USB-A)
Battery Life	Up to 25 hours
Weight	370 g
Materials	Acrylonitrile Butadiene Styrene (ABS), Aluminum, Polyurethane (PU)

Compatible Devices	PC, Game Console (Xbox, PS4/PS5, Nintendo Switch), Laptop, Tablet, Mobile Phone
--------------------	---

9. WARRANTY INFORMATION

Specific warranty details are not available in the provided product information. Please refer to the official Dark Project website or contact your retailer for comprehensive warranty terms and conditions.

10. SUPPORT

For further assistance, technical support, or inquiries not covered in this manual, please visit the official Dark Project support website or contact their customer service department. Contact information can typically be found on the manufacturer's website or product packaging.