

[Manuals.plus](#) /

› [Yeego](#) /

› Yeego 20 Bottle Wine Cooler Refrigerator Instruction Manual

Yeego YG-WSJC62-25

Yeego 20 Bottle Wine Cooler Refrigerator Instruction Manual

Model: YG-WSJC62-25

INTRODUCTION

Thank you for choosing the Yeego 20 Bottle Wine Cooler Refrigerator. This appliance is designed to provide an optimal environment for storing your wine, ensuring its flavor and quality are preserved. Featuring a compressor cooling system, digital temperature control, and a double-layer glass door, this wine cooler offers reliable performance and ease of use. Please read this manual thoroughly before installation and operation to ensure proper use and maintenance.

SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch cold surfaces immediately after plugging in the unit.
- Ensure the appliance is properly grounded.
- Do not operate the appliance with a damaged cord or plug.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Yeego Wine Cooler Refrigerator
- 4 x Wire Shelves
- 1 x Instruction Manual

SETUP

Unpacking and Placement

Carefully remove all packaging materials. This wine cooler is designed for freestanding or under-counter placement. It is not recommended for built-in installation. Ensure adequate ventilation around the unit. Allow at least 2-3 inches of space on the sides and back for proper air circulation. Place the unit on a flat, stable surface away from direct sunlight and heat sources.



Image: The Yeego 20 Bottle Wine Cooler Refrigerator, showcasing its sleek design and compact size suitable for various placements.

Leveling the Appliance

The wine cooler is equipped with adjustable feet. Use a level to ensure the appliance is perfectly level. Adjust the feet by turning them clockwise or counter-clockwise until the unit is stable and level. Proper leveling is crucial for efficient operation and to prevent vibrations.

Initial Power-On

After placing the unit, allow it to stand upright for 24-36 hours before plugging it into a power outlet. This allows the refrigerant to settle, optimizing cooling performance and preventing damage to the compressor.

Handle Installation (if applicable)

If your model requires handle installation, align the handle with the pre-drilled holes on the door. You may need to gently push aside or temporarily remove the door gasket to access the screw holes. Secure the handle with the provided screws. Ensure the gasket is properly seated after installation to maintain a secure seal.




Image: Detailed product dimensions (16.96"W x 18.93"D x 25.62"H) for proper placement and installation planning.

OPERATING INSTRUCTIONS

Control Panel Overview

The wine cooler features an intuitive digital touch control panel located on the door frame, allowing temperature adjustments without opening the door.



Image: Close-up of the external touch control panel, showing the light-on/off button, temperature unit switch, temperature display, and temperature adjustment buttons.

Temperature Adjustment

Use the "+" and "-" buttons on the control panel to set your desired temperature. The temperature range is 38-65°F (3-18°C). Each press adjusts the temperature by 1°F. The digital display will show the set temperature, then revert to the actual internal temperature.

Temperature Unit Switch

Press the "°F/°C" button to switch the temperature display between Fahrenheit and Celsius.

LED Light Control

Press the light bulb icon button to turn the internal soft blue LED light on or off. This light provides ambiance and visibility without affecting wine quality.

No Worries Just Simplicity

Intuitive design for easy operation




Image: The wine cooler interior illuminated by soft blue LED lighting, highlighting bottles on the shelves.

Electronic Safety Lock

The control panel features an electronic safety lock to prevent accidental temperature changes. The panel will automatically lock after 12 seconds of inactivity. To unlock, press and hold the "+" and "-" buttons simultaneously for 5 seconds.

Power Failure Memory

In the event of a power outage, the wine cooler's power failure memory function will restore the previous temperature setting once power is re-established, preventing wine flavor changes due to temperature fluctuations.

Shelf Adjustment and Bottle Storage

The wine cooler includes 4 removable wire shelves. These shelves can be adjusted or removed to accommodate various

bottle sizes and quantities. The unit can store at least 20 standard 750ml Bordeaux bottles. For optimal storage, ensure bottles are placed securely to prevent rolling.

External Touch Panel

Internal temperature maintained between 38°F–65°F via smart touch panel.

Tips : 12s Automatic Lock, Press "+" & "-" at the Same Time, Press for 5s to Unlock!

LED Light Switch

Temp Unit Switch

Temperature Display

Temperature Control (38°F–65°F)

Image: The interior of the wine cooler displaying its large capacity and adjustable wire shelves, designed to fit multiple wine bottle sizes.

Secure Delivery · Reliable Support

Safe Delivery · Palletized Protection
Dedicated truck service, one-on-one handover, guaranteed safe arrival

Professional Support · Expert Guidance
Get answers on use and maintenance anytime

Image: Detail of the strengthened wire shelves, providing stable support for each bottle and allowing for flexible arrangement.

MAINTENANCE

Cleaning the Wine Cooler

Regular cleaning helps maintain the appearance and efficiency of your wine cooler. Unplug the unit before cleaning.

- **Interior:** Clean the interior with a soft cloth dampened with a solution of baking soda and warm water (2 tablespoons baking soda to 1 quart water). Rinse thoroughly and dry.
- **Exterior:** Wipe the exterior surfaces with a soft cloth and mild detergent. For the glass door, use a glass cleaner. Avoid abrasive cleaners or solvents.
- **Door Gasket:** Clean the door gasket regularly to ensure a tight seal.
- **Shelves:** Remove and clean the wire shelves with mild soap and water, then dry completely before returning them to the unit.

Manual Defrosting

This appliance features a manual defrost system. Frost buildup can occur over time, especially in humid environments.

When frost accumulation exceeds 1/4 inch (0.6 cm), the unit should be defrosted.

1. Unplug the wine cooler from the power outlet.
2. Remove all bottles and shelves.
3. Leave the door open to allow frost to melt naturally. Place towels at the bottom to absorb water. Do not use sharp objects or heating devices to speed up defrosting.
4. Once defrosted, clean and dry the interior thoroughly.
5. Plug the unit back in and allow it to reach the desired temperature before reloading bottles.

TROUBLESHOOTING

Before contacting customer support, review this section for potential solutions to common issues.

Problem	Possible Cause	Solution
Appliance does not operate	Not plugged in; circuit breaker tripped; power switch off.	Ensure plug is secure; check circuit breaker; turn power switch on.
Temperature is not cold enough	Door not closed properly; excessive door openings; warm items added; poor ventilation; unit placed near heat source; temperature setting too high.	Check door seal; reduce door openings; allow time for new items to cool; ensure proper clearance; relocate unit; lower temperature setting.
Excessive vibration	Appliance not level.	Adjust leveling feet.
Noise from unit	Normal compressor operation; fan noise; bottles rattling.	This is normal; ensure bottles are stable on shelves.
Door does not close properly	Appliance not level; gasket dirty or damaged; shelves out of position.	Level the unit; clean or replace gasket; reposition shelves.

SPECIFICATIONS

Key technical details for your Yeego Wine Cooler Refrigerator:

Feature	Detail
Model Number	YG-WSJC62-25
Capacity	20 Bottles (750ml Bordeaux standard) / 2.19 Cubic Feet
Temperature Range	38-65°F (3-18°C)
Cooling Method	Compressor
Installation Type	Freestanding
Product Dimensions (D x W x H)	18.93" x 16.96" x 25.62"
Number of Shelves	4 (Wire, Removable)
Door Type	Double-layer UV-Resistant Glass

Feature	Detail
Defrost System	Manual Defrost
Voltage	115 Volts
Special Features	Digital Temperature Control, Low Noise, Electronic Safety Lock, Touch Control, Adjustable Feet

WARRANTY AND SUPPORT

Your Yeego 20 Bottle Wine Cooler Refrigerator is covered by a **1-Year Manufacturer Warranty**. The compressor is covered by a **3-Year Warranty**. For any questions regarding installation, operation, maintenance, or troubleshooting, our support team is available 24/7 to assist you. Please refer to the contact information provided with your purchase or visit the official Yeego website for assistance.

Your browser does not support the video tag.

Video: Official video demonstrating the direct cooling system and features of the Yeego Wine Cooler, including its design and functionality.