

[Manuals.plus](#) /

› [T4TREAM](#) /

› T4TREAM 32" Tall Fluted Nightstand (Model FPSC3DRDS-NO) Instruction Manual

T4TREAM FPSC3DRDS-NO

T4TREAM 32" Tall Fluted Nightstand (Model FPSC3DRDS-NO) Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your T4TREAM 32" Tall Fluted Nightstand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: Two T4TREAM 32-inch tall fluted nightstands, showcasing their design and finish.

SAFETY INFORMATION

For your safety and to prevent damage to the product, observe the following:

- Always follow the assembly instructions carefully.
- Use caution when handling components to avoid injury.
- Ensure the nightstand is properly assembled and stable before use.
- Keep the nightstand away from direct heat sources.
- Do not place excessively heavy objects on the tabletop that could compromise stability or cause tipping.
- Utilize the included wall anchor to secure the nightstand to a wall, preventing accidental tipping, especially in households with children or pets.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Assembly Guide
- Feet metal plates
- Hardware (screws, dowels, etc.)
- Repair stickers
- Wall anchor kit

SETUP AND ASSEMBLY

Assembly is designed to be straightforward. Each component is labeled with a serial number for easy identification. A pack of spare hardware is included in case of loss during assembly. Two adults are recommended for efficient assembly.

Recommended Tools:

- Hammer
- Screwdriver (Phillips head recommended)

Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the provided labels and the assembly guide.
3. Follow the step-by-step instructions in the assembly guide to connect the panels and frame.
4. Install the drawer slides and assemble the three drawers.
5. Attach the splayed legs and the steel support at the base for enhanced stability.
6. Carefully place the faux marble top onto the assembled frame.
7. Secure the nightstand to the wall using the provided wall anchor kit to prevent tipping.

Faux Marble Top Design

Elegant, waterproof and easy to clean



Wear-Resistant



Waterproof



Image: Dimensional diagram of the nightstand, including overall size and drawer measurements.



☒ **Stable Support Legs**



☒ **Bottom Reinforced with Steel**

Image: Details of the nightstand's construction, including fluted panels, metal handles, and steel-reinforced legs.

OPERATING INSTRUCTIONS

Your T4TREAM nightstand is designed for versatile use and efficient storage.

Using the Drawers:

- The nightstand features three smooth-glide drawers. Pull the chic metal handles to open and push to close.
- These drawers are suitable for storing clothing, bedding, cosmetics, jewelry, and other personal items, helping to keep your space organized.

Using the Tabletop:

- The spacious faux marble tabletop provides a surface for lamps, framed photos, decorative accents, or personal devices.
- The smooth curved edge of the tabletop enhances safety.

32" Wide with 3 Spacious Drawers

Save space and organize efficiently

Smooth Curved Edge

Wide Thickened Tabletop

Smooth Sliding Drawers

Image: View of the nightstand's tabletop and an open drawer, highlighting its smooth operation and design features.

CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your nightstand.

Cleaning:

- The faux marble top is made of melamine veneer, which is water-resistant and easy to maintain. Wipe spills immediately with a soft, dry cloth.
- For general cleaning, use a soft, damp cloth with a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the finish.
- Dust the wood surfaces regularly with a soft, dry cloth.

General Care:

- Avoid placing hot items directly on the faux marble top; use coasters or protective pads.
- Protect the surface from sharp objects to prevent scratches.
- Periodically check all hardware and tighten if necessary to maintain stability.

Dimensions

☑ Overall: 32" W × 16" D × 32" H

☑ Packaging Dimensions & Weight: 37" × 20" × 10", 80 lbs




Image: Detail of the faux marble top, emphasizing its wear-resistant and waterproof properties.

TROUBLESHOOTING

If you encounter any issues with your nightstand, refer to the following common solutions:

- **Wobbly Nightstand:** Ensure all screws and fasteners are securely tightened. Check that the nightstand is on a level surface. Adjust the feet metal plates if necessary.
- **Drawers Not Sliding Smoothly:** Verify that the drawer slides are correctly installed and free from obstructions. Ensure the drawers are not overloaded.
- **Missing or Damaged Parts:** If you find any parts missing or damaged upon arrival, please contact customer support immediately.

For issues not resolved by these steps, please contact T4TREAM customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	T4TREAM
Model Name	FPSC3DRDS-NO
Product Dimensions (D x W x H)	16"D x 32"W x 32"H
Color	Natural Oak
Shape	Rectangular
Table Design	Nightstand
Style Name	Modern
Furniture Finish	Oak
Top Color	White/Cream (Faux Marble)
Number of Drawers	3
Frame Material Type	Engineered Wood
Top Material Type	Faux Marble (Melamine Veneer)
Handle Material	Metal
Base Type	Legs (Splayed)
Is Stain Resistant	Yes
Indoor Outdoor Usage	Indoor
Global Trade Identification Number (GTIN)	00850076290450

WARRANTY INFORMATION

T4TREAM products are manufactured to high-quality standards. For specific warranty details regarding your 32" Tall Fluted Nightstand, please refer to the warranty card included with your purchase or contact T4TREAM customer support directly. Warranty terms typically cover manufacturing defects under normal use.

CUSTOMER SUPPORT

Should you have any questions, require assistance with assembly, or need to report missing/damaged parts, please do not hesitate to contact T4TREAM customer support. We are committed to assisting you.

Please have your model number (FPSC3DRDS-NO) and purchase information ready when contacting support to ensure efficient service.

Contact information can typically be found on the packaging, the assembly guide, or the official T4TREAM website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

I am on step 12 of the T4TREAM FPSC3DRDS-NO nightstand assembly; where are the screw holes for parts M and N?

For the T4TREAM FPSC3DRDS-NO nightstand, step 12 typically involves attaching the drawer slides or the back panels. If you cannot see pre-drilled screw holes for parts M or N, please check the following: Check...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0DTTVQC8T>

More documents and user manuals: <https://manuals.plus/>