

SENCHO GINSY TALIOR JSL-SWST-1

SENCHO GINSY TALIOR 5-in-1 Heavy-Duty Metal Playset Instruction Manual

MODEL: JSL-SWST-1

Introduction

This manual provides essential instructions for the safe assembly, operation, and maintenance of your SENCHO GINSY TALIOR 5-in-1 Heavy-Duty Metal Playset, Model JSL-SWST-1. This outdoor playset is designed to offer multiple activities for children, including a saucer swing, a belt swing, a slide, soccer goals, and a basketball hoop. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

Safety Information

- **Adult Supervision Required:** Always ensure children are supervised by an adult while using the playset.
- **Weight Capacity:** The playset supports a total weight of up to 440 lbs. Only up to 2 children should use the swings simultaneously, with each child's maximum weight not exceeding 220 lbs.
- **Age Recommendation:** Suitable for children aged 6 years (72 months) and older.
- **Secure Installation:** The playset must be firmly anchored to the ground using the provided ground anchors to prevent tipping and ensure stability.
- **Clearance Area:** Ensure adequate clear space around the playset, free from obstacles such as fences, trees, or other structures.
- **Regular Inspection:** Before each use, inspect all components for wear, damage, or loose connections. Tighten all bolts and check ropes for fraying.
- **Protective Covers:** Ensure all screw and bolt protective covers are in place to prevent scratches or injuries.
- **Weather Conditions:** Do not use the playset during severe weather conditions (e.g., strong winds, heavy rain, snow).


Components Overview

The SENCHO GINSYTALIOR 5-in-1 Playset includes the following main components:

- Main Metal Frame (Alloy Steel, Powder Coated)
- Saucer Swing (39-inch, Oxford Fabric)
- Belt Swing (PE Material)
- Slide (Double-Walled Plastic)
- Soccer Goal Net with Scoring Targets
- Basketball Hoop with Backboard
- Ground Anchors (7 pieces)
- Inflatable Football and Basketball with Pump




Soccer Goals



Saucer Swing


5 IN 1 SWING SETS MEET KIDS' DIFFERENT ENTERTAINMENT NEEDS



Belt Swing



Basketball Hoop



Slide

Figure 1: Overview of the 5-in-1 Playset Components.

Setup and Assembly

Assembly of the playset requires two adults and approximately 3-4 hours. All parts are labeled and pre-drilled for convenience. Follow the detailed step-by-step instructions provided in the separate assembly

manual included with your product. Ensure all connections are secure before proceeding to the next step.

1. **Unpack and Verify:** Carefully unpack all components and verify against the parts list in your assembly manual.
2. **Frame Assembly:** Assemble the main A-frame structure and horizontal bar using the provided hardware. Ensure all bolts are tightened securely.
3. **Attach Swings:** Connect the saucer swing and belt swing to the designated hangers on the main bar. Adjust rope lengths as needed.
4. **Install Slide:** Attach the slide to the frame according to the assembly manual. Ensure it is stable and securely fastened.
5. **Mount Soccer Goal and Basketball Hoop:** Secure the soccer goal net and basketball hoop to the frame. Note that the basketball hoop may require additional securing beyond standard bolts for optimal stability.
6. **Ground Anchoring:** Once the playset is fully assembled, position it on a level surface. Install all 7 ground anchors firmly into the ground to prevent movement and enhance stability.



Figure 2: Key structural features for a heavy-duty and safe swing set.

This playset offers five distinct play activities:

- **Saucer Swing:** The 39-inch saucer swing features wear-resistant and weather-resistant oxford fabric. Its braided ropes are adjustable to accommodate different child heights.
- **Belt Swing:** Made from durable, impact-resistant PE material with a thickened design and 3D non-slip pattern for safety. The braided ropes are also adjustable.
- **Slide:** Constructed from double-walled plastic for durability, offering a smooth and waterproof surface. Features a secure structure and metal ladder for climbing.
- **Soccer Goals:** The unique soccer net includes three scoring goals (marked 10 and 20 points) to enhance game play and encourage sportsmanship. An inflatable football is included.
- **Basketball Hoop:** Integrated with the playset, this hoop provides an opportunity for children to practice basketball skills and exercise jumping ability. An inflatable basketball is included.



Figure 3: Adjustable swing ropes and integrated sports features.

Maintenance

Regular maintenance is crucial for the longevity and safety of your playset:

- **Cleaning:** Clean the playset regularly with mild soap and water. Avoid abrasive cleaners that could

damage the finish or materials.

- **Frame Inspection:** Periodically check the metal frame for any signs of rust, dents, or structural damage. The frame is covered with rust-resistant painting, but prolonged exposure to harsh weather can cause wear.
- **Hardware Check:** Regularly inspect all bolts, nuts, and connections. Tighten any loose hardware to maintain structural integrity.
- **Swing Ropes and Seats:** Examine swing ropes for fraying, cuts, or excessive wear. Check swing seats (saucer and belt) for tears, cracks, or degradation. Replace damaged components immediately.
- **Slide Surface:** Ensure the slide surface remains smooth and free of cracks or sharp edges.
- **Ground Anchors:** Verify that all ground anchors remain securely embedded in the ground. Re-secure if any appear loose.
- **Protective Covers:** Ensure all silicone protective covers on screws are intact.

Troubleshooting

- **Playset Feels Wobbly:**

Solution: Ensure all ground anchors are fully inserted and secure. Re-tighten all bolts and connections on the main frame. Verify the playset is on a level surface.

- **Basketball Hoop Net Not Secure:**

Solution: The assembly instructions may not fully detail net attachment. Use durable string or zip ties to securely fasten the net to the hoop.

- **Swing Ropes or Seats Show Wear:**

Solution: Discontinue use of the affected swing immediately. Inspect for damage and replace worn or damaged ropes/seats with manufacturer-approved parts.

- **Slide Appears Loose:**

Solution: Check all attachment points of the slide to the main frame. Tighten any loose bolts or fasteners.

Specifications

Feature	Detail
Brand	SENCHO GINSYTALIOR
Model Number	JSL-SWST-1
Product Dimensions	68"D x 136"W x 75"H
Frame Material	Alloy Steel
Finish Type	Powder Coated (Frame), Fabric (Saucer Swing), PE (Belt Swing)
Item Weight	60 pounds
Maximum Weight Capacity	440 lbs (Total), 220 lbs (Per Child on Swing)
Manufacturer Minimum Age	72 Months
Color	Yellow Blue

PRODUCT SIZE



Figure 4: Product Dimensions and Weight Capacity.

Customer Support

If you have any questions regarding the assembly, operation, or maintenance of your SENCHO GINSYALIOR playset, please contact our customer support team. We are committed to providing a satisfactory solution within 24 hours.

For further assistance, please refer to the contact information provided with your purchase documentation.