Oakley OX 8105

Oakley OX8105 PITCHMAN R Eyeglasses Bundle Instruction Manual

Introduction

Welcome to the instruction manual for your Oakley OX8105 PITCHMAN R Eyeglasses Bundle. This guide provides essential information on the proper setup, operation, maintenance, and care of your new eyeglasses and the accompanying universal anti-slip silicone leash. Please read this manual thoroughly to ensure optimal use and longevity of your product.

Product Overview

The Oakley OX8105 PITCHMAN R eyeglasses feature a lightweight frame design for all-day comfort, suitable for everyday wear. This bundle includes a universal anti-slip silicone leash designed to secure your eyeglasses during various activities.



This image displays the Oakley OX8105 PITCHMAN R eyeglasses in a polished translucent ginger frame, accompanied by the universal anti-slip silicone leash. The eyeglasses feature a modern, lightweight design, and the leash is designed to secure them during wear.

Setup Instructions

Attaching the Anti-slip Silicone Leash

1. Gently slide one end loop of the silicone leash over the temple tip of one arm of your Oakley eyeglasses.
2. Ensure the loop is securely fitted around the temple tip, providing a snug but not overly tight grip.
3. Repeat the process for the other end loop on the opposite temple tip.
4. Adjust the leash so that it hangs comfortably behind your neck when the eyeglasses are worn.



This image shows a close-up of the universal anti-slip silicone leash. The leash features two end loops designed to securely fit over the temples of your eyeglasses, preventing accidental drops.

Operating Your Eyeglasses

Wearing the Eyeglasses

Place the eyeglasses on your face, ensuring the nose pads rest comfortably on your nose bridge and the temple arms extend over your ears. The lightweight design is intended for all-day comfort.

Using the Anti-slip Silicone Leash

Once attached, the silicone leash will rest around your neck. If you remove your eyeglasses, the leash will prevent them from falling to the ground, keeping them secure and accessible. This is particularly useful during outdoor activities or when frequently taking your eyeglasses on and off.

Care and Maintenance

Cleaning the Lenses and Frame

- Use a clean microfiber cloth specifically designed for eyewear to gently wipe the lenses.
- For stubborn smudges, use a specialized lens cleaning spray or mild soap and water. Rinse thoroughly with clean water and dry with a microfiber cloth.
- Avoid using paper towels, clothing, or harsh chemicals, as these can scratch the lenses or damage the frame finish.
- Clean the frame and silicone leash with a damp cloth and mild soap if necessary, then rinse and dry.

Storage

When not in use, store your Oakley eyeglasses in the protective carrying case provided. This protects them from scratches, dust, and accidental damage. Avoid leaving eyeglasses in direct sunlight or extreme temperatures, such as on a car dashboard, as this can cause damage to the frame and lenses.

Troubleshooting

Common Issues

- **Loose Fit:** If your eyeglasses feel loose, a qualified optician can adjust the frame for a more secure fit.
- **Dirty Lenses:** Refer to the 'Cleaning the Lenses and Frame' section for proper cleaning techniques.
- **Leash Not Secure:** Ensure the silicone loops are fully seated over the temple tips. If the leash feels too loose, it may not be correctly attached or may require replacement.

Product Specifications

Feature	Detail
Product Dimensions	6 x 2 x 2 inches; 12 ounces
Item Model Number	OX 8105
Department	Men
Date First Available	January 22, 2025
Manufacturer	Luxottica Group S.p.A.
ASIN	B0DTVNGYZD
Origin	Made in the USA or Imported

Warranty and Customer Support

Your Oakley OX8105 PITCHMAN R Eyeglasses are manufactured by Luxottica Group S.p.A. For specific warranty information, please refer to the documentation included with your purchase or visit the official Oakley website. For customer support, including inquiries about repairs or replacements, please contact Oakley's authorized customer service channels.

© 2025 Oakley. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question