

Yaheetech 615154

Yaheetech 10x10 Pop-up Canopy Tent Instruction Manual

Model: 615154

1. PRODUCT OVERVIEW

The Yaheetech 10x10 Pop-up Canopy Tent is designed for versatile outdoor use, providing 100 square feet of shade. It features a convenient multifunctional sidewall with storage pockets and a hanging strap. The canopy is constructed with water-resistant 150D Oxford fabric and a powder-coated steel frame for durability and all-weather protection.

This pop-up tent is ideal for various outdoor activities such as backyard barbecues, beach parties, camping trips, and street stalls, comfortably accommodating up to ten people.



Image: The Yaheetech 10x10 Pop-up Canopy Tent set up outdoors, providing shade for two people seated at a table. The blue canopy top and white sidewalls are visible, with storage pockets on the sidewall.

2. SETUP INSTRUCTIONS

The Yaheetech Pop-up Canopy Tent features an effortless one-person setup thanks to its innovative push-to-lock mechanism. Follow these steps for quick assembly:

1. Remove the canopy frame from the wheeled carry bag.
2. Partially open the frame and drape the canopy fabric over the top, aligning the four corners.
3. Push the center knob upwards until it locks into place, securing the canopy top.
4. Extend each leg to the desired height and lock it using the adjustable height flexibility mechanism.
5. Attach the multifunctional sidewall using the Velcro straps and tie strips as needed.
6. Secure the tent to the ground using the provided guy lines and eight robust ground anchors. For added stability, fill the four sandbags with sand and attach them to the canopy legs.



Secure Straps for Enhanced Stability:
Boosts wind resistance and prevents water buildup



Effortless One-Push Setup:
Offers quick and easy assembly.



Adjustable Height Flexibility:
Provides customization without being limited by preset holes.



Durable Canopy Fabric:
Coated with UV protection for lasting durability.

Image: A detailed view of the canopy's features, highlighting secure straps for stability, the effortless one-push setup mechanism, adjustable height flexibility, and the durable canopy fabric with UV protection.

Setup Video Guide

Video: This video demonstrates the step-by-step process of setting up the Yaheetech Pop-up Canopy Tent, including extending the frame, attaching the canopy top, and securing the legs and sidewalls.

3. OPERATING INSTRUCTIONS

Once set up, your Yaheetech canopy tent provides a comfortable and protected space. The versatile sidewall can be installed on any side to block sunlight, wind, or for privacy. Utilize the nine varied-sized pockets and hanging strap on the sidewall for convenient storage of small items, rackets, or volleyballs.

Versatile Sidewall w/ Pockets

Ample Extra Storage Space with 9 Varied-Sized Pockets



Image: A close-up view of the versatile sidewall, illustrating its various storage options including mesh pockets, large pockets, zipper pockets, and an additional hanging strap for organizing items.

Features Overview Video

Video: This video highlights the various features of the Yaheetech 10x10 Pop-up Canopy Tent, including its size, ease of assembly, and the utility of its sidewall pockets.

4. MAINTENANCE

To ensure the longevity of your Yaheetech canopy tent, proper maintenance is essential:

- **Cleaning:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow the fabric to air dry completely before storage to prevent mildew.
- **Frame Care:** Inspect the steel frame regularly for any signs of rust or damage. Clean any dirt or debris from the frame and joints. Lubricate moving parts if necessary.
- **Storage:** Always store the canopy tent in its wheeled carry bag in a dry, cool place, away from direct

sunlight and extreme temperatures. Ensure all components are dry before packing.

Waterproof & UV-Resistant

Designed to block UV rays, resist water, and withstand wear for lasting durability.




Image: A close-up shot of the canopy's fabric, demonstrating its waterproof and UV-resistant properties with water droplets visible on the surface, indicating protection against the elements.

5. TROUBLESHOOTING

If you encounter any issues with your canopy tent, consider the following:

- **Stability Issues:** Ensure all legs are fully extended and locked. Use all provided guy lines, ground anchors, and sandbags to secure the tent, especially in windy conditions.
- **Water Pooling:** While the canopy is waterproof, heavy rain can sometimes cause water to pool. Ensure the canopy fabric is taut and properly stretched over the frame to allow water to run off. Adjust leg heights if necessary to create a slight slope.
- **Difficulty with Setup/Takedown:** Refer to the setup instructions and video. Ensure the push-to-lock mechanism is fully engaged or disengaged. Do not force any parts.


Takedown Video Guide

Video: This video provides a comprehensive guide on how to efficiently take down and pack the Yaheetech 10x10 Pop-up Canopy Tent into its wheeled carry bag.

6. SPECIFICATIONS

Feature	Detail
Brand	Yaheetech
Model Number	615154
Material	Alloy Steel, Polyester Fabric (150D Oxford)
Color	Blue
Item Weight	39.2 Pounds
Product Dimensions	119.29"L x 119.29"W x 104.33"H
Floor Area	100 Square Feet
UV Protection	Yes
Water Resistance Level	Waterproof
Assembly Required	Yes

10_{FT} × 10_{FT}



For warranty information or product support, please refer to the documentation included with your purchase or contact Yaheetech customer service directly. Keep your purchase receipt for any warranty claims.