

ORGBRO X3

ORGBRO X3 Sticker Printer Instruction Manual

Model: X3

1. INTRODUCTION

The ORGBRO X3 is a compact and portable Bluetooth thermal printer designed for various printing needs, including study notes, labels, photos, and more. This device utilizes thermal printing technology, eliminating the need for ink or toner. Its high-resolution output ensures clear and stable prints. This manual provides detailed instructions for setting up, operating, and maintaining your ORGBRO X3 printer.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- ORGBRO X3 Mini Thermal Printer
- 1 Roll of 80mm x 3m White Sticker Thermal Paper
- 3 Rolls of 80mm x 3m Colored Thermal Paper (Yellow, Pink, Blue)
- USB Charging Cable
- User Manual (this document)




Image: The ORGBRO X3 printer shown with various printed materials and included paper rolls.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your ORGBRO X3 printer:

ORGBRO X3


Bluetooth wireless printer



Android



iOS



Document printing



Template printing



Label printing



Provide stickers
for selection



Scanning function



Graffiti function

Image: The ORGBRO X3 printer demonstrating Bluetooth connectivity with a smartphone and icons representing various app functions like document printing, template printing, label printing, sticker selection, scanning, and graffiti.

Key Components:

- **Power Button:** Located on the top, used to turn the printer on/off.
- **Paper Exit Slot:** Where printed paper emerges.
- **Paper Compartment Cover:** Opens to load thermal paper.
- **Charging Port:** For connecting the USB charging cable.
- **Indicator Light:** Displays printer status (e.g., charging, connected, error).

4. SETUP

4.1 Charging the Printer

1. Connect the provided USB charging cable to the printer's charging port.
2. Plug the other end of the USB cable into a standard USB power adapter (not included) or a computer's USB port.
3. The indicator light will show the charging status. Ensure the printer is fully charged before first use for optimal battery life.

4.2 Loading Thermal Paper

1. Gently open the paper compartment cover.
2. Insert a roll of thermal paper into the compartment, ensuring the printing side faces the print head. The printing side is typically smoother and will produce a mark when scratched lightly with a fingernail.
3. Pull a small length of paper out of the compartment, extending it past the paper exit slot.
4. Close the paper compartment cover firmly until it clicks into place.

Supports 4 Sizes of Thermal Paper

Only prints in black fronts. (No Color Printing)




Image: The ORGBRO X3 printer demonstrating the maximum printing width of 3.15 inches (80mm) and examples of various paper sizes it supports, including 0.7" (18mm), 1.1" (28mm), 2.09" (53mm), and 3.15" (80mm).

Compatible with ORGBRO X3 Sticker Printer



Image: The ORGBRO X3 printer shown alongside three rolls of colored thermal paper (yellow, pink, blue), indicating compatibility and dimensions of 76mm (2.99") width and 3m (9.84') total length.

4.3 App Installation and Bluetooth Pairing

1. **Download the App:** Search for the 'ORGBRO' app in your smartphone's app store (Google Play Store for Android or Apple App Store for iOS). Install the application.
2. **Turn on Printer:** Press and hold the power button on the ORGBRO X3 printer until the indicator light illuminates.
3. **Enable Bluetooth:** On your smartphone, go to your device's Bluetooth settings and ensure Bluetooth is enabled.
4. **Pair Device:** Open the ORGBRO app. The app should automatically detect nearby ORGBRO X3 printers. Select 'X3' from the list of available devices to establish a connection. Follow any on-screen prompts to complete the pairing process.

5. OPERATING INSTRUCTIONS

5.1 Printing Functions

The ORGBRO app offers various functions to maximize your printer's utility:

- **Document Printing:** Print text documents, notes, or web pages directly from your phone.
- **Template Printing:** Utilize pre-designed templates for labels, lists, or decorative elements.
- **Label Printing:** Create custom labels for organization, shipping, or personal use.
- **Stickers for Selection:** Access a library of stickers to enhance your prints.
- **Scanning Function:** Convert physical documents or drawings into digital format for printing.
- **Graffiti Function:** Draw or write directly within the app and print your creations.

Widely used in daily life




Image: The ORGBRO X3 printer illustrating its wide range of uses in daily life, including printing labels for gifts, pictures, stickers, study notes, and shopping lists.

Mini thermal printer - Home companion



Image: The ORGBRO X3 printer depicted as a 'Mini thermal printer - Home companion', showcasing applications such as family category labels, study notes, gift cards, and photos.

5.2 Printing Tips

- The ORGBRO X3 is a thermal printer and prints only in black. Color printing is not supported.
- Ensure the thermal paper is loaded correctly with the printing side facing the print head.
- For best results, use ORGBRO brand thermal paper.
- The included paper rolls are self-adhesive, allowing you to easily stick your prints.

Enjoy Efficient Label Creation



Image: Demonstrates the features of ORGBRO sticker paper, highlighting clear printing, easier tearing, and strong adhesive properties.

High Quality ORGBRO Sticker Paper

Clear
Printing



Easier Tearing



Strong Adhesive



Image: Shows various creative labels and stickers printed with the ORGBRO X3 printer, arranged in a journal, illustrating efficient label creation.

Free Coloring Free Imagination



Image: A child coloring a printed image from the ORGBRO X3 printer, emphasizing the 'Free Coloring, Free Imagination' aspect.

6. MAINTENANCE

6.1 Cleaning the Print Head

To ensure optimal print quality, periodically clean the print head:

1. Turn off the printer and disconnect it from the power source.
2. Open the paper compartment cover.
3. Gently wipe the print head with a cotton swab lightly dampened with isopropyl alcohol. Allow it to dry completely before closing the cover and using the printer.

6.2 Paper Storage

Proper storage of thermal paper helps maintain its quality and longevity:

- Store thermal paper in a cool, dry place.
- Keep away from direct sunlight, high humidity, and excessive heat.
- Minimize friction or pressure on the paper rolls to prevent premature discoloration.

7. TROUBLESHOOTING

If you encounter issues with your ORGBRO X3 printer, refer to the following common problems and solutions:

- **Printer not turning on:** Ensure the printer is fully charged. Connect it to a power source and try again.
- **Cannot connect via Bluetooth:**
 - Ensure Bluetooth is enabled on your smartphone and the printer is on.
 - Restart both the printer and your smartphone.
 - Make sure the ORGBRO app has Bluetooth permissions.
- **Poor print quality (faint or blank prints):**
 - Check if the thermal paper is loaded correctly with the printing side facing up.
 - The paper roll might be depleted; replace it with a new one.
 - Clean the print head as described in the Maintenance section.
 - Ensure the paper is not old or damaged from improper storage.
- **Paper jam:**
 - Turn off the printer.
 - Open the paper compartment cover and carefully remove any jammed paper.
 - Ensure the paper is loaded straight and not wrinkled.
- **Printer not responding:** Try resetting the printer by turning it off and on again. If the issue persists, contact customer support.

8. SPECIFICATIONS






Feature	Specification
Model	ORGBRO X3
Printing Technology	Thermal Printing (Inkless)
Resolution	300 DPI
Printing Width	2-3 inches (50-80mm), Max 3.15 inches (80mm)
Print Speed	Up to 47 inches per minute (20 mm/second)
Connectivity	Bluetooth
Paper Type	Thermal Paper (Non-adhesive and Self-adhesive)
Paper Roll Dimensions	80mm (3.15 inches) wide x 3m (9.84 feet) long
Power Source	Rechargeable Battery

9. WARRANTY AND CUSTOMER SUPPORT

The ORGBRO X3 Sticker Printer comes with a standard manufacturer's warranty. For specific warranty details,

please refer to the warranty card included in your package or visit the official ORGBRO website. If you have any questions, require technical assistance, or need to report a defect, please contact ORGBRO customer support through the contact information provided on the product packaging or the official website. Please have your product model and purchase date ready when contacting support.

Related Documents - X3

	<p>ORGBRO X1 Thermal Label Printer User Guide</p> <p>Comprehensive user guide for the ORGBRO X1 Thermal Label Printer, covering setup, operation, charging, product information, and FCC compliance.</p>
	<p>Easythreed X3 3D Printer Installation Manual - Setup Guide</p> <p>Step-by-step installation manual for the Easythreed X3 3D Printer. Includes parts list, assembly instructions, and connection guides for easy setup.</p>
	<p>X3 S TTL</p> <p>X3 S TTL</p>
	<p>Godox AD600ProII</p> <p>Godox AD600ProII</p>
	<p>Godox X3 Pro TTL Wireless Flash Trigger Instruction Manual</p> <p>Explore the Godox X3 Pro TTL Wireless Flash Trigger, a professional tool for photographers. This manual details its advanced features, including TTL and manual flash modes, a 2.4-inch touchscreen, extensive camera compatibility, and stable wireless performance for creative lighting control.</p>