

[Manuals.plus](#) /

› [Fonus](#) /

› Fonus Wireless Ear-Hook TWS Earphones User Manual

Fonus Fo-FO28714T7K-171

Wireless Ear-Hook TWS Earphones User Manual

Model: Fo-FO28714T7K-171

INTRODUCTION

Thank you for choosing the Fonus Wireless Ear-Hook TWS Earphones. This manual provides detailed instructions on how to set up, operate, and maintain your new earphones. Please read this manual carefully before use to ensure optimal performance and longevity of your device.

PACKAGE CONTENTS

Please check the package for the following items:

- Wireless Ear-Hook TWS Earphones (Left and Right)
- Charging Case
- USB Charging Cable
- Multiple Sizes of Ear Tips (XS, S, M, L, XL)
- User Manual



Image: The Fonus Wireless Ear-Hook TWS Earphones resting in their charging case, displaying the digital LED screen.

PRODUCT OVERVIEW

Familiarize yourself with the components of your earphones and charging case.



Image: The charging case with the earbuds inside, showing a 100% battery level on the digital LED display.



Image: The open charging case, showing the molded slots for the left and right earbuds.

Dual LED Digital Power Display

Checking the remaining battery & charging status at a glance




Image: A detailed diagram illustrating the dual LED digital power display on the charging case, indicating battery levels for both the case and individual earbuds (L and R).

Key Features:

- **Digital LED Display:** Shows battery levels for the charging case and individual earbuds.
- **Ergonomic Ear-Hook Design:** Provides a secure and comfortable fit, ideal for sports and extended wear.
- **Bluetooth 5.3 Technology:** Ensures stable connection and faster data transfer speeds.
- **Long Playtime:** Up to 10 hours on a single charge, with a total of 50 hours using the charging case.
- **IPX7 Waterproof:** Resistant to sweat and rain, suitable for workouts.
- **Dual Volume Control:** Independent volume and track controls on each earbud.

CHARGING YOUR EARPHONES

To ensure optimal performance, fully charge your earphones and charging case before first use.

1. **Charging the Earbuds:** Place the earbuds into the charging case. They will automatically begin charging. The LED

display on the case will show the individual earbud battery levels.

2. **Charging the Case:** Connect the charging case to a USB power source using the provided USB cable. The digital LED display on the case will flash and show the charging progress (from 1 to 100).

A full charge for the earbuds provides approximately 10 hours of playtime. The charging case holds enough power for 4 additional charges, extending total listening time to about 50 hours.



Image: An illustration demonstrating the extended playtime, showing 10 hours for a single earbud charge and 50 hours total with the charging case providing 4 additional charges.

SETUP AND PAIRING

Follow these steps to pair your earphones with your device:

1. **Power On:** Open the charging case, and the earbuds will automatically power on and enter pairing mode.
2. **Activate Bluetooth:** On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings and turn on Bluetooth.

3. **Select Device:** Look for "Fonus Earphones" (or similar name) in the list of available devices and select it to connect.
4. **Confirmation:** Once connected, you will hear a voice prompt confirming the successful pairing. The LED indicator on the earbuds may change.

The earphones will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

Single Earbud Mode:

You can use either the left or right earbud independently. Simply take one earbud out of the case, and it will automatically connect to your device. The other earbud can remain in the case or be used later for stereo sound.



Image: A visual representation of the advanced Bluetooth 5.3 chip, highlighting its role in providing a stable and fast connection.

OPERATING YOUR EARPHONES

Touch Controls:

The earphones feature touch-sensitive controls on each earbud. Specific functions may vary slightly based on your device and operating system.

Action	Function
Single Tap (L/R)	Play/Pause Music, Answer/End Call
Double Tap (L)	Previous Track
Double Tap (R)	Next Track
Triple Tap (L/R)	Activate Voice Assistant
Long Press (L)	Volume Down
Long Press (R)	Volume Up
Long Press (2s) during call	Reject Call

Wearing Instructions:

For the best audio experience and secure fit, ensure you wear the earphones correctly.

1. **Choose the Right Ear Tips:** Select the ear tips that provide the most comfortable and secure seal for your ear canal. The package includes XS, S, M, L, XL sizes.
2. **Position the Ear-Hook:** Gently place the earbud into your ear canal and loop the ear-hook over the top of your ear.
3. **Adjust for Comfort:** Adjust the earbud and ear-hook until it feels snug and stable. The flexible ear-hooks are designed to conform to your ear's shape.

Designed for Sports

Equipped with 5 pairs of eartips to fit the ear curves and flexible ear hooks make your ear relax and focus on sports, no worry for falling troubles!



Image: An illustration detailing the ergonomic design, flexible ear-hook, and the five different sizes of ear tips (XS, S, M, L, XL) included for a customized fit.

MAINTENANCE AND CARE

Proper care will extend the lifespan of your earphones.

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, always store the earphones in their charging case to protect them from dust and damage.

- **Water Resistance:** The earphones are IPX7 waterproof, meaning they can withstand sweat and rain. However, they are not designed for swimming or submersion in water. Ensure they are dry before placing them back in the charging case.
- **Temperature:** Avoid exposing the earphones to extreme temperatures (hot or cold) or high humidity.

IPX7 Waterproof Sports Earbuds

No worry for any rains and sweats, go straight to enjoy your sports time!




Image: A person exercising, demonstrating the IPX7 waterproof feature of the sports earbuds, showing resistance to sweat and splashes.

TROUBLESHOOTING

If you encounter any issues, please refer to the following common solutions:

Problem	Solution
---------	----------

Problem	Solution
Earbuds not pairing with device	◦ Ensure earbuds are fully charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget the device in your Bluetooth settings and re-pair. ◦ Place earbuds back in the case, close, then reopen to reset.
Only one earbud working	◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the charging case, close the lid for 5 seconds, then open again. ◦ Check if your device's audio output is set to stereo.
Low volume or poor sound quality	◦ Adjust volume on both the earbuds and your connected device. ◦ Ensure ear tips are properly sealed in your ear canal. ◦ Clean any debris from the earbud speakers. ◦ Move closer to your connected device to avoid interference.
Charging case not charging	◦ Check the USB cable and power adapter. ◦ Ensure the charging port is clean and free of debris. ◦ Try a different USB port or power source.

SPECIFICATIONS

Feature	Detail
Model Number	Fo-FO28714T7K-171
Brand	Fonus
Connectivity	Wireless (Bluetooth 5.3)
Earbud Playtime	Up to 10 hours (single charge)
Total Playtime (with case)	Up to 50 hours
Charging Case Battery Capacity	500mAh
Water Resistance Rating	IPX7
Driver Size	13mm Biocomposite Membrane
Color	Black
Item Weight	4 ounces
UPC	701052287141

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official Fonus website. Keep your proof of purchase for any warranty claims.

Manufacturer: Fonus

Date First Available: January 24, 2025

© 2025 Fonus. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DTZ73CZM>

More documents and user manuals: <https://manuals.plus/>