

manuals.plus /

› [NEBO](#) /

› [NEBO SLYDE King 4K Rechargeable Flashlight and Work Light Instruction Manual](#)

NEBO NEB-WLT-0031

NEBO SLYDE King 4K Rechargeable Flashlight and Work Light Instruction Manual

Model: NEB-WLT-0031

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your NEBO SLYDE King 4K Rechargeable Flashlight and Work Light. Please read this manual thoroughly before operating the device and retain it for future reference.



Image 1: The NEBO SLYDE King 4K, a versatile rechargeable flashlight and work light.

SAFETY INFORMATION

To ensure safe operation, always follow these guidelines:

- Do not look directly into the LED light. The intense light output can cause temporary vision impairment.
- Keep out of reach of children.
- Do not disassemble the unit. This will void the warranty and may cause damage.
- Use only the provided USB-C charging cable or a certified equivalent.
- Do not expose the battery to extreme temperatures or fire.
- Ensure the charging port cover is securely closed when not charging to maintain water resistance.

PACKAGE CONTENTS

Verify that all items are present in your package:

- NEBO SLYDE King 4K Flashlight and Work Light
- USB-C to USB Charging Cable
- Lanyard
- Instruction Manual (this document)

SETUP

Initial Charge

Before first use, fully charge the NEBO SLYDE King 4K. The device comes with a pre-installed rechargeable lithium-ion battery.

1. Locate the USB-C charging port on the flashlight. It is typically covered by a rubber flap to protect against water and dust.
2. Open the rubber flap and insert the small end of the USB-C charging cable into the port.
3. Connect the larger USB-A end of the cable to a powered USB port (e.g., computer, wall adapter, power bank).
4. The power button will illuminate to indicate charging status. A red light indicates charging, and a blue light indicates a full charge.
5. Charging typically takes 4 to 8 hours for a full charge.
6. Once fully charged, disconnect the cable and securely close the rubber flap over the charging port.




Image 2: The NEBO SLYDE King 4K connected to a USB-C charging cable.

Attaching the Lanyard

Attach the included lanyard to the designated loop on the flashlight's tail cap for added security and ease of carrying.

OPERATING INSTRUCTIONS

Power Button Functions

The power button controls all light modes and power functions.

- **Press and Release:** Cycles through flashlight modes (High, Low).
- **Double Press:** Activates the work light (COB).
- **Press and Hold:** Activates dimming function for current mode.
- **Direct-to-Red:** When the work light is active, press and hold to switch to red light mode.

Flashlight Operation

The front-facing LED flashlight offers powerful illumination and adjustable focus.

1. **Turn On/Off:** Press the power button once to turn on the flashlight. Press again to cycle through modes or turn off after a few seconds in a single mode.
2. **Modes:** The flashlight has High (4000 lumens) and Low (400 lumens) modes.
3. **Zoom Function:** Twist the head of the flashlight to adjust the beam from a wide floodlight to a focused spotlight (4X zoom).



FLASHLIGHT

Light up the night with 400 to 4000 lumens to see near or far.



Image 3: The NEBO SLYDE King 4K flashlight in use, demonstrating its powerful beam.



4X ZOOM

Twist-focus beam for floodlight or spotlight.



Image 4: Illustrates the 4X zoom capability, switching between floodlight and spotlight modes.

Work Light (COB) Operation

The COB work light provides broad area illumination and features a unique slide-to-reveal design.

1. **Activate:** Slide the body of the flashlight downwards to reveal the COB work light. The work light will automatically turn on.
2. **Modes:** The work light has High (1000 lumens) and Low (100 lumens) white light modes.
3. **Red Light Mode:** From the white work light mode, press and hold the power button to switch to Red High (40 lumens), Red Low (4 lumens), and Red Flashing (40 lumens) for emergency signaling or preserving night vision.
4. **Turn Off:** Slide the body upwards to conceal the COB work light, which will turn it off. Alternatively, cycle through modes until off, or press and hold the power button.



Image 5: The innovative slide-to-reveal design of the NEBO SLYDE King 4K, exposing the COB work light.




Image 6: The COB work light in operation, providing wide-area illumination.



Image 7: The work light operating in red mode, useful for night vision preservation or signaling.

Magnetic Base

The powerful magnetic base allows for hands-free operation by attaching the flashlight to metallic surfaces.



Image 8: The magnetic base securely holding the flashlight to a metal surface for hands-free use.

Power Memory

The SLYDE King 4K features power memory, which means it will remember the last used light mode (flashlight or work light, and its intensity) when turned back on, provided it was off for more than 8 seconds.

MAINTENANCE

- **Cleaning:** Wipe the flashlight with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Charging Port:** Keep the USB-C charging port clean and free of debris. Ensure the rubber flap is sealed when not charging to maintain water resistance.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Recharge regularly. If storing for an extended period, charge the battery to approximately 50% every 3-6 months.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is depleted.	Charge the flashlight using the USB-C cable.
Light output is dim.	Low battery level.	Recharge the battery.
Work light does not activate.	Not fully slid open.	Ensure the body is fully slid down to reveal the COB light.
Charging indicator light is not working.	Cable not properly connected or faulty.	Ensure the USB-C cable is securely connected to both the flashlight and the power source. Try a different USB port or cable.
Water ingress after exposure.	Charging port flap not sealed.	Always ensure the rubber flap covering the USB-C port is securely closed when not charging to maintain IPX7 water resistance.

SPECIFICATIONS

Feature	Detail
Model Number	NEB-WLT-0031
Light Output (Flashlight High)	4000 Lumens
Light Output (Flashlight Low)	400 Lumens
Light Output (Work Light High)	1000 Lumens
Light Output (Work Light Low)	100 Lumens
Light Output (Red High)	40 Lumens
Light Output (Red Low)	4 Lumens
Light Output (Red Flashing)	40 Lumens
Battery Type	Rechargeable Lithium-Ion (2600 mAh, 3.7V)
Charging Time	4-8 hours via USB-C
Material	Anodized Aircraft-Grade Aluminum
Water Resistance	IPX7 (Submersible up to 1 meter for 30 minutes)
Impact Resistance	Yes
Dimensions (Compact)	20.7 cm (8.15 inches) Length, 4.5 cm (1.77 inches) Diameter
Dimensions (Extended)	25.9 cm (10.2 inches) Length
Weight	548.85 g (1.21 lbs)
Included Components	USB-C Charging Cable, Lanyard

NEBO [®] SLYDEKING 4K			
MODES	OUTPUT (LUMENS)	RUNTIME (HOURS)	DISTANCE (METERS/YARDS)
FLASHLIGHT HIGH	4000	1	350m / 382yd
FLASHLIGHT LOW	400	6	100m / 109yd
WORK LIGHT HIGH	1000	4	35m / 38yd
WORK LIGHT LOW	100	24	10m / 10yd
RED HIGH	40	6	-
RED LOW	-	35	-
RED FLASHING	-	-	-
*Low modes are accessed via dimming function			

Image 9: Detailed specifications for each light mode, including output, runtime, and beam distance.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official NEBO website or contact their customer service directly. Keep your purchase receipt as proof of purchase.


Online Support: [Visit NEBO Support Page](#)

Manufacturer: NEBO

Manufacturer Part Number: NEB-WLT-0031

© 2023 NEBO. All rights reserved.


Related Documents - NEB-WLT-0031

	<p>NEBO Slyde King 2K Flashlight: 2000 Lumens, Work Light, 4X Zoom</p> <p>Discover the NEBO Slyde King 2K, a powerful rechargeable flashlight featuring 2000 lumens, an integrated 500-lumen C•O•B work light, 4X zoom, and adjustable brightness with memory. Learn about its modes, specifications, and charging indicator.</p>
-------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



[NEBO SLYDE+ Flashlight: Features, Modes, and Instructions](#)

Discover the NEBO SLYDE+ flashlight, featuring 4 light modes, 4x zoom, dimmable beam, C•O•B LED technology, and a magnetic base. Get detailed instructions and specifications.



[Nebo Slyde King 2K Flashlight User Guide](#)

Comprehensive guide to the Nebo Slyde King 2K flashlight, detailing its features, light modes, brightness dimming, work light functionality, 4x zoom, and rechargeable battery. Learn how to operate and maintain your Nebo flashlight.

NEBO

SLYDE KING™ 1K

The Slyde King™ 1K combines a powerful 1000 lumen LED flashlight with a 500 lumen work light.

The Worklight is revealed when pulling up on the flashlight head, extending the neck.

LED spot and COB work/red lights feature dimming and memory.

FEATURES:

- IP67 dust and waterproof
- Integrated Zoom
- Rugged aircraft aluminum
- 1 meter drop resistant
- Anti-roll magnetic base
- Lampard included

RECHARGEABLE

Lithium-Ion Rechargeable Battery included.

To charge, connect the light to a power source with the included USB cable. The power button serves as a battery indicator when the light is on and a charging indicator when plugged in.

Steadily Orange: Battery more than 25%
Flashing Orange: Battery less than 25%

Pulsing Green: Battery charging
Steadily Green: Battery fully charged

OPERATION

Press the power button to turn on light

Brightness/Dimming
Lights have continuous dimming and brightening cycling with memory.

When ON, press and hold power button to activate dimming, release to set desired brightness. Double-tap to recall last saved mode.

WORK LIGHT

Slide open to activate the work light. Press and release power button to switch between White, Red, and Flash modes. For Direct-to-Red, hold power button while sliding the work light open.

PRODUCT GUARANTEE

If you experience a problem, please do not return to your local store. Contact our Customer Service team at 800-425-6065 or NEBO@light15.com

For more information, detailed video instructions, and warranty registration, visit NEBO.light15.com

[NEBO SLYDE KING™ 1K Rechargeable LED Flashlight: Features and Operation](#)

Detailed information on the NEBO SLYDE KING™ 1K, a rechargeable LED flashlight with a powerful 1000 lumen flashlight and 500 lumen work light, featuring dimming, memory, and IP67 rating. Learn about its operation, battery system, and product guarantee.

[NEBO Franklin Pivot RC Rechargeable LED Work Light User Guide](#)

User guide for the NEBO Franklin Pivot RC, detailing its features, specifications, light modes, charging, and power memory recall. Includes warranty and disposal information.



[NEBO Franklin Dual LED Flashlight - Features and Operation](#)

Detailed overview of the NEBO Franklin Dual LED flashlight, including its high-powered flashlight and work light modes, operational features like Power Memory Recall and Direct-to-Red, rechargeable battery, and specifications.