Calvin Klein Distinguish 25200488

Calvin Klein Men's Distinguish 44mm Quartz Watch Instruction Manual

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Calvin Klein Men's Distinguish 44mm Quartz Watch. Please read this manual thoroughly to ensure proper use and care of your timepiece.

Setup

Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to the outermost position.
2. **Set the time:** Rotate the crown to adjust the hour and minute hands to the correct time. For watches with a date function, ensure you set the time correctly for AM/PM to avoid the date changing at noon.
3. **Set the date (if applicable):** If your watch has a date display, push the crown halfway in and rotate it to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the date change mechanism.
4. **Push in the crown:** Once the time and date are set, push the crown back into its original position against the watch case to start the watch movement and ensure water resistance.

Adjusting the Bracelet

The stainless steel bracelet may require adjustment for a comfortable fit. This typically involves removing or adding links. It is recommended to have this procedure performed by a qualified jeweler or watch technician to prevent damage to the bracelet or watch.
If you choose to adjust it yourself, you will need a specialized watch link removal tool. Follow these general steps:

1. **Identify removable links:** Look for small arrows on the inside of the bracelet links, indicating the direction to push out the pins.
2. **Remove pins:** Use the link removal tool to push out the pins in the direction of the arrows.
3. **Remove links:** Remove the desired number of links, ensuring an even number are removed from each side of the clasp for balance.
4. **Reassemble:** Reinsert the pins in the opposite direction to secure the bracelet.



Image: Calvin Klein Distinguish watch worn on a man's wrist, demonstrating typical fit.




Image: Calvin Klein Watch Sizing Guide, illustrating different watch sizes on 6-inch and 7-inch wrists for reference.

Operating Your Watch

Timekeeping

Your Calvin Klein Distinguish watch features a precise quartz movement, providing accurate timekeeping with minimal maintenance.

GMT Function

The watch includes a GMT function with a 24-hour track and an additional hour hand. This allows you to track a second time zone simultaneously. The GMT hand can be set independently to display the time in a different time zone.

Water Resistance

This watch is water resistant up to 30 meters (100 feet) or 3 ATM. This means it is suitable for splashes or brief immersion in water, such as washing hands or light rain. **It is not suitable for swimming, showering, diving, or any water sports.** Always ensure the crown is fully pushed in to maintain water resistance.

Maintenance and Care

Proper care will extend the life and maintain the appearance of your Calvin Klein watch.

Cleaning

- Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dirt and moisture.
- For stainless steel bracelets, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials.

Battery Replacement

Your quartz watch is powered by a battery. When the battery runs low, the watch may stop or the second hand might jump in irregular intervals (End-of-Life indicator). Battery replacement should be performed by an authorized Calvin Klein service center or a professional watchmaker to ensure the watch's integrity and water resistance are maintained. **Never attempt to open the watch yourself**, as this can void the warranty and damage internal components.

Service Interval

A maintenance interval of 3 to 5 years is recommended for your timepiece, in addition to any required battery replacement. This service helps ensure the watch continues to function optimally.



Image: Rear view of the Calvin Klein Distinguish watch, displaying the stainless steel case back and water resistance rating.

Troubleshooting

If you encounter issues with your watch, please refer to the following common solutions:

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Incorrect time:** Reset the time as described in the "Setting the Time and Date" section.
- **Date not changing:** Ensure the time is set correctly for AM/PM. If the date changes at noon, you have set the time for

the wrong 12-hour cycle. Advance the time by 12 hours.

- **Water inside the watch:** If condensation or water appears inside the watch, immediately take it to a professional watchmaker. This indicates a breach in water resistance.

For issues not resolved by these steps, contact Calvin Klein customer support or an authorized service center.

Specifications

Feature	Detail
Model Name	Distinguish
Model Number	25200488
Movement Type	Quartz
Display Type	Analog
Case Material	Stainless Steel
Band Material	Stainless Steel
Case Diameter	44 Millimeters
Case Thickness	10.2 Millimeters
Band Width	13 Millimeters
Crystal Type	Mineral
Water Resistance Depth	30 Meters (3 ATM)
Clasp Type	Push Button Deployment Clasp
Item Weight	145.5 Grams





Image: Front view of the Calvin Klein Distinguish 44mm Quartz Watch with blue dial and stainless steel bracelet.

Warranty Information

Your Calvin Klein Distinguish watch comes with a limited warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects under normal use.

Keep your proof of purchase for any warranty claims.



Image: Calvin Klein watch packaging box and included warranty information card.

Customer Support

For further assistance, service, or warranty inquiries, please contact Calvin Klein customer support or visit their official website. You can find contact information on the warranty card or through the brand's official channels.
When contacting support, please have your watch model number (25200488) and proof of purchase readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question