

- Manuals.plus /
- › Grandeur /
- › Grandeur Carré Crystal 1-3/4” Cabinet Knob in Satin Nickel Instruction Manual

Grandeur 853349

Grandeur Carré Crystal 1-3/4” Cabinet Knob in Satin Nickel Instruction Manual

PRODUCT OVERVIEW

The Grandeur Carré Crystal Cabinet Knob, model 853349, is a premium hardware component designed for cabinetry. This knob features precisely crafted, stepped edges made from lead-free crystal, which catches and refracts light, providing an elevated tactile and visual experience. It is seated on a solid brass base and finished in Satin Nickel, offering a sophisticated aesthetic for various interior designs.



Image: Grandeur Carré Crystal Cabinet Knob in Satin Nickel, showcasing its faceted crystal design and metal base.

Key Features:

- Lead-free crystal for unmatched clarity and brilliance.
- Solid brass base ensures durability and a secure mounting.
- Includes both long and short screw lengths to accommodate various cabinet thicknesses for easy installation.
- Suitable for cabinetry in kitchens, bathrooms, and furniture throughout the home.
- Features a 10-Year finish warranty.

SETUP AND INSTALLATION

This section provides step-by-step instructions for installing your Grandeur Carré Crystal Cabinet Knob. Ensure you have the necessary tools before beginning.

Tools Required:

- Measuring tape or ruler
- Pencil
- Drill with appropriate drill bit (typically 3/16" or 5mm for cabinet hardware)
- Screwdriver (Phillips head recommended)
- Protective eyewear (recommended)

Installation Steps:

1. **Determine Placement:** On the cabinet door or drawer front, use a measuring tape and pencil to mark the desired location for the knob. For consistency, measure from the edges of the cabinet.
2. **Drill Pilot Hole:** Carefully drill a pilot hole through the marked spot. Ensure the drill bit size is appropriate for the screw provided, typically 3/16 inch (5mm), to prevent splitting the wood. Drill straight through the cabinet material.
3. **Attach Knob:** Insert the screw from the inside of the cabinet door or drawer through the drilled hole. Align the knob on the outside of the cabinet with the screw.
4. **Secure Knob:** Using a screwdriver, turn the screw clockwise until the knob is firmly attached. Do not overtighten, as this can damage the cabinet material or the knob. Choose the appropriate screw length (long or short) based on your cabinet thickness.



Image: A Grandeur Carré Crystal Cabinet Knob (Satin Brass variant shown for illustration) installed on a white cabinet door, demonstrating typical placement.

OPERATING INSTRUCTIONS

The Grandeur Carré Crystal Cabinet Knob is designed for straightforward operation.

- To open a cabinet door or drawer, grasp the knob firmly and pull.
- To close, push the door or drawer until it is fully shut.
- The knob does not require any special turning mechanism; it functions as a pull handle.

CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your Grandeur Carré Crystal Cabinet Knob.

- **Cleaning:** Use a soft, damp cloth to wipe the crystal and metal surfaces. For stubborn marks, a mild soap solution

can be used, followed by wiping with a clean, dry cloth.

- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, ammonia-based products, or strong chemical solvents, as these can damage the finish of the brass and the clarity of the crystal.
- **Regular Inspection:** Periodically check the tightness of the mounting screw. If the knob feels loose, gently tighten the screw from the inside of the cabinet.
- **Crystal Care:** While durable, crystal can chip or scratch if subjected to hard impacts. Handle with care.

TROUBLESHOOTING

This section addresses common issues you might encounter with your cabinet knob.

Problem	Possible Cause	Solution
Knob feels loose.	Mounting screw has loosened over time.	From the inside of the cabinet, gently tighten the screw with a Phillips head screwdriver until the knob is secure. Do not overtighten.
Knob is difficult to pull.	Cabinet door/drawer mechanism is stiff or misaligned.	Inspect the cabinet hinges or drawer slides. Lubricate if necessary, or adjust alignment. The knob itself should not cause resistance.
Crystal appears dull or dirty.	Accumulation of dust, grime, or residue from cleaning products.	Clean the crystal and metal base with a soft, damp cloth and a mild soap solution. Wipe dry immediately with a clean, lint-free cloth. Avoid harsh chemicals.

PRODUCT SPECIFICATIONS

Detailed specifications for the Grandeur Carré Crystal Cabinet Knob (Model 853349).

Model Number	853349
Brand	Grandeur
Material	Brass, Crystal
Color	Satin Nickel
Product Dimensions (L x W)	1.75"L x 1.06"W
Projection Distance	1.75 inches
Item Weight	1.76 ounces
Handle Type	Knob
Included Components	Cabinet knob and screw to install (long and short lengths).
Specific Uses	Cabinets, Cupboards, Drawers
Indoor/Outdoor Usage	Indoor
UPC	662972533490
ASIN	B0DV23KLV6

WARRANTY INFORMATION

The Grandeur Carré Crystal Cabinet Knob comes with a manufacturer's warranty to ensure your satisfaction.

- **Finish Warranty:** This product is backed by a 10-Year finish warranty. This warranty covers defects in the finish under normal use and maintenance.
- For specific terms and conditions of the warranty, please refer to the official Grandeur Hardware website or contact customer support.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to report a warranty claim, please contact Grandeur customer support.

- **Manufacturer:** Grandeur
- **Website:** For further information and support resources, please visit the official [Grandeur Store on Amazon](#) or the manufacturer's official website.
- When contacting support, please have your product model number (853349) and purchase details available.

© 2026 Grandeur. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DV23KLV6>

More documents and user manuals: **<https://manuals.plus/>**