



[Manuals.plus](#) /

› [Greesum](#) /

› Greesum 7-Piece Outdoor Patio Dining Set (Model GS-TB5023C-7) Instruction Manual

## Greesum GS-TB5023C-7

# Greesum 7-Piece Outdoor Patio Dining Set (Model GS-TB5023C-7) Instruction Manual

Comprehensive guide for assembly, usage, maintenance, and safety.

## 1. INTRODUCTION

Thank you for choosing the Greesum 7-Piece Outdoor Patio Dining Set. This manual provides essential information for the safe assembly, proper use, and effective maintenance of your new outdoor furniture. Please read these instructions carefully before assembly and retain this manual for future reference.



Image 1.1: The Greesum 7-Piece Outdoor Patio Dining Set arranged on a patio, featuring a table and six chairs with cushions, set against a scenic outdoor backdrop.

## 2. SAFETY INFORMATION

- Ensure the table is level using the adjustable foot pads to maintain stability and prevent wobbling.
- Exercise caution when sitting in high-back chairs to prevent accidental tip-overs, especially on uneven surfaces.
- Always follow the provided assembly instructions precisely for safe and secure setup.
- Regularly inspect the furniture for any signs of wear, damage, or weathering effects. Address any issues promptly to ensure continued safety and structural integrity.
- Keep small children and pets away from the assembly area during setup to prevent injury.

## 3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x Dining Table

- 6 x Rattan Chairs with Cushions
- 1 x Tool Kit (for assembly)
- 1 x Assembly and Usage Manual (this document)



Image 3.1: An overhead perspective of the Greesum 7-Piece Outdoor Patio Dining Set, showcasing the rectangular table and six individual chairs, highlighting the complete set.

## 4. SETUP AND ASSEMBLY

---

The Greesum 7-Piece Outdoor Patio Dining Set is designed for straightforward assembly. All necessary tools and detailed instructions are included in your package. Please follow the step-by-step guide provided in the separate assembly manual for proper construction.

### Key Assembly Considerations:

- Ensure all bolts and screws are tightened securely, but do not overtighten to avoid damaging components.
- Assemble on a soft, clean surface to prevent scratches to the furniture.
- It is recommended to have two people for assembly, especially for the dining table, to ensure stability and ease of handling.

# PRODUCT DIMENSIONS



Image 4.1: A diagram illustrating the dimensions of the Greesum dining table (59.1" L x 35.4" W x 29.3" H) and a single chair (33.07" H x 19.09" W x 20.78" D, seat height 16.14", seat depth 19.68"). The image also indicates that the product ships in three separate boxes.

# RATTAN TABLE&CHAIRS

The long service life, upgraded material..



Image 4.2: Detailed view of the Greesum rattan chair highlighting key features: durable, waterproof, and easy-to-care rattan weave; an adjustable leg design for balance; a waterproof and padded cushion with a smooth zipper for easy removal and washing; and high-quality acacia wooden armrests.

## 5. OPERATING AND USAGE

This 7-piece dining set is designed for outdoor use, providing a comfortable and elegant space for dining and conversation. The large dining table offers ample space for food, drinks, and other items, while the six chairs provide a cozy seating experience.

### Key Usage Points:

- **Stability:** The dining table is equipped with adjustable foot pads to ensure stability on various outdoor surfaces. Adjust as needed to prevent wobbling.
- **Comfort:** The chairs feature a high back, widened design, curved acacia wooden armrests, and soft cushions for enhanced comfort during extended use.
- **Placement:** Position the set on a flat, stable surface. Avoid placing it directly under heavy objects or in areas prone to strong winds without additional securing.



Image 5.1: The Greesum 7-Piece Outdoor Patio Dining Set positioned beside a swimming pool, demonstrating its suitability for poolside relaxation and dining.

## 6. MAINTENANCE

Proper maintenance will extend the life and preserve the appearance of your Greesum outdoor dining set.

### Cleaning Instructions:

- **Tabletop:** The acacia wood tabletop can be cleaned effortlessly by simply wiping it down with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly.
- **Rattan and Frame:** The PE rattan wicker and rust-resistant steel frame can be cleaned with a soft cloth and mild soapy water. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The cushions feature a smooth zipper for easy removal. The cushion covers can be hand-washed or machine-washed on a gentle cycle with cold water. Air dry only; do not tumble dry.

### General Care:

- Regularly inspect the furniture for any loose bolts or screws and tighten them as necessary.
- During periods of harsh weather (heavy rain, snow, strong winds), it is recommended to cover the furniture or store it indoors to protect it from damage.

- Periodically check the acacia wood for signs of weathering and consider applying a suitable wood protector or sealant to maintain its appearance and longevity.



Image 6.1: A detailed view of the Greesum solid wood desktop, emphasizing its acacia wood construction, ease of cleaning with a damp cloth, and the natural elegance of its wood grain.

## 7. TROUBLESHOOTING

This section addresses common issues you might encounter with your dining set.

- **Wobbly Table/Chairs:** Check all connections and tighten any loose bolts. Utilize the adjustable foot pads on the table to level it on uneven surfaces.
- **Scratches on Armrests:** If minor scratches occur on the acacia wooden armrests, they can often be minimized with wood polish or a furniture marker designed for wood.
- **Cushion Stains:** For removable cushion covers, follow the cleaning instructions in the Maintenance section. For non-removable stains, spot clean with a mild fabric cleaner.
- **Rattan Damage:** Small breaks in the PE rattan can sometimes be repaired with a strong, flexible adhesive. For significant damage, contact customer support for replacement options.

## 8. SPECIFICATIONS

| Feature                      | Detail                                                          |
|------------------------------|-----------------------------------------------------------------|
| Brand                        | Greesum                                                         |
| Model Number                 | GS-TB5023C-7                                                    |
| Set Configuration            | 1 Dining Table, 6 Chairs                                        |
| Table Dimensions (L x W x H) | 59.1 x 35.4 x 29.3 inches                                       |
| Chair Dimensions (L x W x H) | Approx. 20.78 x 19.09 x 33.07 inches (based on diagram)         |
| Item Weight                  | 46.5 pounds (total package weight may vary)                     |
| Color                        | Black                                                           |
| Materials                    | Acacia Wood (tabletop, armrests), PE Rattan Wicker, Steel Frame |
| UPC                          | 760606756335                                                    |

## 9. WARRANTY AND SUPPORT

While specific warranty details are not provided in this manual, Greesum is committed to customer satisfaction. For any questions, concerns, or assistance with your product, please contact Greesum customer support.

You can visit the official Greesum store for more information and support:

[Visit the Greesum Store on Amazon](#)